

95445028 *N*



CDC[®]
MATRIX PRINTER EQUIPMENT
CT104A-B-C-D-E

INTRODUCTION
OPERATING INSTRUCTIONS
PRINCIPLES OF OPERATION
INSTALLATION AND CHECKOUT
MAINTENANCE
FAULT ISOLATION
TEST AND ADJUSTMENTS
DIAGRAMS

FIELD SERVICE AND REFERENCE MANUAL

95445028



CDC[®]
MATRIX PRINTER EQUIPMENT
CT104A-B-C-D-E

INTRODUCTION
OPERATING INSTRUCTIONS
PRINCIPLES OF OPERATION
INSTALLATION AND CHECKOUT
MAINTENANCE
FAULT ISOLATION
TEST AND ADJUSTMENTS
DIAGRAMS

FIELD SERVICE AND REFERENCE MANUAL

REVISION RECORD

REVISION	DESCRIPTION
<p>A 4-77</p> <p>B 7-77</p> <p>C 10-77</p> <p>D 1-1-78</p> <p>D₁ 1-8-78</p> <p>E 4-78</p> <p>F 7-78</p> <p>F₁ 7-17-78</p> <p>G 10-78</p> <p>H 1-79</p> <p>I 4-79</p> <p>J 4-80</p> <p>K 7-80</p> <p>L 10-80</p> <p>M 1-81</p> <p>N 7-81</p>	<p>Initial release of the CDC 70/125 LPM Matrix Printer</p> <p>To incorporate editorial comments.</p> <p>To incorporate ECO's: PH14771 & PH14836 - Spec set up of VFU Brushes & adjusting procedure.</p> <p>To incorporate ECO's" PH14903-Improve horizontal line to line registration, PH14911-Upper cabinet lock. , PH14995-Update spec. , PH15001-Replaceable head</p> <p>Revised table of contents to reflect new section 10 and added new section 10 to manual.</p> <p>To Incorporate Review Comments.</p> <p>To Incorporate ECO's: PH15311-Character Rom, PH15318- Code disk, PH15381- Spec dimensions, PH15413-Needle driver PCB & Fuse harness and PE corrections.</p> <p>Revised to incorporate print head to platen set-up.</p> <p>Revised to incorporate ECO's: PH15139-Controller-Head logic, PH15504-Character definition, PH15544-Adj. timing drive pulley, PH15568-Rom Set, PH15570-Needle Drivers, PH15578-Char Prom.</p> <p>Revised to incorporate ECO's: PH15689-Character definition, PH15690-Character definition, PH15736-Character definition, PH15737-Character definition, PH15738-Character definition.</p> <p>Revised to incorporate CE comments</p> <p>Revised to incorporate ECO's: PH16513- Pots P1 & P3 factory adjust only, PH16529-Power cord receptacle.</p> <p>Revised to incorporate ECO's: PH16589- Assy Adj; Spec Code strip note, PH16684-Cleaning & ADJ Code Strip.</p> <p>Revised to incorporate-EECO PH17000- Code strip Brkt Adj.</p> <p>NOT AFFECTED</p> <p>Incorporate CE correction.</p>

PUBLICATION NO.

95445028

PREFACE

This publication contains reference information for maintaining the CDC 70/125 LPM Matrix Printer.

Associated Publications

Parts Identification Manual (Publication No. 95445027)

* RS-232 Buffered and Unbuffered Interface Field Service, Reference and Parts Manual (Publication No. 95445069).

* Special interface used on some printers.

CDC
TABLE OF CONTENTS

<u>Section</u>	<u>Description</u>	<u>Page</u>	<u>Section</u>	<u>Description</u>	<u>Page</u>
1	INTRODUCTION	1-1	1	Paper Runaway Option	1-11
	GENERAL DESCRIPTION	1-1	(Con't)	6/8 Line Per Inch Option	1-11
	70 Line Per Minute Printer	1-1		Audible Alarm Option	1-11
	125 Line Per Minute Printer	1-1		Tear Bar Option	1-11
	Dimensions-Nominal Outside	1-1		Led Diagnostics Option	1-11
	Weight	1-1		Test Print Switch Option	1-12
	Cabinet Design	1-1		Line Feed Switch Option	1-12
	Printer Access	1-1		Compressed Pitch Option	1-12
	Front Cover	1-1		7X9 Character Set Option	1-12
	Side Cover	1-2		9X7 Character Set Option	1-12
	Upper Cabinet Cover	1-2		9X9 Character Set Option	1-12
	Lower Cabinet Skirt	1-2		9X9 Overlapping Character	
	Power Requirements	1-3		Set Option	1-12
	Frequency	1-3		Bottom Forms Feed Option	1-12
	Voltage	1-3	2	OPERATING INSTRUCTIONS	2-1
	Current	1-3		Introduction	2-1
	Input Power	1-3		Switches/Indicators And	
	Input Power Protection	1-3		Controls	2-1
	Power Cord	1-3		On/Off Switch Indicator	2-2
	Environmental And Safety			Starts/Stop Switch Indicator	2-2
	Requirements	1-3		Form Feed Switch	2-2
	Temperature Range-Dry Bulb	1-3		Line Feed Switch-Option	2-2
	Temperature Change	1-3		Test Print Switch-Option	2-2
	Relative Humidity Range	1-3		Electronic Vertical Format	
	Humidity Change	1-3		Load Switch-Option	2-2
	Barometric Pressure	1-3		6/8 Line Per Inch Switch	
	Operating Vibration	1-3		Option	2-2
	Operating Shock	1-3		Compressed Pitch Switch	
	Acoustic Noise	1-3		Option	2-2
	Safety Requirements	1-3		Vertical Forms Positioning	
	Forms Path	1-4		Knob	2-3
	Printer Sub Systems	1-4		Forms Density Control	
	Power Distribution	1-4		Knob	2-3
	Cooling System	1-4		Horizontal Forms Positioning	2-3
	Print System	1-4		Tear Bar-Option	2-3
	Print Head	1-4		Operating Procedures	2-3
	Print Head Drive	1-5		Ribbon Cassette Replacement	2-3
	Print Head Monitoring	1-5		Forms Installation And	
	Ribbon System	1-6		Alignment For Standard	
	Paper Motion System	1-6		Rear Loading Units	2-4
	Logic Chassis And Printed			Forms Installation And	
	Circuit Cards	1-7		Alignment For Units With	
	Control Panel	1-7		The Front Loading Option	
	Interface	1-8		Installed	2-5
	Standard Features	1-9		Electronic Vertical	
	Interactive Mode Feature	1-9		Format Unit Load	
	Test Print Feature	1-9		Operation	2-5
	Elongated Character Feature	1-9		Format Unit Load	
	80 Column Feature	1-9		Operation	2-5
	Auto Terminate Feature	1-9		Format Tape Punching	
	Auto Line Feed Feature	1-9		Operation	2-6
	Auto Double Space Feature	1-9		6/8 Line Per Inch Operation	2-8
	Standard Optional Feature	1-10		6/8 L. P. I. (Without EVFU)	2-8
	Interface Adapter Option	1-10		6/8 L. P. I. (With EVFU)	2-8
	Electronic Vertical Format			Compressed Pitch Operation	2-8
	Unit Option	1-10		Tear Bar Operation	2-8

(Continued)

Contents (Continued)

<u>Section</u>	<u>Description</u>	<u>Page</u>	<u>Section</u>	<u>Description</u>	<u>Page</u>
2 (Con't)	Tear Bar Installation And Removal	2-8	4	Barometric Pressure	4-3
	Tear Bar Forms Installation	2-8		Unpackaging And Assembly Pedestal (Optional)	4-3
	Tear Bar-Forms Tearing Operation	2-9		Unpackaging And Assembly	4-3
	Tear Bar Slide Clamp Operation	2-9		Printer Unpackaging And Assembly	4-3
	Paper Basket Operation	2-10		Paper Basket (Optional) Unpackaging And Assembly	4-3
	On Line Printing Operation	2-11		Printer Installation	4-3
	Print Head Replacement	2-11		Printer Checkout	4-5
	Operator Maintenance	2-12		Disassembly And Repackaging	4-8
	Preventive Maintenance	2-12		Printer Disassembly And Repackaging	4-8
	Corrective Maintenance	2-12		Pedestal (Optional) Disassembly And Repackaging	4-8
	Forms And Operating Supplies	2-12		Paper Basket (Optional) Disassembly And Repackaging	4-8
	Safety Precautions	2-12			
	Safety Interlock Switch	2-12			
3	PRINCIPLES OF OPERATION	3-1			
	GENERAL	3-1			
	Flowchart Symbols	3-1	5	MAINTENANCE	5-1
	PRINT HEAD ELECTRONICS AND ELECTRO- MECHANICAL ASSEMBLIES	3-2		INTRODUCTION	5-1
	Power Distribution	3-2		Maintenance Aids	5-1
	Head Ready Circuits	3-6		Tools And Materials	5-1
	Print Head And Needle Drivers	3-9		Test Print	5-1
	Print Head And Paper Motion	3-12		Preventive Maintenance	5-2
	Horizontal And Vertical Servo System	3-13		Cleaning	5-2
	CONTROLLER ELECTRONICS	3-19		Lubrication	5-2
	Data Interchange Technique	3-19		Part Replacement	5-2
	Data Sequencing	3-19	6	Checks And Adjustment	5-2
	Control Codes	3-19			
	Interface Signals	3-19		FAULT ISOLATION	6-1
	Microprocessor System	3-21		INTRODUCTION	6-1
	Power On And Master Clear			Fuse Functions And Location	6-1
	Flowchart	3-26		Binary Code And LED Display Diagnostics	6-3
	Executive Flowchart	3-29		LED Binary Display Diagnostics	6-3
	Test Print Flowchart	3-31		Needle Driver Fault LED	6-3
	Form Feed Flowchart	3-33		Binary Diagnostics Without LED	6-3
	Load VFU Flowchart	3-34		Fault Isolation Flow Chart::	6-7
	Start Head Motion Flowchart	3-36			
	Print Cycle Flowchart	3-37	7	TEST AND ADJUSTMENTS	7-1
	Output Cycle Flowchart	3-38		MECHANICAL TESTS AND ADJUSTMENTS	7-1
	9TH Column Flowchart	3-43		Pulley Assembly-Right Hand Tools Required	7-1
	Paper Motion Flowchart	3-44		Tests	7-1
	EVFU Pointer Up Flowchart	3-46		Adjustments	7-1
	Paper Motion Interrupt Flowchart	3-48		Pulley Assembly-Left Hand Tools Required	7-1
	Interrupt Enable Flowchart	3-49		Tests	7-2
	Load Data Flow Chart	3-50		Adjustments	7-2
	Interrupt Service Flowchart	3-51		Head Drive Belt Tension And Alignment	7-2
4	INSTALLATION AND CHECKOUT	4-1		Tools Required	7-2
	INTRODUCTION	4-1		Tests	7-2
	Sight Planning	4-1		Adjustments	7-2
	Space Requirements	4-1		Print Head Motor And Drive Belt Tools Required	7-4
	Electrical Requirements	4-2		Tests	7-4
	Power Cord	4-2		Adjustments	7-4
	Frequency	4-2		Vertical Servo Worm Gear Alignment	7-4
	Voltage Requirements	4-2		Tools Required	7-4
	Current	4-2		Tests	7-4
	Input Power	4-2		Adjustments	7-4
	Input Power Protection	4-2			
	Cooling	4-2			
	Environmental Requirements	4-2			
	Operating Temperature And Humidity	4-2			
	Storage Temperature And Humidity	4-3			


(Continued)

<u>Section</u>	<u>Description</u>	<u>Page</u>
7	Code Disc And Optical Reader	
(Con't)	Clearance	7-4
	Clearance	7-4
	Tools Required	7-4
	Tests	7-4
	Adjustments	7-4
	Format Reader Brush Block	7-5
	Tools Required	7-5
	Tests	7-6
	Adjustments	7-6
	Format Reader And Code Disk Synchronization	7-6
	Tools Required	7-6
	Tests	7-6
	Adjustments	7-6
	Tractor Assembly	7-6
	Tools Required	7-6
	Tests	7-6
	Adjustments	7-7
	Paper Feed Assembly	7-7
	Tools Required	7-7
	Tests	7-7
	Adjustments	7-8
	Shaft Alignment Brackets	7-8
	Print Head To Platen	7-8
	Tools Required	7-8
	Tests	7-8
	Adjustments	7-8
	Lower Paper Slide To Platen	7-8
	Tools Required	7-8
	Tests	7-8
	Adjustments	7-8
	Line Finder To Platen	7-9
	Tools Required	7-9
	Tests	7-9
	Adjustments	7-9
	Print Head To Print Head	7-9
	Tools Required	7-9
	Tests	7-9
	Adjustments	7-9
	Out Of Paper Switches	7-11
	Tools Required	7-11
	Tests	7-11
	Adjustments	7-11
	Code Strip To Reader	
	Alignment	7-11
	Tools Required	7-11
	Tests	7-11
	Adjustments	7-11
	ELECTRICAL TESTS AND ADJUSTMENTS	
	Power Supply Board Assembly	7-12
	Tools Required	7-12
	Tests And Adjustments	7-12
	Needle Driver Board Assembly	7-13
	Tools Required	7-13
	Tests And Adjustments	7-13
	Horizontal Servo System (Print Head Motion)	7-14
	Tools Required	7-14
	Tests And Adjustments	7-14
	Vertical Servo System (Paper Motion)	7-15
	Tools Required	7-15
	Tests And Adjustments	7-15

<u>Section</u>	<u>Description</u>	<u>Page</u>
8	PARTS REPLACEMENT	8-1
	INTRODUCTION	8-1
	Print Head Replacement	8-1
	Tools Required	8-1
	Removal	8-1
	Installation	8-1
	Print Head Flat Cable Assembly	
	Replacement	8-2
	Tools Required	8-2
	Removal	8-2
	Installation	8-2
	Horizontal Transducer Board And Cable Assembly	
	Replacement	8-3
	Tools Required	8-3
	Removal	8-3
	Installation	8-3
	Code Strip Replacement	8-3
	Tools Required	8-3
	Removal	8-3
	Installation	8-3
	Cassette Drive Cord Assembly	
	Replacement	8-4
	Tools Required	8-4
	Removal	8-4
	Replacement	8-4
	Pulley Assembly-Left Hand (Disassembly And Assembly)	8-5
	Tools Required	8-5
	Disassembly	8-5
	Assembly	8-5
	Pulley Assembly-Right Hand (Disassembly And Assembly)	8-5
	Tools Required	8-5
	Disassembly	8-5
	Assembly	8-5
	Horizontal Servo Motor	
	Replacement	8-6
	Tools Required	8-6
	Removal	8-6
	Installation	8-6
	Vertical Servo Motor	
	Replacement	8-7
	Tools Required	8-7
	Removal	8-7
	Installation	8-8
	Tractor Assembly	
	Replacement	8-9
	Tools Required	8-9
	Removal	8-9
	Installation	8-9
	Tractor Flap Replacement	8-10
	Tools Required	8-10
	Removal	8-10
	Installation	8-10
	Tractor Timing Belt	
	Replacement	8-10
	Tools Required	8-10
	Removal	8-10
	Installation	8-10
	Clutch Assembly Replacement	8-10
	Tools Required	8-10
	Removal	8-10
	Installation	8-11

(Continued)

<u>Section</u>	<u>Description</u>	<u>Page</u>
8	Control Panel Lens And	
(Cont)	Lamp Replacement	8-12
	Tools	8-12
	Removal	8-12
	Installation	8-12
	Rear Fan Replacement	8-12
	Tools Required	8-12
	Removal	8-12
	Installation	8-12
	Front Fan Replacement	8-13
	Tools Required	8-13
	Removal	8-13
	Installation	8-13
	Platen Advance Shaft	
	Assembly Replacement	8-13
	Tools Required	8-13
	Removal	8-13
	Installation	8-14
	Platen Assembly	
	Replacement	8-14
	Tools Required	8-14
	Removal	8-14
	Installation	8-14
	Head Support Shafts And	
	Print Head Support Casting	
	Replacement	8-14
	Tools Required	8-14
	Removal	8-14
	Installation	8-16
9	DIAGRAMS	9-1
	Key To Diagrams	9-2
	Interconnection Diagrams	9-7
	Block Diagrams	9-11
	Timing Diagrams	9-14
	Logic Diagrams	9-15
	Logic Term Index	9-27
10	UNIQUE CDC PRINTER CONFIGURATIONS	10-1
	Introduction	10-1
	Special Features	10-1
	Operator Visible LED Diagnostics feature	10-1
	Printer To Data Source Fault-Detection Feature	10-1
	Printer Interfaces	10-1
	Configurations	10-4



CDC 70/125 LPM MATRIX PRINTER

INTRODUCTION

GENERAL DESCRIPTION

This manual describes the 70 and 125 line per minute versions of the Matrix Printer. The characters printed by these printers are generated using the dot matrix method of character formation. Each character consists of a pattern of dots formed in any of several optional matrix patterns. The standard printer produces characters in a 7X7 matrix pattern. Optional matrix character patterns of 7X9, 9X7, 9X9 and 9X9 overlap are also available.

The characters are printed by a bi-directional print head using 9 vertically spaced print wires which are individually controlled.

Activation of one or more of the solenoid driven print wires forces an inked ribbon against the paper and platen to form either 7 or 9 rows of horizontal dots, depending on the optional matrix pattern being used. The printing mode is bi-directional and the nominal head velocity of the standard units is 18 inches per second in both directions. Optional character patterns and compressed character pitches require that the head velocity be reduced to correlate with the operating frequency of the print head solenoids. The print head transport and paper motion systems are each driven by a separate dc servo motor. The printer has a cassette type ribbon system. These printers have an internal micro-processor common controller which interfaces to the trunk and controls the operation of the printer. The printer drive and controller electronics is of discrete component and integrated circuit design and is controlled by an 8080 micro processor common controller.

70 LINE PER MINUTE PRINTER

This printer is a single head bi-directional printer having a print rate of 70 lines per minute (50/60 Hz) while printing a full line of 132 (7X7 pattern) characters and a maximum short line print rate of 200 lines per minute (33 contiguous columns, 7X7 pattern). The standard character pitch is 10 characters per inch with an optional compressed pitch of 16.5 characters per inch (not available for 9X9 overlap pattern).

Vertical line spacing is 6 lines per inch standard, with an operator selectable option of 6/8 lines per inch. The paper slew speed is 7.5 inches per second. The printer has position seeking capability for increased throughput. The printer also has capability for optional operation in an interactive key board mode.

125 LINE PER MINUTE PRINTER

This printer is a two head bi-directional printer having a print rate of 125 lines per minute (50/60 Hz) when printing the 7X7 character pattern. The standard character pitch is 10 characters per inch and the maximum number of characters per line is 132.

Vertical line spacing is 6 lines per inch standard with an operator selectable option of 6/8 lines per inch. The paper slew speed is 7.5 inches per second.

DIMENSIONS-NOMINAL OUTSIDE

Height: 13.50 inches (344 mm)
Length: 28.75 inches (730 mm)
Depth: 17.30 inches (439 mm)

WEIGHT

The weight of the 70 line per minute printer is approximately 98 pounds (44.5 kg). The weight of the 125 line per minute printer is approximately 100 pounds (45.5 kg).

CABINET DESIGN

The standard printer is designed as a table-top unit having four rubber feet. An optional bolt on printer stand (pedestal) is also available.

The cabinet is cooled with a forced air cooling system. The air enters the printer cabinet through a rectangular opening on the left side of the base and is then fan driven and directed through the printed circuit card rack and exhausted through an opening on the right rear of the cabinet. The interface connector is located on the left rear of the cabinet and the power cord is located on the right rear of the cabinet. The cabinet is designed such that neither the interface cord or the line cord need be disconnected when removing the cover or cabinet parts for access or servicing.

PRINTER ACCESS (FIGURE 1-1)

The interior printer area can be accessed by removing the front cover, side cover, upper cabinet cover and lower cabinet skirt. The upper cabinet cover and lower cabinet skirt should only be removed by trained service personnel.

Front Cover (Figure 1-1)

Removal of the front cover permits access for chang-

ing ribbon cassettes and forms loading. To remove the front cover, grasp the two lifting tabs on either side of the cover and lift the cover up and off the upper cabinet.

When installing the front cover the beveled edge must be toward the rear of the machine facing downward. To install the cover reverse the removal procedure. Care should be taken that the four corner guides are engaged properly into the upper cabinet before seating the front cover.

Side Cover (Figure 1-1)

Removal of the side cover permits access to the format reader, format tape, 6/8 line per inch switch, compressed pitch switch and the load vertical format switch. To remove the side cover place your finger tips in the depression in the left side of the upper cabinet and under the bottom edge of the side cover and slide the side cover upward and off the upper cabinet.

To install, reverse the removal procedure.

Upper Cabinet Cover (Figure 1-1)

WARNING

THIS COVER SHOULD ONLY BE UNLOCKED OR REMOVED BY A TRAINED FIELD SERVICE REPAIRMAN DURING SERVICING AND SHOULD NEVER BE UNLOCKED OR REMOVED BY THE OPERATOR (USING CUSTOMER OR CUSTOMER OWNER). THE FIELD SERVICE REPAIRMAN SHALL ASSURE THAT THIS COVER IS REPLACED AND LOCKED IN PLACE WITH THE LOCKING SCREWS AFTER SERVICING.

Removal of the upper cabinet cover permits access to the control panel wiring, format reader, paper drive servo motor and access for removal of the print head. To remove cover, turn the two locking screws (Figure 1-1) in until they clear the plastic cover and bottom out against the right and left format plates. Remove the upper knob on the right side of cover by pulling it off its shaft and lift cabinet cover off the lower cabinet skirt.




FIGURE 1-1. PRINTER ACCESS

To install, reverse the removal procedure and back locking screws out to the lock nut stops.

Lower Cabinet Skirt (Figure 1-1)

Removal of the lower cabinet skirt permits full access to all inner printer areas and must be removed to access or probe most of the printed circuit cards.

The lower cabinet skirt may not be removed without first removing the upper cabinet cover.

The lower cabinet skirt is fastened to clinch nuts in the base plate with 4 slotted head screws. Loosening of these 4 screws permits the lower cabinet skirt to be lifted up and off the base plate.

To install reverse the removal procedure.

POWER REQUIREMENTS

The printer is capable of operating within the following limits when supplied with two wires plus earth ground.

Frequency

50 Hz or 60 Hz (Single Phase)

Frequency Ranges

50 Hz = 49.0 to 50.5 Hz
60 Hz = 59.0 to 60.6 Hz

Voltage

Voltage ranges are tap selectable by changing field accessible input power terminal block connections. No component changes are required when changing from 60 Hz to 50 Hz operation. The tap selectable ranges are as follows:

<u>Nominal (VAC)</u>	<u>Voltage Range</u>
100	90 to 107
120	104 to 127
200	180 to 213
220	198 to 235
230	207 to 246
240	216 to 257
260	234 to 278

Current

125 Line Per Minute Printers:

<u>Amps</u>	<u>Vac</u>	<u>Hz</u>
Less than 1.75	220	50
Less than 3.2	120	60

70 Line Per Minute Printers:

<u>Amp</u>	<u>Vac</u>	<u>Hz</u>
Less than 1.53	220	50
Less than 2.8	120	60

Input Power

<u>Lines Per Minute Printer</u>	<u>Volt Amps Maximum</u>
125	384
70	336

Input Power Protection

A dual purpose double pole circuit breaker and illumin-

ated on/off switch located in the front right corner of the printer cabinet provides input power protection and is rated as follows:

Full Load = 7.5 amps r. m. s.
Trip = 9.38 amps r. m. s.

Power Cord

The standard printer is wired for 120 vac and is provided with a 3 wire power cord of which approximately 7.5 ft. (2.3 meters) is external to the printer. The cord is terminated with a non-locking, 3 prong plug for use with 60 Hz outlets.

ENVIRONMENTAL AND SAFETY REQUIREMENTS

This printer is designed to meet the following operating requirements for electronic data processing equipment

Temperature Range - Dry Bulb

10°C to 40°C (50°F to 105 F)

Temperature Change

10°C (18°F) per hour max.

Relative Humidity Range

20-80%

Humidity Change

10% per hour-max.

Barometric Pressure

10.5X10⁴ N/m² to 6.9X10⁴ N/m²
(Maximum equivalent altitude 9850 feet - 3000 meters)

Operating Vibration

Continuous vibration over the following frequency ranges:

5-17 Hz = .02g or .004 inch (0.1 mm) double amplitude (whichever is smaller)
17-300 Hz = .2g or .0015 inch (0.038 mm) double amplitude (whichever is smaller)

Operating Shock

Intermittent shocks of up to 3g, not exceeding 10 milli-second duration. (The time between consecutive shocks shall be less than 5 seconds.)

Acoustic Noise

Operating: 7.8 bels, max.
Idle: 7.0 bels, max.

Safety Requirements

These printers are U/L listed and CSA certified. These printers are also designed to meet non-domestic VDE and IEC safety requirements.

FORMS PATH

The forms supply for the standard table top unit must be placed directly behind the printer and at the same level as the printer. The forms are inserted under the tension weights and into the rear paper slide. The forms are then routed between the platen and print head. Above the platen they are engaged by the forms tractors which pull the form from the stack across the print station and then push the forms to the rear of the printer where the paper is stacked.

Front forms feed is also available as a special option and is normally used with units that are pedestal mounted. On front feed units the forms supply is placed under and to the front of the printer. The forms are slid up through an opening in the base plate, up a paper chute and between the platen and print head. Above the platen the forms are engaged by the forms tractors which pull the forms past the print station and then push the forms to the rear of the printer for stacking. An optional paper basket is also available. The paper basket attaches to the rear of the printer and catches the forms as they are pushed from the forms tractors.

PRINTER SUBSYSTEMS

All the printer subsystems are contained within a noise suppressing acoustical cabinet. The subsystems contain all the electrical and mechanical components necessary for the printer to operate as a free standing unit. There are eight major subsystems. These subsystems are discussed in the following order:

1. Power Distribution
2. Cooling System
3. Print System
4. Ribbon System
5. Paper Motion System
6. Logic Chassis
7. Control Panel
8. Interface

Power Distribution

Power distribution is split into two subsystems; ac distribution and dc distribution. The ac power enters the printer through a three conductor line cord which is connected to the line filter. The ac input voltage is then filtered through this filter and enters a dual purpose double pole circuit breaker and illuminated On/Off switch. When this On/Off circuit breaker switch is depressed to the on position, input voltage is supplied to the cooling system blower fan and to the primary of the power transformer.

The input to the transformer is stepped down to four ac output voltages. The four voltage outputs are: 30 vac, 55 vac and two separate 16 vac. The four ac output voltages then enter the power supply board where they are converted into dc voltages. The dc distribution is initiated on the power supply board. The power supply develops six dc voltages; +36 vdc, -36 vdc, +5 vdc, -5 vdc, +12 vdc and -12 vdc. The +36 vdc and the -36 vdc are used to supply power to the vertical (paper motion) and horizontal (print head transport)

servo linear power amplifiers, which in turn supply power to drive the print head transport and end paper motion servo motors. The +36 vdc also provides power to the needle driver coils.

The +12 vdc and -12 vdc are used to power the servo linear control circuits.

The +5 vdc and -5 vdc are used to power the controller circuits. The +5 vdc also supplies power to the servo digital control circuits.

Cooling System

The inner cabinet is cooled with a forced air cooling system which is composed of a single ac multi type fan. The air enters the printer cabinet through a rectangular opening on the left side of the printer base plate, is then fan driven and directed through the printed circuit card rack and exhausted through an opening on the right rear of the cabinet.

An additional fan is required on units with the "Bottom Forms Feed Option" installed. This fan is located in the front left corner of the printer base plate and directs air across the Needle Driver Board Assembly.

Print System

Print Head (Figure 1-2). The print head contains the print wires and solenoids necessary to perform a print operation. The print head has nine steel print wires (sometimes referred to as print needles) that are guided through molded plastic guides. Each of these nine print wires is actuated by a solenoid driven armature. When a solenoid is actuated by the driver circuit, it propels its print wire toward the platen. The print wire impacts the ribbon, driving it against the form and platen, leaving a dot impression on the form. As the print head moves horizontally across the print station, the solenoids activate the print wires, creating a series of dot patterns within a programmed matrix. The pattern of these dots in the matrix forms the character. Two types of print heads are available, the standard nine wire head and the optional nine wire overlapping head. The standard nine wire print head has the wires arranged in a single vertical column. The optional nine wire overlapping print head is identical to the standard 9 wire head with the exception that it has its print wires arranged in two vertical columns that allow the printed dots to overlap in the vertical direction. This is accomplished by the print head having two vertical rows of wires in a staggered 5-4 pattern that are located on an integral number of half dot positions apart. The controller is then programmed to delay information to one column of wires so that they will print in the same physical location as the other column of wires, thus producing an overlapped row of nine dots. Both the nine wire and the nine wire overlapping print heads are spared as assemblies only and are not intended to be reworked or repaired when rendered inoperable due to failure or end of life. The single print head used on 70 LPM printers is operator replaceable, with the exception of some early models. The two print heads required on the 125 LPM printer are not operator replaceable, since they require some head to head adjustment when being replaced.




FIGURE 1-2. PRINT HEAD

Print Head Drive (Figure 1-3). The print head is attached to a print head support assembly that is belt driven horizontally back and forth along two print head support shafts by a dc servo motor.

Servo motor control circuits monitor and maintain the speed and control the direction of the print head by pulsing the voltage or reversing the current to the dc servo drive motor.




FIGURE 1-3. PRINT HEAD DRIVE AND MONITORING

Print Head Monitoring (Figure 1-3). The position of the print head is monitored by an optical reader mounted to the print head support assembly. As the print head moves horizontally back and forth the optical reader monitors a fixed mylar code strip. The code strip contains windows that when monitored indicate the 132 character positions as well as the left and right home position of the print head.

The 125 lpm printer with two heads uses a two channel optical reader and a code strip with two rows of horizontal windows. The first row of windows indicate the 132 character positions and the second row has two windows that indicate the left and right home positions.

The 70 lpm printer with one head uses a four channel optical reader and a code strip with 4 rows of windows. The first two rows of windows indicate the 132 character positions and the left and right home positions when printing in the standard 10 characters per inch mode. The bottom two rows of windows indicate the 132 character positions when printing in the optional (compressed pitch) 16.5 characters per inch mode. When printing in the compressed pitch mode, the long windows on all four rows are used to indicate the left and right home position of the print head.

In both the 10 and 16.5 characters per inch modes it should be noted that the odd character position windows are in one row and the even character position windows are in the adjacent row. The staggering of these windows is done to help keep track of the heads position seeking functions.

Ribbon System (Figure 1-4). The ribbon system consists of a disposable ribbon cassette that snaps over the print head and engages a cassette drive shaft on the print head support assembly. The cassette drive shaft is pulley and cord driven by two stationary cassette drive cords. Each of the drive cords drives one of the two cassette drive pulleys attached to the bottom of the print head support and pulley assembly. Each of these pulleys has a built in one-way clutch.

As the print head moves horizontally to the right, the upper drive pulley clutch engages the drive shaft and turns it counter clockwise, while the lower drive pulley clutch disengages. When the print head moves to the left the lower drive pulley clutch engages the drive shaft and turns it counter clockwise, while the upper drive pulley clutch disengages. As the cassette drive shaft turns counter clockwise the ribbon is in constant motion, from left to right across the print station.




FIGURE 1-4. RIBBON SYSTEM

Each ribbon cassette contains an endless loop of nylon ribbon that is cycled through the cassette in one direction until the end of ribbon life is reached and a new ribbon cassette is installed. The ribbon system for the 125 L.P.M. printer is the same as the 70 L.P.M. printer except that it has to drive a ribbon cassette for each of its two heads. This is accomplished by each head having a separate ribbon drive system. The upper cassette drive pulleys on each support and pulley assembly are driven by one cassette drive cord and the two lower cassette drive pulleys are driven by the other drive cord.




FIGURE 1-5. PAPER MOTION SYSTEMS

Paper Motion System (Figure 1-5).

The paper motion system can be activated by a manual control panel forms feed switch or by an electrical command from the controller.

The vertical forms advance is driven by a dc servo motor, while the distance the forms travel is controlled by a code disk and optical reader. The standard 70 and 125 L. P. M. printers are provided with 6 line per inch spacing. An optional operator selectable 6/8 line per inch option is also available.

When a paper motion pulse is received, forward drive current is applied to the servo motor. The servo motor gear drives the tractor drive shaft. The tractor drive shaft drives the tractor sprockets, which engage the forms, causing paper motion. Servo motor control circuits monitor and maintain the speed of the servo motor by controlling the amount of forward drive current applied to the motor. To stop the motor a reverse drive current is applied to the servo motor. Once the servo motor is stopped a one way bearing on the tractor drive shaft prevents reverse rotation of the drive shaft.

The distance the forms travel is measured by a code disk mounted on the servo motor drive shaft. The code disk, in conjunction with a two channel optical reader generates the pulses used to generate the stop the paper (STP) pulse. The standard code disk generates both

6 and 8 line per inch pulses which are read by the 2 channel optical reader and sent to the controller. On standard printers the controller only accepts the 6 line per inch pulses. On printers with the 6/8 line per inch option installed, the controller will only accept the pulses of the line per inch mode selected.

The standard controller will respond to the four ASCII control codes: Line Feed (LF), Form Feed (FF), Vertical Tab (VT), and Carriage Return (CR). The standard paper motion system without the EVFU (Electronic Vertical Format Unit) Option installed will not respond to two of the ASCII codes - Forms Feed (FF) and Vertical Tab (VT) and converts them into Line Feeds (LF) whenever they are detected at the interface.

EVFU (Electronic Vertical Format Unit) may be installed as an option to the standard paper motion system. The EVFU consists of a format brush reader and a load EVFU switch.

The primary function of the EVFU is to read a punched format tape and load it into a controller memory where it is combined with code disk pulses to determine the line spacing.

When the EVFU paper tape is loaded in the reader and the load switch (mounted on the Vertical Transducer Printed Circuit Card Assembly) is actuated, the tape will pass through the reader until two successive form feeds (channel 1 top of form) are sensed, then, the tape is automatically re-read to check the loaded data. The tape will stop when a successful load and check has occurred. The tape may then be removed.

The maximum length of the format tape loaded into EVFU may not exceed 176 lines. The format tape must be re-loaded whenever the 6/8 line per inch mode is changed.

The Paper Runaway Option is required in the printer whenever the EVFU option is added, and prevents a runaway condition from occurring while loading the EVFU data. No controller hardware or software changes are required to use the EVFU option.

A manual vertical forms positioning lever and knob are also provided in the paper feed assembly. The clutch retractor lever when pressed, disengages the clutch on the tractor shaft and the forms can then be moved up or down as required by turning the tractor shaft knob.

An additional real time, vertical format tape brush reader unit is also available as a special option.

Logic Chassis and Printed Circuit Cards

The logic chassis is located at the rear of the printer and houses all the printed circuit boards with the exception of the Needle Driver Board Assembly, Vertical Transducer Board Assembly, Horizontal Transducer Board Assembly and Control Panel Board Assembly. All the boards in the logic chassis are hinged at the bottom and swing down for easy access. The following is a list of the logic chassis circuit boards and their locations in the logic chassis.

- 1PC1 Power Supply Board Assembly.
- 1PC2 Controller And Head Logic Board Assembly.
- 1A03 Interface (Any one of several interface boards may be installed in card location 1A03. This manual does not describe these interface boards. For information pertaining to the interface board installed, refer to the appropriate interface manual). Interface card location 1A03 may also be subdivided into positions 1A04 and 1A05 with the installation of a 7 X 10 inch (177.8 X 254 mm) interface adapter option. Interface adapter option kits are available to accept all previously designed 7 X 10 inch Matrix Printer interface boards

The Needle Driver Board Assembly (2PC1) is located in the front of the printer, just above the base plate. The Needle Driver Board may be moved forward out of its guides for service or removal. The Vertical Transducer Board Assembly (5PC1) is located on the left side of the printer and is mounted just below the vertical dc servo motor (Figure 1-5). The Horizontal Transducer Board Assembly (2PC2) is mounted to the print head support assy and is located in the front of the printer just under the print head (Figure 1-3).

The Control Panel Board Assembly (4PC1) is located in the upper front right hand corner of the printer and is mounted to the bottom of the control panel.

Control Panel (Figure 1-6)

The control panel is located in the upper right front corner of the printer.

The standard printer control panel contains a Stop/Start Switch/Indicator and a Forms Feed Switch. Four additional switch locations are available for optional control panel configurations. Two of these optional locations are reserved for the Test Print Switch Option and the Line Feed Switch Option, while the other two switch locations are not defined and may be used for any number of special options.




FIGURE 1-6. CONTROL PANEL SWITCH LOCATING




FIGURE 1-7. INTERFACE CONNECTORS

CONNECTOR	PIN NO.	SIGNAL
1J01	1	DATA BIT 1
	2	DATA BIT 1 RETURN
	3	DATA BIT 2
	4	DATA BIT 2 RETURN
	5	DATA BIT 3
	6	DATA BIT 3 RETURN
	7	DATA BIT 4
	8	DATA BIT 4 RETURN
	9	DATA BIT 5
	15	DATA BIT 5 RETURN
	14	DATA BIT 6
	13	DATA BIT 6 RETURN
	12	DATA BIT 7
	11	DATA BIT 7 RETURN
	10	DATA BIT 8
	16	DATA BIT 8 RETURN
	17	STROBE
	18	STROBE RETURN
	19	ACK
	20	ACK RETURN
	21	READY
	22	READY RETURN
	23	BUSY
	24	BUSY RETURN
	25	MASTER CLEAR
	26	MASTER CLEAR RETURN
	27	PAPER OUT
	28	PAPER OUT RETURN
	29	GROUND

FIGURE 1-8. I/O CONNECTOR PIN ASSIGNMENT




FIGURE 1-9. DATA SOURCE TO PRINTER CONTROLLER INTERFACE

The control panel switch pattern is laid out so that the control panel switches may be soldered into pre-assigned switch pin locations on the control panel printed circuit board.

For the switch functions, see the Operating Instructions section of this manual.

Interface (Figure 1-8 and 1-9)

The basic controller operates on an interlocked hand shaking technique that is controlled by a micro-processor. The interlocked feature simply means that there are no stringent timing requirements on the data interchange signals. The interchange of data is accomplished by switching from one logic level to the other rather than with the use of pulses.

The data source transmits a character by placing the (-) Strobe line at a logical "0". When the printer controller has sampled the data byte, the (-) ACK line will be placed at a logical "0". The (-) Strobe line may be removed concurrently or after the data source senses the (-) ACK line. When the printer controller senses the Strobe line at a logical "1", the ACK line will be placed at a logical "1". The Data lines must be stable a minimum of 200 nanoseconds before and after the generation of the strobe signal.

A full line of buffer memory allows the loading of zero through 132 characters and one control code. The data load cycle may be terminated at any time by the control code, in which case the print head will move only as far as is required to print the number of characters loaded. A control code must be loaded no later than the 133rd character time; if not, a carriage return code will be automatically substituted for the 133rd character and the print cycle initiated. The 133rd character will not be printed since it exceeds the maximum line length and is not saved for the following line.

With the Compressed Pitch Option installed or the Elongated Character Feature enabled, the buffer allows 217 characters to be loaded into memory.

The codes recognized as valid control codes which will terminate the input cycle are the ASCII codes: VT, FF, LF, and CR.

The standard common controller is electronically compatible with several other predesigned adapter option kits and space has been provided in the logic chassis to accept these optional interface printed circuit boards.

The standard printers are provided with a 36 pin, AMP type, CPC series, interface connector that is chassis mounted in the left rear of the printer (Figure 1-7). The mating cable mounted 36 pin, AMP type, CPC series interface connector is not supplied with the printer (Figure 1-7).

STANDARD FEATURES

The following seven controller features are provided as standard equipment on 70 and 125 lpm printers, but may only be activated at the factory or in the field by trained field service personnel.

Interactive Mode Feature (70 L.P.M. only)

Activation of this feature allows each character to be printed as it is loaded into the controller buffer. A full line need not be loaded to initiate printing. This mode allows the printer to be used with a key board.

Test Print Feature

A controller board mounted feature that controls off-line printer operation. Activation of the feature will cause the printer to alternately print groups of characters. The character printed is determined by the character generator ROM typically "B" followed by groups of blank characters. When a full line of this pattern is completed, a single line advance occurs. This operation is continued until the feature is deactivated.

Elongated Character Feature (70 L.P.M. only)

Activation of this feature allows the interface to select elongated character (double width) printing to be selected.

The elongated character mode is set when a (037) octal code is loaded and will be reset when a (036) octal code is loaded or a controller clear is generated. This print mode can only be enabled in the on-line mode. If the interface ready signal from the printer resets while the elongated character mode is enabled, the processor must reload the (037) octal code when the next data transfer occurs in order for this mode to be maintained. (Figure 1-10).

80 Column Feature (70 L.P.M. only)

Activation of this feature causes lines to be automatically terminated at 80 columns rather than 132 columns.

Automatic Terminate Feature

Activation of this feature causes lines to be automatically terminated at 132 columns rather than 133 columns.

Automatic Line Feed Feature

With this feature activated, a line feed paper motion function will automatically occur whenever the input data line is terminated with a CR (Carriage Return) control code.

Auto Double Space Feature

Activation of this feature converts all LF (Line Feed) control codes into two line skips. With both this feature and Auto Line Feed activated, a line termination in either CR (Carriage Return) or LF (Line Feed) will result in a double space paper motion operation.




FIGURE 1-10. ELONGATED CHARACTER




FIGURE 1-11. INTERFACE ADAPTER RACK

STANDARD OPTIONAL FEATURES

The following standard optional features are available on 70 and 125 LPM printers. These standard optional features may be factory installed as part of the original equipment configuration or field installed as standard option feature kits.

Interface Adapter Option (Figure 1-11)

An optional interface adapter rack may be installed in the printer logic chassis card location 1A03. This adapter rack is built to accept two 7 X 10 inch (177.8 X 254 mm) or one 10 X 11.5 inch (254 X 292.1 mm) optional interface adapter printed circuit cards.

By removing the interface adapter back plane card, the card rack may be converted to accept the larger 10 X 11.5 interface card.

The adapter rack is hinged at the bottom and will swing down for easy access.

Electronic Vertical Format Unit Option (Figure 1-12)

The Electronic Vertical Format Unit (EVFU) may be installed as an option to the standard paper motion system. The EVFU consists of a format brush reader and a load EVFU switch.

The primary function of the EVFU is to read a punched format tape and load it into a controller memory, where it is combined with code disk pulses to determine the line spacing.

When the EVFU paper tape is loaded into the reader and the load EVFU switch (mounted on the Vertical Transducer Printed Circuit Card Assembly) is activated, the tape will pass through the reader until two successive form feeds (channel one top of forms) are sensed. The tape is then automatically re-read to check the loaded data. The tape will stop when a successful load and check has occurred. The tape may then be removed.

The maximum length of the format tape loaded into EVFU may not exceed 176 lines.

The format tape must be reloaded whenever the 6/8 LPI mode is changed.

The Paper Runaway Option is required in the printer when ever the EVFU option is added.




FIGURE 1-12. ELECTRONIC VERTICAL FORMAT UNIT

Paper Runaway Option

With the Paper Runaway Option installed, paper motion will stop whenever the forms slew for more than 16 seconds (approximately 4½ forms).

A runaway condition could occur if stop the paper pulses (STP) are not received by the controller or if EVFU load check errors occur. This option is located on the Controller And Print Head Electronics Board Assembly in card location 1PC2.

6/8 Line Per Inch Option

The 6/8 LPI option is located under the vertical format servo motor on the Vertical Transducer Board Assembly and consists of a toggle switch and chip. The standard code disk driven by the vertical format servo motor supplies both 6 and 8 LPI signals to the controller, but only accepts the 6 LPI signals. The switch provides the selection of either 6 LPI or 8 LPI mode by simply signaling the controller the line per inch mode required.

Audible Alarm Option

The Audible Alarm Option provides an audible buzzer signal to notify the operator that the printer is out of paper. The audible alarm buzzer is triggered through the controller by the out of paper switch.

The audible alarm consists of a printed circuit board mounted buzzer and associated circuitry. The audible alarm board is mounted at the rear of the printer, just above the interface connector, on the inside of the cabinet.

Tear Bar Option

The Tear Bar Option provides two new sectional tractor cover flaps and a tear bar to convert the printer paper feed tractors so that 8.5 inch (216.0 mm) wide non-perforated forms may be torn. This kit is designed to tear up to 5 part forms (with carbon paper) and may also be used to tear perforated forms on other than the perforations. The Tear Bar Option may be disabled by removing the tear bar and engaging a slide clamp on each of the tractor flap covers.

LED Diagnostics Option

The LED Diagnostics Option consists of 6 light emitting diodes mounted on the Controller Electronics Printed Circuit Card Assembly located in card location 1PC2.

With this option installed the controller electronics isolates and displays on six (6) LED lamps a binary code for a controller detectable error condition. A summary of the codes and their interpretation is given in Figure 1-13.

BINARY LED DISPLAY	STATUS/ERROR
00 0001	ROM Check Fault
00 0010	RAM Check Fault
00 0011	Start Switch Not Released
00 0100	Wait Loop for Switch Depression (stop NOT READY mode)
00 0101	Missing STP or FMT CHNL 1
00 0110	VFU Tape Load Error
00 0111	VFU Load Switch Not Released
00 1000	VFU Tape Longer Than 176 Lines
00 1001	Cannot Home Print Head
00 1010	Single Space SW Not Released
00 1011	Wait for Input Data
00 1100	Loading Data
00 1101	Interface Error
00 1110	FF Switch Not Released
00 1111	Test Print Switch Not Released
01 0000	(Position seek in process (PM70 only)
01 0001	(Not used)
01 0010	(Not used)
01 0011	(Not used)
01 0100	Missing MT3 O/S
01 0101	Missing Char Start O/S
01 0110	Char Start O/S at Constant "1"
01 0111	Char Start O/S #67 Missing (138/218 in PM70)
01 1000	Elongated char routine in process (PM70 only)
01 1001	(Not Used)
01 1010	(Not used)
01 1011	(Not used)
01 1100	STP at a Constant "1" (First Pass)
01 1101	STP at a Constant "1" (Interrupt Routine)
01 1110	Wait for STP Interrupt
01 1111	(Not Used)

1 = LAMP LIT IN THAT POSITION
0 = LAMP NOT LIT IN THAT POSITION

FIGURE 1-13. LED STATUS ERROR CHART

Test Print Switch Option (Figure 1-6)

This is an illuminated momentary contact push button switch/indicator located on the control panel and is only active when the printer is in off line Ready Not mode. Actuation of this switch will cause the printer to alternately print groups of characters (the character printed is determined by the character generator rom typically "B") followed by groups of blank characters. When a full line of this pattern is completed, a single line advance occurs. This operation will continue until the switch is actuated again removing the test print condition.

Line Feed Switch Option (Figure 1-6)

This is a non-illuminated, momentary contact, push button switch located on the control panel. Depression of this switch causes the paper motion system to advance forms one line space.

Compressed Pitch Option (70 L.P.M. only)

When the Compressed Pitch Option is installed and activated it will cause 16.5 characters per inch to be printed horizontally rather than the standard 10 characters per inch. The Compressed Pitch Option is activated by an alternate action toggle switch located under the vertical format servo motor on the Vertical Transducer Board Assembly. This option also requires component changes and additions to the Controller Electronics Board Assembly located in card location 1PC2.

The compressed pitch mode will cause printing to occur horizontally compressed, enabling the use of narrower forms.

7 X 9 Character Set Option

This option prints a matrix consisting of seven horizontal dots and nine vertical dots. This option requires two extra needle driver circuits per head since all of the nine standard print head wires are used. A unique two character generator ROM set is also required.

9 X 7 Character Set Option

This option prints a matrix consisting of nine horizontal dots and seven vertical dots and requires a unique character generator ROM.

9 X 9 Character Set Option

This option prints a matrix consisting of nine horizontal dots and nine vertical dots. This option requires nine needle driver circuits per head plus a two character generator ROM set.

9 X 9 Overlapping Character Set Option

9 X 9 overlapping refers to dots overlapping in the vertical direction. It is accomplished by a special print head having two vertical rows of needles in a staggered 5-4 pattern, located on an integral number of half dot positions apart. The controller delays information to one row of needles so that they will print in the same vertical column as the other row, thus producing an overlapped vertical row of 9 dots. This option requires nine needle driver circuits per print head, a unique two character generator ROM set, plus program ROM set changer.

Bottom Forms Feed Option

This option consists of two paper shrouds that are added from the bottom of the printer to the print station. These shrouds form a path for the forms to be fed through the bottom of the printer from a forms supply located directly below the printer. An out of paper switch is provided to indicate the absence of forms, 2.5 inches below the print station. Due to the restriction of air flow caused by these shrouds, an additional fan is required to cool the Needle Driver Board Assembly. Units with this option installed have the capability of feeding forms from either the rear or the bottom of the printer.

OPERATING INSTRUCTIONS

INTRODUCTION

This section is designed to provide an operator with all the information necessary for a person to successfully operate and maintain the printer. This section is divided into four parts, Switches/Indicators And Controls, Operating Procedures, Operator Maintenance and Safety Precautions.

SWITCHES/INDICATORS AND CONTROLS

To operate the printer properly, it is necessary for the operator to fully understand the functions of the switches, indicators and various operator adjustments provided in the printer.

The standard switches and indicators provided in the printer are the On/Off Switch, the Start/Stop Switch and the Form Feed Switch. Optional switches and indicators that may also be provided with the printer are the Single Space Switch, Test Print Switch, the Electronic Vertical Format Unit Load Switch, the 6/8 Line Per Inch Option Switch, and the Compressed Pitch Option Switch.

The operator controls and adjustments provided include the Vertical Forms Positioning Knob, the Forms Density Control Knob, the Horizontal Forms Positioning, and the Tear Bar Option Controls.




FIGURE 2-1. PRINTER CONTROLS AND INDICATORS

On/Off Switch Indicator (Figure 2-1)

Located in the lower front right corner of the printer, this switch is used to power the printer on or off. The switch is illuminated at all times when in the on position. When the printer is initially turned on, the switch generates a .1 to .2 second Master Clear pulse. This pulse clears all logic circuitry in preparation for operation. When the switch is toggled to the off position, the printer is turned off.

Start/Stop Switch Indicator (Figure 2-1)

Located on the control panel in the top right front corner of the printer, this switch is used to place the printer on or off line to the data source. The Start/Stop switch is illuminated whenever the printer is in an on-line (start) condition. It remains illuminated until the switch is actuated a second time and the printer goes to an off line (stop) condition. If the printer is printing or moving forms, the transition from on-line (start) to off line (stop) is delayed until the operation is complete. Once completed, the printer remains off-line until the Start/Stop switch is again actuated. A controller master clear pulse of 1 msec duration is generated to initialize the controller logic, when going from a stop mode to a start mode. If the switch is depressed while in the stop mode and not in test print, a start condition will be generated.

Form Feed Switch (Figure 2-1)

Located on the control panel in the top right front corner of the printer, this non-illuminated, momentary action, push button switch causes the forms to be advanced either a single space or to the top of form, depending on whether or not the Electronic Vertical Format Unit Option is installed.

Depression of the Form Feed Switch on standard printers (printers without the Electronic Vertical Format Option) causes the paper motion system to advance forms one line space and all form feed commands to be executed as single spaces.

Depression of the Form Feed Switch on printers with the Electronic Vertical Format Option installed causes the paper motion system to advance forms until the top of forms channel is detected in the electronic format tape memory.

This switch is only operable when the printer is in the off line (stop) condition.

Single Space Switch Option (Figure 2-1)

This non-illuminated, momentary action, push button switch is located on the control panel at the top right, front, corner of the printer. Depression of this switch causes the paper motion system to advance forms one line space. This switch is only operable when the printer is in the off line (stop) condition.

Test Print Switch Option (Figure 2-1)

This is an illuminated momentary action push button switch located on the control panel at the top, right, front, corner of the printer. Depression of this switch will cause the printer to alternately print groups of characters (the character printed is determined by

the character generator ROM typically "B") followed by the groups of blank characters. When a full line pattern is completed, a single line advance occurs. This operation will continue until the switch is again activated, removing the test print condition. This switch is only operable when the printer is in the off-line (stop) condition.

Electronic Vertical Format Load Switch Option (Figure 2-2)

The load EVFU (Electronic Vertical Format Unit) switch is located on the left side of the printer and may be accessed by removing the side cover or the upper cabinet cover (Figure 2-1).

The switch is mounted on the Vertical Transducer Printed Circuit Board Assembly located under the vertical format servo drive motor. This switch activates the vertical format tape reader to read the form at tape and loads it into the format tape memory. For additional information on EVFU, see the operating procedures section of this manual.

6/8 Line Per Inch Switch Option (Figure 2-2)

The 6/8 line per inch switch is located on the left side of the printer and may be accessed by removing the side cover or the upper cabinet cover (Figure 2-1). This switch is mounted on the Vertical Transducer Printed Circuit Board Assembly located under the vertical format servo motor. This switch provides the selection of either 6 l.p.i. or 8 l.p.i. mode by simply signaling the controller the line per inch mode required.

When operating with the EVFU option, the EVFU will require a reload following a 6/8 l.p.i. mode change.




FIGURE 2-2. OPTION SWITCHES

Compressed Pitch Switch Option (Figure 2-2)

The compressed pitch switch is located on the left side of the printer and may be accessed by removing the side cover or the upper cabinet cover (Figure 2-1). This switch is mounted on the Vertical Transducer Printed Circuit Board Assembly located under the vertical format servo motor. This switch provides the selection of either 16.5 character per inch or the standard 10 characters per inch to be printed horizontally.

The 16.5 characters per inch compressed pitch mode will cause the printing to occur horizontally compressed, enabling the use of narrower forms.

Vertical Forms Positioning Knob (Figure 2-1)

The vertical forms positioning knob is located on the right side of the printer on the end of the lower tractor drive shaft. The knob is used to manually move the forms when vertical positioning and alignment are required. The vertical forms positioning knob is used in conjunction with the clutch retractor lever. When depressed the clutch retractor lever decouples the tractor shaft from the paper motion drive mechanism. This allows the forms to be moved independently of the drive mechanism, facilitating manual vertical forms alignment.

Forms Density Control Knob (Figure 2-1)

The forms density control knob is located on the right side of the printer on the end of the platen advance shaft. The forms density control is used to compensate for the difference in thickness of forms used in printing. As the control knob is turned clockwise the gap between the print mechanism and the print surface of the platen is increased, allowing accommodation of heavy weight and multiple part forms. The opposite is true of turning the knob counter clockwise. There are numerous detented positions the knob may be placed in. The detent positions do not correspond to the number of copies being handled, but are intended for operator reference when forms are changed frequently. The forms density control should always be set to provide the optimum print quality for the form in use. Care should be taken to assure that the forms density control knob is not turned counter clockwise to the point where the ribbon and forms are clamped between the platen and the face of the print head. Clamping of the form and ribbon can cause form tearing or ribbon damage.

WARNING

OPERATOR MUST SET DENSITY CONTROL KNOB FOR OPTIMUM PRINT QUALITY FOR FORM IN USE. IMPROPER SETTING OF DENSITY CONTROL KNOB CAN CAUSE PREMATURE PRINT HEAD FAILURE.

Horizontal Forms Positioning (Figure 2-1)

Horizontal forms positioning is accomplished by releasing the clamp lever on the tractor assembly and applying pressure to the side of the tractor to be moved. The tractors can be moved horizontally to compensate for different forms widths and desired marginal set-ups. The tractors are designed to accommodate forms widths of 4 inches up to 16.75 inches (101.6 mm up to 419 mm)

Tear Bar Controls (Option)

See the Operating procedures section of this manual for the tear bar option operator controls and instructions.

OPERATING PROCEDURES

This section covers the normal daily operations the operator would be expected to perform in the course of operating the printer. These operations include Ribbon Cassette Replacement, Forms Installation And Stacking, Electronic Vertical Format Unit Operation,




FIGURE 2-3. RIBBON CASSETTE REPLACEMENT

Format Tap Preparation, 6/8 Line Per Inch Operation, Compressed Pitch Operation, Tear Bar Operation, Paper Basket Operation, On Line Printing Operation and Print Head Replacement (Units With Operator Replaceable Heads).

Ribbon Cassette Replacement (Figure 2-3)

The ribbon used in this printer consists of a disposable ribbon cassette that snaps over the print head and engages a cassette drive shaft on the print head support assembly. Each ribbon cassette contains an endless loop of nylon ribbon that is cycled through the cassette in one direction until the end of life is reached.

The following steps should be followed when replacing cassettes:

1. Remove the front cover to gain access to the ribbon cassette.
2. Place your finger tips under the cassette locking tab and pull it upward until you hear a slight click, indicating that the cassette has disengaged from the head support and pulley assembly.
3. Remove the ribbon cassette by lifting it up and off of the print head.
4. Remove the new ribbon cassette from its wrappings and assure that the cassette locking tab is in the up (disengaged) position.

5. Place the new ribbon cassette over the print head so that the drive spline on the bottom of the cassette engages the cassette drive shaft on the head support. The ribbon advance knob on the top of the cassette may be turned counter clockwise very slightly to aid in the engagement of the spline and drive shaft.
6. While applying a slight pressure to the top of the cassette with one hand, press the cassette locking tab downward until you hear a slight click. The cassette should now be locked to the head support and pulley assembly.
7. Using the thumb and forefinger of one hand, grasp the cassette by both sides and lift upward using a moderate pressure. If the cassette lifts off the print head, it was not seated properly and steps 4 thru 7 should be repeated. Slide the Print Head Support Casting from side to side to assure that ribbon is moving.
8. Replace the front cover and assure that it is seated properly.

NOTE

A SAFETY INTERLOCK SWITCH DIS-
ABLES MECHANICAL MOTION WHEN
THE FRONT COVER IS REMOVED OR
NOT SEATED PROPERLY.

Forms Installation and Alignment For Standard Rear Loading Units (Figure 2-5).

1. Turn the printer off or place it in the stop mode. Remove the front access cover.
2. Place the stack of fan fold forms behind the printer, directly below the forms input slot.
3. Insert the top form into the rear forms input slot and under the paper tension weights. The four paper tension weights may be raised and locked in an up position during form loading. Continue feeding the forms between the upper and lower paper slides until the form is visible at the platen in the front of the printer. When loading multiple part forms it may be necessary to increase the gap between the print head face and the platen so the form may pass with ease. This is accomplished by turning the density control knob all the way clockwise.
4. Grasp the form and pull it upward until the top of the form is in line with the top of the tractor flaps.
5. Open the left tractor flap and position the forms on the tractor feed pins. Close the flap.
6. Replace the front access cover and use its column guide for forms position reference.
7. Release the left tractor clamp lever and position the left tractor for the desired margin on the form. Reclamp the tractor in place with the tractor clamp lever.
8. Open the right tractor flap and release its tractor clamp lever. Position the right tractor so that the tractor feed pins can be seen through the form feed holes.
9. Position the form on the tractor feed pins. Close the left tractor flap.
10. Slide the right tractor to the right very lightly until the form is taut. Reclamp the right tractor in place with the tractor clamp lever.
11. Using the vertical forms positioning knob, position the top edge of the first form at the top edge of the tractor flaps. If the top edge of the form does not line up with the top of both tractor flaps, the form is mis-aligned on the feed pins.
12. If your printer does not have the Electronic Vertical Format Option, skip to step 13. Turn the printer on and actuate the form feed switch. The format reader memory is now at the top of forms position.
13. Depress the clutch retractor lever and use the forms positioning knob to align the first line of print position on the forms to the print position on the line finder (Figure 2-4). Release the clutch retractor lever.
14. Reset the density control knob if it was moved during form loading. Care should be taken to assure that the forms density control knob is not turned counter clockwise to the point where the ribbon and forms are clamped between the platen and the face of the print head. Clamping of the forms and ribbon can cause form tearing or ribbon damage. Also lower the necessary paper tension weights. The forms should now be ready for printing. For single part forms use only the two center weights. Swing the outer two weights up away from the forms. For multiple part forms all four weights are normally used. For narrow forms any weight not covering the form with at least half of its width should be lifted. If forms tear at the sprocket holes. Weights should be lifted until the tearing is eliminated. If tearing continues, the density control knob may need adjusting.




FIGURE 2-4. LINE FINDER AND COLUMN PRINTER




FIGURE 2-5. FORMS PATH FOR REAR AND BOTTOM LOADING UNITS

Forms Installation and Alignment For Units With The Bottom Forms Feed Option Installed (Figure 2-5).

1. Turn the printer off or place it in the stop mode. Remove the front access cover.
2. Place the stack of fan fold forms under the printer and directly below the front forms input slot.
3. Insert the top form into the front forms input slot. Continue feeding the forms up between the front and rear paper shrouds until the form is visible at the platen in the front of the printer. When loading multiple part forms it may be necessary to increase the gap between the print head face and the platen so the form may pass with ease. This is accomplished by turning the density control knob all the way clockwise.
4. Continue with steps 4 thru. 13 of "Forms Installation and Alignment For Standard Rear Loading Units."

5. Reset the density control knob if it was moved during form loading. Care should be taken to assure that the forms density control knob is not turned counter clockwise to the point where the ribbon and forms are clamped between the platen and the face of the print head. Clamping of the form and ribbon can cause form tearing or ribbon damage. The forms should now be ready for printing.

Electronic Vertical Format Unit Load Operation (Figure 2-6)

1. Power the printer on. Remove the side cover to gain access to the electronic vertical format unit and its load switch.
2. Lift the brush block away from the format tape drive sprocket by pulling the brush block retraction lever toward the front of the printer.




FIGURE 2-6. FORMAT TAPE LOAD OPERATION

3. Mount the format tape over the teeth on the format drive sprocket. Lower the brush block to hold the format tape in place. This is accomplished by pushing the brush block retraction lever toward the rear of the printer.

Channel one on the format tape should be on the inside.

4. If your printer has the 6/8 Line Per Inch or the Compressed Pitch Options installed check to see that their switches are switched to modes required and that the proper line per inch tape is being loaded. The selector switches for 6/8 lpi and compressed pitch are located on the Vertical Transducer Board Assembly.
5. Load the format tape into the format tape memory by activating the load EVFU switch which is located on the Vertical Transducer Board Assembly. This is a momentary action switch and will return to its original position after being actuated.

Activation of the switch will cause the tape to pass through the reader until two successive form feeds (Channel 1 - top of forms) are sensed, then the tape is automatically re-read to check the loaded data. The tape will stop when a successful load and check has occurred. The tape should then be removed and the brush block assembly raised so that the brushes are not contacting the sprocket wheel. The maximum format tape length that may be loaded is 176 lines.

The tape must be reloaded whenever the 6/8 l.p.i. mode is changed or the printer is turned off.

A minimum of 2 full pages of forms will be moved through the tractors during format tape loading. This paper loss can be prevented by depressing the tractor clutch retractor lever during the loading operation.

6. The format tape load operation is now completed.

Format Tape Preparation (Figures 2-7 and 2-8)

The format tape is a standard 1 inch (2.54 mm) wide tape with sprocket holes on .10 inches (2.54 mm) centers.

The standard format tape (95414500) comes with channel three already punched. Channel one should be punched to correspond to the top of forms positions.

Channel two may be punched at any vertical tab desired. The format tape may be any length from 5.5 to 12.5 inches (139.7 to 317.5 mm). Any punching of the format tape should only involve channels one and two of the tape. The standard tape already has channel three punched. When punching the format tape use tape punch 76657900 (Figure 2-8.)

The following procedures are intended to aid the operator in punching the format tape.

1. Raise the splicer arm out of the way during the punching operation.
2. Raise the tension arms and slide the punch channel selector to the rear and out of the way.
3. Place the format tape on the sprocket pins (Channel one inside) so that the desired top of forms (FF) is in line with the punch groove. Lower the two tension arms.
4. Move the punch channel selector to position one and depress the punch.
5. If vertical tab (VT) is desired at this location, move the punch channel selector to position two and depress the punch.
6. Count the number of holes in channel three (lines on the form) until the next desired top of forms (FF) or vertical tab (VT) location is reached.
7. Lift the tension arms and position the next line to be punched in line with the punch groove. Place the format tape over the sprocket pins and lower the tension arms.
8. Repeat step 4 and/or 5.
9. The pattern for each form may be repeated as many times as desired up to 12.5 inches (317.5 mm) of format tape.
10. When the desired length of tape is reached, align the end line with the groove under the tape splicer.
11. Lower the splicer arm and draw the cutting blade across the format tape.
12. To splice the tape raise the splicer arm and place the two ends of the format tape over the splicer sprocket pins so that they abut at the groove beneath the splicer.
13. Remove the adhesive backing from a format tape splice (76628200) and position the splice on the sprocket pins so that it equally covers both ends of the format tape.
14. Lower the splicer arm and depress the splicer handle.
15. Now reverse the format tape and apply another splice on the opposite side, so that the splice is displaced at least one or two sprocket holes from the first splice on the opposite side. This offset minimizes an abrupt change in tape thickness due to the splices. Repeat step 14.
16. Reverse the tape. The tape is now ready to be installed.




FIGURE 2-7. FORMAT TAPE CONFIGURATION




FIGURE 2-8. FORMAT TAPE PUNCH

6/8 Line Per Inch Operation (Figure 2-6)

The 6/8 LPI switch is mounted on the Vertical Transducer Printed Circuit Board Assembly which is located under the vertical format servo motor. This switch may be accessed by removing the side cover. The 6/8 LPI switch provides the selection of either 6 LPI or 8 LPI by simply signaling the controller the line per inch mode required.

When operating with the EVFU option, the EVFU will require a reload of a different format tape following each 6/8 LPI mode change.

6/8 LPI Operation For Standard Printers Without The Electronic Vertical Format Unit Option Installed (Figure 2-6).

1. Place the printer in the stop (not ready) mode.
2. Place the 6/8 l.p.i. switch in the mode required.
3. Depress the form feed switch on the control panel twice. The forms will advance two single spaces (form feed commands on non EVFU units are executed as single spaces). This will properly index the code disk to the line per inch mode selected.

6/8 LPI Operation For Printers With The Electronic Vertical Format Unit Option Installed (Figure 2-6)

1. Place the printer in the stop (not ready) mode.
2. Place the 6/8 LPI switch in the mode required.
3. Remove the format tape and replace it with the new line per inch mode format tape.
4. Load the new format tape into the format tape memory per the EVFU Load Operation found in the operating procedures section of this manual.

Compressed Pitch Operation (Figure 2-6)

The compressed pitch switch is mounted on the Vertical Transducer Printed Circuit Board Assembly which is located under the vertical format servo motor. This switch may be accessed by removing the side cover. This switch provides the selection of either 16.5 characters per inch or the standard 10 characters per inch to be printed horizontally. The compressed pitch option is only available on 70 lpm printers.

1. Place the printer in the stop (not ready) mode.
2. Place the compressed pitch switch in either the 10 or 16.5 character per inch mode.
3. The printer is now ready to print in the mode selected.

Tear Bar Operation (Figure 2-9).

The tear bar option consists of two special two piece tractor flaps and a tear bar that convert the feed tractors so that 8.5 inch (216.00 mm) wide non perforated forms may be torn. The tear bar will tear up to 5 part forms (with carbon paper) and may also be used to tear perforated forms on other than the perforations.

Tear Bar Installation And Removal (Figure 2-9)

When using the tear bar, the slide clamp on the top right and top left tractor cover flap assemblies must be disengaged from the lower right and left tractor cover flap assemblies. This is accomplished by sliding the slide clamp to its upmost position (Figure 2-9).

When installing or removing the tear bar the top right and top left tractor cover flap assemblies must be in their open position (Figure 2-9). The tear bar is mounted between the lower left and lower right tractor cover flap assemblies and is held in place with two thumb screws. With the tear bar screwed in place, the tractors are tied together and will accept 8.5 inch (216.0 mm) wide forms (Figure 2-9).

Tear Bar Forms Installation (Figure 2-9)

The form installation procedure for printers with the tear bar option is identical to printers without it, with exception of tractor form loading which is described below.

1. Turn the printer off and remove the front cover. Open the right and left hand top tractor cover flap assemblies. Loosen the two thumb screws that retain the tear bar and remove the tear bar. Open the lower right and left hand tractor cover flap assemblies (Figure 2-9).
2. Insert the form into the printer following the form path shown in Figure 2-5 and until the form is visible just below the tractors.
3. Pull the form upward and position the holes in the forms on the left feed pins. Close the lower left tractor cover flap assembly.
4. Replace the front cover. Using the column guide mounted on the front cover for reference, position the left tractor for the desired margin on the form and lock the left tractor in place.
5. Slide the right tractor assembly under the right side of the forms until the holes in the forms are positioned on the right tractor feed pins. Close the lower right tractor cover flap assembly.
6. Install the tear bar and tighten the two thumb screws. Close the top left and right tractor cover flap assemblies and lock the right hand tractor in place.




FIGURE 2-9. TEAR BAR OPERATION

7. Turn the printer on. If the printer has the Electronic Vertical Format Unit Option installed, actuate the form feed switch. The format reader memory is now at the top of forms position.

It is not necessary to actuate the form feed switch on printers without the Electronic Vertical Format Unit Option, since form feed on these printers will only give you a single space and is not a true top of form switch.

8. Depress the clutch retractor lever and use the forms positioning knob to align the first line of print position on the forms to the print position.
9. Release the clutch retractor lever. The forms are now ready for printing.

Tear Bar-Forms Tearing Operation (Figure 2-9).

The top right and top left tractor cover flap assem-

blies must both be in the open position (as shown in Figure 2-9) before forms may be torn off against the tear bar. When tearing forms, grasp the forms in the upper left hand corner, pulling the form forward against the tear bar and to the right as shown in Figure 2-9. After tearing forms and before resuming printing, both the top right and top left tractor cover flap assemblies must be in the closed position.

Tear Bar-Slide Clamp Operation (Figure 2-10)

If it is necessary to use other than 8.5 inch wide forms, the tear bar may be removed and the tractors restored to full use by tying the top and lower cover flaps assemblies together using the slide clamps on each top tractor cover flap assembly. This is accomplished by sliding the slide clamps downward and engaging them into the lower tractor cover assemblies (Figure 2-10).




FIGURE 2-10. TEAR BAR SLIDE CLAMP

Tractor Clamp Operation (Figure 2-11)

The correct release position of the tractor clamp is to place the clamp in an upward direction. The tractor will then move freely along the tractor shaft (Figure 2-11). The correct clamped position of the tractor clamp is to place the clamp toward the rear of the printer at approximately 30 degrees from the upward (released) position. The tractor will then be clamped to the tractor shafts (Figure 2-11). Failure to use the tractor clamps in the correct manner may result in breakage of the clamp.




FIGURE 2-11. TRACTOR CLAMP OPERATION

Paper Basket Operation (Figure 2-12)

The paper basket consists of two pieces, a paper basket mounting rack and a paper basket. The paper basket mounting rack is mounted to the rear of the printer by hooking it over the paper tensioner shaft.

The paper basket mounts to the paper basket mounting rack. The paper basket may be mounted in the rack in either of two positions. The lower basket mounting position is used when the printer is pedestal mounted and the forms supply is located on the floor or under the printer. The upper basket mounting position is used when the printer is table mounted and the forms supply is located on the table behind the printer.

Both pieces of the paper basket must be removed before removing the upper cabinet cover.




FIGURE 2-12. PAPER BASKET OPERATION (Basket shown in lower mounting position)

On Line Printing Operation

1. Check to see that the printer has a ribbon cassette and that the forms are loaded and aligned properly. Install the paper basket.
2. Turn the on/off switch to the on position.
3. If the printer has 6/8 Lines Per Inch or Compressed Pitch Options installed, set the 6/8 l. p. i. switch and/or the compressed pitch switch to the modes required.
4. If the printer has an Electronic Vertical Format Unit, check to see that you have the proper format tape before loading it into the format tape memory. Load the format tape into memory.
5. Depress the start/stop switch on the control panel to the start position. The printer is now on line with the data source and will start printing on command.

The printer will continue printing on command until the stop switch on the control panel is depressed. The stop switch disconnects the printer from the data source.

Print Head Replacement (On Printers With Operator Replaceable Head Only)

On some models the matrix printhead is a snap-in device easily replaceable upon wear-out or failure by the customer operator. Your service organization can determine whether your monthly maintenance cost includes printhead replacement.

This procedure describes the removal and replacement of the operator replaceable printhead used on 70 LPM Matrix Printers only. Replacement of the print head on 125 LPM printers and some early 70 LPM printers, that have the head mounted with two screws, must be replaced by a trained field serviceman.

The following steps should be followed when replacing the printhead.

1. Disconnect the printer line cord from its power source.
2. Remove the front cover to gain access to the printhead.
3. Remove the ribbon cassette (see Cassette Replacement Procedure in this section of the manual).
4. Reach under the printhead support casting with your fingers and unplug the printhead harness connector from the printhead flat cable connector (Figure 2-12).
5. Unclamp the printhead from the support casting by gasping the right and left hand clamping levers (one with either hand) and pulling the levers toward the sides of the printer until they are disengaged from the printhead (Figure 2-13).
6. Remove the printhead harness from the retaining hook located under the printhead support casting as shown in Figure 2-13.
7. Slide the printhead toward the front of the printer removing it from the print head support casting and out of the printer.




FIGURE 2-13. PRINTHEAD REPLACEMENT

8. Mount the new printhead to the printhead support casting. Note that the hole on either side of the printhead should be slid over the guide pins on either side of the mounting surface on the printhead support casting. Slide the printhead toward the rear of the printer and until it is seated against the mounting surface on the support casting (Figure 2-12).
9. While holding the printhead against the mounting surface of the support casting with one hand clamp it in place with the two clamping levers as shown in Figure 2-12. Caution should be taken to assure that the notches on the clamp levers are placed on the corner of the printhead as shown in Figure 2-12 before clamping the printhead in place.
10. Route the printhead harness and connector as shown in Figure 2-12 and plug the printhead harness connector into the printhead flat cable connector. Note that the printhead harness connector guides should be on top when making the connection (Figure 2-12). Also assure that the printhead harness has been placed behind the retaining hook as shown in Figure 2-12.
11. Grasp the printhead support casting and move it from one side of the printer to the other assuring that the printhead harness does not rub on the front support shaft or hit on the side of the printhead structure. Adjust the harness in the retaining hook as necessary.
12. Replace the ribbon cassette (see cassette replacement procedure in this section of the manual).
13. Replace the front cover and assure that it is seated properly. When installing the front cover the beveled edge must be toward the rear of the machine facing downward. Care should also be taken that the four corner guides are engaged properly into the upper cabinet before seating the cover.
12. Connect the printer line cord to its power source.
13. Load paper and start printing. Adjust the density control knob as required.

OPERATOR MAINTENANCE

This section contains preventive and corrective maintenance procedures that will aid the operator in finding and correcting minor nonfunctional printer problems. This section also contains a list of suggested operator supplies. Turn the printer off before attempting any of the following maintenance procedures.

Preventive Maintenance

Check and replace, if required:

1. Ribbon. To replace, refer to ribbon cassette replacement section of this manual.

2. Format tape. To replace, refer to the Format Tape Preparation section of this manual.
3. Printhead (on single printhead, 70 LPM printers, with operator replaceable head only). All other units require that the head be replaced by a trained field serviceman. To replace operator replaceable in the operating procedures section of this manual.

Clean when required:

1. Clean the exterior of the printer cabinet with a clean lint free cloth and a mild commercial cleaning solvent or detergent. The clear plastic front cover should only be cleaned with water and a soft non-abrasive cloth.
2. A vacuum cleaner with a soft nozzle or a lint free cloth may be used to clean the paper and ribbon dust from the print station.
3. Care should be taken not to knock or twist the code strip out of adjustment during cleaning or maintenance operations.
4. Before leaving the printer site, field service personnel should check the alignment of the code strip marks in code strip windows and test print. See the tests and adjustments section of the printer manual for code strip to reader adjustment procedure.

Corrective Maintenance

This section is divided into three areas of corrective maintenance: Inoperative Problems, Forms Problems and Print Problems.

INOPERATIVE PROBLEMS
<ol style="list-style-type: none"> 1. The power on switch is in the on position, but the switch is not illuminated. <ol style="list-style-type: none"> A. Check to see if printer is plugged into the power source. B. Have the building circuit breakers or fuses checked. 2. The printer is powered on and the start switch is depressed, but the start switch does not light up. <ol style="list-style-type: none"> A. Is the front access cover installed and seated properly. The printer will not start if the interlock switch under the front cover is not being held down by the front cover. B. No forms present. 3. The start switch is illuminated but the printer is not printing. <ol style="list-style-type: none"> A. The data source is not ready to send data. B. The data source has received an out of paper signal from the printer and has stopped sending data. Load forms.

FORMS PROBLEMS
1. Forms are jamming.
A. Forms supply is not aligned with the entry to the printer.
B. Tractors are not spaced properly (holding the forms to tight or not tight enough).
C. The sprocket hole and sprocket on the left tractor is not in line with the sprocket hole and sprocket on the right tractor.
2. Forms are tearing at the sprocket holes.
A. Form supply is not aligned with the entry to the printer.
B. The forms density control is not set properly.
C. Too many of the paper tension weights are in the down position.
3. Forms are not spacing properly.
A. Wrong format tape is being used.
B. Improperly punched format tape.
C. Worn format tape.
D. Format tape has not been loaded into EVFU memory.
E. 6/8 line per inch switch is in the wrong mode.

PRINT PROBLEMS
1. Light print
A. The forms density control is not properly adjusted.
B. The ribbon is worn out and the ribbon cassette needs replacing.
2. Missing dots or light dots
A. The forms density control is not properly adjusted.
B. Printhead is worn out and needs replacing.

TABLE 2-1. FORMS RECOMMENDATIONS

PARTS	WHITE SULPHITE BOND PAPER	CARBON PAPER
1	15 pound continuous bond (56 g/m ²)	
1	24 pound continuous bond (90 g/m ²)	
2 & 3	12 pound continuous bond (45 g/m ²)	8 pound (14 g/m ²)
2 & 3	15 pound continuous bond (56 g/m ²)	8 pound (19 g/m ²)
4 & 5	12 pound continuous bond (45 g/m ²)	6 pound (14 g/m ²)

TABLE 2-2. OPERATOR SUPPLIES

PART NUMBER	DESCRIPTION
76657900	FORMAT TAPE PUNCH
95414500	FORMAT TAPE
76628200	FORMAT TAPE SPLICE
44671690	RIBBON CASSETTE
	COMMERCIAL CLEANING SOLVENT (i. e. Brief, Formula 409, etc.)
	NON-ABRASIVE CLOTH

Forms And Operating Supplies

The printer will handle standard continuous forms with feed holes on each edge, with or without marginal perforations.

The form may be from 4 to 16.1 inches (101.6 to 425 mm) in width including margins, and 3.5 to 17 inches (88.9 to 431.8 mm) long from fold to fold. When using the output paper basket, the forms length is limited to 12 inches (304.8 mm) from fold to fold. The forms must have sprocket holes punched along both margins .25 ± .03 inches (6.35 ± 0.76 mm) from the paper edge to the hole centerlines. The distance between hole centerlines must be .500 ± .005 inches (12.7 ± 0.13 mm) non-accumulative, and the diameter of the holes should be .156 ± .010 inches (3.96 ± 0.25 mm). The distance across the sheet be-

tween sprocket hole centerlines must be uniform within .015 inches (0.38 mm). Multiple part forms shall be suitably locked with a non-metallic locking device. Locking the right edge only is not recommended.

SAFETY PRECAUTIONS

The upper cabinet cover should never be removed by the operator without first unplugging the printer line cord from its power source.

Safety Interlocks Switch

The printer is provided with a safety interlock switch which is located under the right front corner of the front cover. Removal of either the front cover or the upper cabinet cover while printing will cause the switch to open and the print head to stop.

PRINCIPLES OF OPERATION

GENERAL

This section explains the principles of operation for the Matrix Printer and should be used in conjunction with the Logic Diagrams section of this manual. The explanations are divided into two major sections: Print Head Electronics and Electro Mechanical Assemblies; and Controller Electronics. The first section is explained through the use of functional drawings, timing diagrams and detailed written explanations. The explanations are arranged by assembly functions to facilitate location and use of the information. The second section, Controller Electronics, also uses functional drawings, timing diagrams and detailed written explanations. In addition, flowcharts are employed to aid in establishing the sequence of logic events. These explanations are arranged in the sequence in which they would occur during normal printer operation.

FLOWCHART SYMBOLS

Eight symbols are used in the flowcharts which appear in this manual. The symbols are illustrated in Figure 3-1 and are explained in the following text.

Normal Event Symbol. The normal event symbol is used to indicate an event which occurs at a definite time within the flow.

Special Event Symbol. This symbol is used to indicate that the event is of special significance to the user of the flowchart. It may indicate that the event occurs in a machine other than the one in which most of the events occur or as a result of a series of events which are charted or described elsewhere in the document. This symbol may also be used to designate an event which may happen at any time during a series of other events. Used in this manner the symbol usually indicates such unpredictable events as a parity error or an out of paper condition.

Check-For-Condition (Decision) Symbol. This symbol indicates a decision which occurs at a definite point in the flow and always determines the direction the flow takes subsequently.

Entry Symbol. The entry symbol is used at the beginning of a flowchart and at any point where information from another flowchart enters the subject flowchart.

Termination Symbol. The termination symbol is used at the end of a flowchart. Depending on how the sequence of operations being charted occur, a flowchart may have one or several termination symbols.

Intraflow Exit and Entry Continuity Symbols. These symbols are used to show flow continuity within a particular flowchart. They may be used to represent an exit from one point of the flow and an entry into another point of the same flow or to show continuity where the flow extends for more than one page.

Interflow Continuity Symbol. This symbol indicates that the sequence of operations described in one flowchart leads directly to a sequence described in another flowchart. When this symbol is used a letter will appear inside of the symbol and the same letter will appear inside the entry symbol on the subsequent flowchart.

Logic Sheet Reference Numbers. These numbers are provided on most flowcharts after the written statement of the event which has occurred. The numbers are provided to aid the user of the flowchart to locate the point in the detailed logic (in the Field Service Manual) where the event occurs. These numbers will appear in parentheses and have two parts. The first part indicates the exact logic sheet number and the second part indicates the logic element and pin number. For example the reference number (00301/A1-5) indicates that the event occurs on sheet 00301 in the logic. It further indicates that the event occurs or can be checked at pin 5 of logic element A1 on that sheet.




FIGURE 3-1. FLOWCHART SYMBOLS

POWER DISTRIBUTION

General Description (Figure 3-2)

Power distribution is split into two subsystems; ac distribution and dc distribution. The ac power enters the printer through a three conductor line cord which is connected to a dual purpose double pole circuit breaker and illuminated ON/OFF switch (3CB1). The ac input voltage is then filtered through line filter 3LF1. When this On/Off circuit breaker switch is depressed to the on position, input voltage is supplied through the line filter to the cooling system blower fan and to the primary of the power transformer.

Voltage ranges are tap selectable by changing field accessible input power terminal block connections. No component changes are required when changing from 60 Hz to 50 Hz operation. The tap selectable ranges are as follows:

Nominal (VAC)	Voltage Range
100	90 to 107
120	104 to 127
200	180 to 213
220	198 to 235
230	207 to 246
240	216 to 257
260	234 to 278

The input to the transformer is stepped down to four ac output voltages. The four voltage outputs are: 30 vac, 55 vac and two separate 16 vac. On some units a special VDE/IEC fuse protection option is provided with the addition of fuses on the 30 vac and the two 16 vac outputs. The four ac output voltages then enter the power supply board where they are converted into dc voltages. The dc distribution is initiated on the power supply board. The power supply develops six dc voltages; 36 vdc, -36 vdc, +5 vdc, - vdc, +12 vdc and -12vdc. The +36 vdc and the - 36 vdc are used to supply power to the vertical (paper motion) and horizontal (print head transport) servo linear power amplifiers, which in turn supply power to drive the print head transport and paper motion servo motors. The +36 vdc also provides power to the needle driver coils.

The +12 vdc and -12 vdc are used to power the servo linear control circuits.

The +5 vdc and -5 vdc are used to power the controller circuits. The +5 vdc also supplies power to the servo digital control circuits.




FIGURE 3-2 POWER DISTRIBUTION

+5 and +12 Volt Power Supply (Figure 3-3)

The +5 and +12 vdc are generated by a 16 vac rms output from the transformer that is full wave rectified by diode bridge CR16 through CR19. The rectified 16 vac is then filtered by capacitor C15 to obtain approximately 20 vdc with several volts of ripple. The +20 volts is then routed to two independent (+12V) voltage regulators. These regulators are standard commercial 3 terminal integrated circuit devices. The +12 volt outputs are regulated by regulator action of VR1 and VR2 and capacitors C23 and C24. Diodes CR24 and CR26 protect the regulators when a fault condition occurs that would cause SCR2 to Crowbar. Silicon controlled rectifier (SCR2) is a fault protection device that grounds the input voltage to the regulator through current limiting resistor R28. The +5 volt output voltage is sensed at the Gate of SCR2 through zener diode CR22 and resistor R29. The two +12 volt outputs are sensed through Zener CR25, R41 and Zener CR27 and R42. The +5 volt regulator is a switching mode regulator. IC2 (723C) is used as a voltage reference source

as well as voltage comparing device which controls the Turn On/Turn Off Action of series transistor switch Q5. When Q5 is turned on the current flows from the input 20 volt dc voltage source through Q5, through storage inductor CL3, through the current limiting sense resistor R38 to the load and energy storage capacitors C20 and C21. When the output voltage at the load slightly exceed 5 volts, it is sensed at IC2 pin 2 via R36. Voltage regulator IC2 then turns off transistor switch Q5, disconnecting the 20 volt input source. The energy stored in inductor CL3 and capacitor C20 and C21 maintain current flow through the load. This closed loop action of current flow is provided by fast recovery diode CR23. When the output voltage drops to a value slightly below 5 volts, series switch Q5 turns on and the cycle is repeated. This constant switching action to the +20 input by the collector of Q5 maintains a 5 volt output at the load. The switching frequency is in the range of 5 to 12 KHz. Resistors R37, R38 and R39 are used for the current limit sensing circuitry internal to voltage regulator IC2. Potentiometer P2 is used to adjust the output voltage regulated by IC2 to 5 volts.




FIGURE 3-3 +5 and +12 VOLT POWER SUPPLY (9PC1)




FIGURE 3-4. -5 AND -12 VOLT POWER SUPPLY (1PC1)




FIGURE 3-5. -36 VOLT POWER SUPPLY (1PC1)

-5 and -12 Volt Power Supply (Figure 3-4)

The -5 and -12 vdc are generated by a 16 vac rms output from the transformer that is full wave rectified by diode bridge CR28 through CR31. The rectified 16 vac is then filtered by capacitor C26 to obtain approximately -20 vdc. The -20 volts is then routed to three independent voltage regulators VR3 (-12V), VR4 (-5V) and VR5 (-5V). Resistors R51 and R52 reduce the input voltage to the two -5 volt regulators VR4 and VR5, thus reducing heat generation. Zener diodes CR32 CR36 and CR37 in conjunction with transistor Q8 are used to sense over voltage at the regulated outputs of regulator VR3, VR4 and VR5 by causing Selecon Controlled Rectifier SCR3 to Crowbar. SCR3 is a fault protection device, that when closed, grounds the input voltage to the regulators through current limiting resistor R46 and R47.

-36 Volt Power Supply (Figure 3-5)

The -36 vdc is generated by a 30 vac rms output from the transformer that is full wave rectified by diode bridge CR12 through CR15. The rectified 30 vac is then filtered by capacitor C13 to obtain -36 vdc.

+36 Volt Power Supply (Figure 3-6)

The +36 vdc switch mode regulator, operates in a similar manner as described for the +5 volt switch regulator. The +36 vdc is generated by a 55 vac rms output from the transformer that is full wave rectified by diode bridge CR1 through CR4. The rectified 55 vac is then filtered by capacitor C2 to obtain approximately 72 volts dc. Voltage regulator IC1 (723), which is powered from the +20 volt source, is again used as a reference source and voltage comparator that controls the Turn On/Turn Off action of series transistor switches Q1 and Q2. Transistors Q3, Q4 and Zener diode CR10 are used to voltage translate the 20 volt operating level of IC1 to the 72 volt operating level of transistors Q1 and Q2. Similarly as in the +5 volt switch mode regulator, the input source current flows through the transistor switch Q1, through energy storage inductor CL1, to energy storage capacitors C8 and C9 to the load. The current then returns through current limit sense resistor R10 and back to the input source common. Transistor switch Q2, inductor CL2 and fast recovery diode CR9 are affectively used in parallel with transistor switch Q1, inductor CL1 and diode CR8 to boost the power output capability required




FIGURE 3-6. +36 VOLT POWER SUPPLY (1PC1)

by a single head (70 LPM) machine to that required by a two head (125 LPM) machine. When the output voltage at the load slightly exceeds 36 volts it is sensed by IC1 pin 2 through voltage divider network R13, P1, R23 and speed up response network R12 and C7. Voltage regulator IC1 then turns off the series transistor switches Q1 and Q2 disconnecting the 72 volt input source.

The stored energy in inductors CL1, CL2 and capacitors C8 and C9 maintain current flow through the load. This closed loop action of current flow is provided through resistor R10 and fast recovery diodes CR8 and CR9. When the output voltage drops to slightly below 36 volts, transistor switch Q1 and Q2 are again turned on to repeat the cycle. The switching rate is in the range of 6 to 15 KHz. Zener diode CR11 is used to sense an over voltage condition at the output and turns on Crowbar SCR 1 to short the output to ground.

Resistors R7, R9, R10, R22 and capacitor C44 are used in the current limiting circuits of IC1 to provide current limiting action.

Pot P1 is used to set the output voltage at 36 volts. Resistor R24 is used to isolate and current limit the electronic shut down input at IC1, pin 9. When the shut down line at terminal J1-13 is grounded it causes IC1 to turn off the series switches Q1 and Q2, thus turning off the 36 volt power supply. This feature is used for the needle driver current fault sensing.

HEAD READY CIRCUITS

The HD RDY circuit samples all the power supply voltages (+5V, +12V and +36V) on the Common Controller Board, plus a rectified 16 vac coming from the Power Supply Board rectifiers CR20 and CR21 (Figure 3-3 and 3-7).

The 16 vac is full wave rectified by CR16, CR18, CR20 and CR21 (Figure 3-3) which is then filtered by C50 (Figure 3-7) such that the crest of the full wave rectified ac is 2.5 volts minimum. This keeps transistor Q22 on and thus Q23 Open (Figure 3-7). If ac power is lost, the base drive to Q22 will be removed turning it Off and allowing Q23 to turn On. This in turn causes Q20 and Hd RDY output transistor Q21 to turn On. The 16 volt full wave rectified ac is used to detect when the machine is powered Off or loses ac power to generate a logical "0" level. HD RDY signal thus inhibiting p paper and head motion. Similarly a logical "0" level HD RDY and logical "1" level inhibit signal is generated when anyone of the power supply voltages is not up. All voltages are sensed by resistor divider/diode gate networks CR10, CR11, CR7, CR8, and CR9 (Figure 3-7). Loss of a supply voltage will cause Q20 and Q21 or just Q21 to turn on, thus effecting a Head Not Ready signal. Head Ready signal can be monitored at test point 40 (Figure 3-7). This signal will be at a logical "0" level when the head electronics is not able to operate.

When a Head Not Ready is generated a Servo Inhibit is also generated. When no fault is sensed and the Head Ready is at a logical "1" the following happens. Head Ready is applied to inverting gates R4 whose outputs are

held at a logical "0" (Figure 3-7). This causes current flow through the series connected LED's (Light Emitting Diodes) in photocouplers S2 and T2 (Figures 3-8 and 3-9). the LED's in turn, turn on there respective photo transistors which are connected across the base to the Emitter of Q10 and Q11 (Figures 3-8 and 3-9). Since these photo transistors are on, effectively shorting base to emitter, their emitter to collector terminals are open circuited. This open circuited condition has no affect on the operation sources Q13, Q4, Q15 and Q6 of the servo output predrive circuits (Figures 3-8 and 3-9).

When a fault occurs the Head Ready signal is in a logical "0" state (Head Not Ready). This causes the outputs of R4 gates (Figure 3-7) to be forced to a logical "1" (open circuit condition) thus interrupting current flow through the LED's in the photo couplers S2 and T2 (Figure 3-8 and 3-9). The LED's in turn, turn off there respective photo transistors which were connected across the base to the emitter of Q10 and Q11 (Figures 3-8 and 3-9). Since the bases of Q10 and Q11 are no longer shorted to their emitters they are forced to conduct by base drive current through R30 and R36. Q10 and Q11 now being a short circuit from collector to emitter causes base drive to be removed through current sources Q13, Q4, Q15 and Q6 of the servo output predrive circuits. This in turn causes the remaining servo drive transistors Q12, Q5, Q14 and Q7 to also be in an off or non conducting state. Thus preventing any base drive current flow from operating the final output drivers Q6, Q7, Q9 and Q10 on the Power Supply Board.




FIGURE 3-7 HEAD READY CIRCUITS (1PC2)




FIGURE 3-8 HEAD READY CIRCUITS (1PC2)




FIGURE 3-9 HEAD READY CIRCUITS (1PC2)

PRINT HEAD AND NEEDLE DRIVERS

Print Head (Figure 3-10)

The print head contains the print wires and solenoids necessary to perform a print operation. The print head has nine steel print wires (sometimes referred to as print needles) that are guided through molded plastic guides. Each of these nine print wires is actuated by a solenoid driver armature. When a solenoid is actuated by the driver circuit, it propels its print wire toward the platen. The print wire impacts the ribbon, driving it against the form and platen, leaving a dot impression on the form. As the print head moves horizontally across the print station, the solenoids activate the print wires, creating a series of dot patterns within a programmed matrix. The pattern of these dots in the matrix forms the character. Two types of print heads are available, the standard nine wire head and the optional nine wire overlapping head. The standard nine wire print head has the wires arranged in a single vertical column. The optional nine wire overlapping print head is identical to the standard 9 wire head with the exception that it has its print wires arranged in two vertical columns that allow the printed dots to overlap in the vertical direction. This is accomplished by the print head having two vertical rows




FIGURE 3-10 PRINT HEAD

of wires in a staggered 5-4 pattern that are located on an integral number of half dot positions apart. The controller is then programmed to delay information to one column of wires so that they will print in the same physical location as the other column of wires, thus producing an overlapped row of nine dots. Both the nine wire and the nine wire overlapping print heads are spared as assemblies only and are not intended to be reworked or repaired when rendered inoperable due to failure or end of life.

Needle Drivers (Figure 3-11)

Either 7, 9, 14 or 18 identical Needle Driver circuits may be used on 70/125 LPM Matrix Printers and is dependent on the number of heads used (one or two) and the number of print needles being fired on each head (7 or 9).

Since each of the needle driver circuits is identical, only one will be described below.

Each of these circuits are basically constant current pulse width modulation switching circuits. In conjunction with each of these circuits is a common Strobe or Needle Enable (NDL/ENAB) line which is activated at every possible dot location during a character time. The input control circuit of this common Strobe line is a pulse approximately 550 micro seconds in duration with an approximate repetitive rate of 625 micro seconds (Figure 3-7). Current flow into the needle drivers is sensed by a diode transistor network to detect current flow at invalid times and through further logic, giving us a current fault sense detection capability.

The average current through the needle solenoids is adjusted by a potentiometer (P1) setting a reference voltage for all needle driver circuits through a common bus.

When this needle driver is not selected and not enabled, the needle driver switching operation is as follows (Figure 3-1). The logical "0" of the select line is transferred at the output of the non inverting, 7407; open collector gate, thus holding output transistor Q2 off. The logical "0" at the base of Q2 is then coupled through diode CR2 to operational amplifier/comparator IC01, thus holding the output (IC01 pin 8) off. Since there is no base current of Q1 flowing through R4, transistor Q1 is also held off. Q1 and Q2 being off allows no current flow through the needle driver solenoid that is connected between the collectors of Q1 and Q2, thus causing the needles not to fire.

When the needle driver is selected, enabled and allowed to fire, the needle driver switching operation is as follows (Figure 3-11).

A logical "1" of the Select line (SEL) is transferred through the 7407 gate to the base of Q2. The needle enable bus is activated to a +36 volt level making available base drive current to Q2 through R8. The potential at the base of Q2 immediately rises above 1 volt, thus reverse biasing CR2 and removing the inhibit of IC01.

Since at the beginning of the cycle there was no current flow through the needle solenoid that was sensed by Q2's emitter resistor R1, and the voltage developed across R1 is less than the reference voltage applied at pin 3 of IC01, this causes IC01 to turn on. This also causes the output of IC01 pin 8 to go low, thus causing Q1 to turn on and allowing current to flow through the needle driver solenoid. This state is maintained until the current flow through the solenoid reaches approximately 2.8 amps. This current amplitude causes the voltage drop across sense resistor R1 to exceed the reference voltage compared by IC01, IC01 then turns off causing Q1 to also

turn off, interrupting the +36 V current flow from the power supply to the needle solenoid. Current flow through the needle solenoid is maintained through the fast recovery, free wheeling diode CR3 via Q2. In this state the needle current flow is looped through the series connected network of the needle solenoid, CR3, Q2 and current sense resistor R1. When the current amplitude drops below approximately 1.8 amps, the voltage drop across R1 is less than the voltage reference and causes IC01 and Q1 to turn on again repeating the cycle. This Turn On/Turn Off switching state is maintained until the end of the drive cycle determined by the needle enable pulse width. When the end of the pulse drive cycle is completed by the needle enable buss going to "0" volts, the base drive to Q2 is removed. The output of IC01 is then inhibited through diode CR2, thus turning off Q1. The solenoid current is now decayed to zero through free wheeling diodes CR1 and CR3. In this state the needle solenoid is connected across the +36 volt supply acts as a 36 volt Zener, however the current is absorbed

by C7 and not dissipated as heat as would be the case in an actual Zener diode. Any current flow to the solenoid driver circuits is through R9 in parallel with CR4. The voltage drop across R9, clamped by CR4, is sufficient to turn on Q3. Q3 then applies +36 volts through R12 on the Current Fault Sense line (ISENSE). This voltage level is further processed by the needle drivers current fault circuits on the Common Controller Board (1PC2).

The needle driver current fault circuit as shown in Figure 3-7 operates as follows. Cross coupled gates R5 are connected as a Set/Reset Flip/Flop and is reset to a logical "0" at pin 6 of R5 by a resistor capacitor network connected to pin 10 of R5 when the machine is powered up. A current fault will set the Flip/Flop output pin 6 or R5 to go to a logical "1" which is then coupled to the open collector of inverting gate R4 pin 3. The output or R4 pin 4 is routed to the +36 volt control regulator IC1 on the Power Supply




FIGURE 3-11 NEEDLE DRIVERS (2PC1)

Board (Figure 3-6). In the fault condition the control regulator is forced to turn off, thus shutting down the +36 volt supply and removing the fault current. This causes the head not ready signal to be activated. The Flip/Flop set by the fault can only be reset by powering down the machine. If fault is still sensed after the power up sequence, the power supply will shut down again. A needle driver current fault is sensed and sets the Flip/Flop R5 as follows (Figure 3-7).

Whenever needle solenoid current flow occurs (determined by the MT3 signal), the output of gate R4 pin 6 is held low. The current sense signal coming from the needle driver as previously described is logically "Anded" at this junction and coupled to the input of gate R5 pins 1 and 2. Since the logic level in this normal state is "0", the output of gate R5 pin 3 is held at a logical "1" and has no effect on the state of Flip/Flop R5. A fault occurs whenever (ISENSE) Current Sense line is in a logical "1" active state and MT3 is at a logical "1" inactive state. The output of gate R4 pin 6 no longer holds the input of gate R5 pins 1 and 2 at logical "0". The voltage at gate R5 pins 1 and 2 is thus allowed to rise to a level sufficient to turn the gate on and apply a logical "0" Set signal to the Flip/Flop. The time delay by C22 and R69 on the Controller Board and R12 on the Needle Driver Board.

PRINT HEAD AND PAPER MOTION SYSTEMS

Print Head Drive (Figure 3-12). The print head is attached to a print head support assembly that is belt driven horizontally back and forth along two print head support shafts by a dc servo motor.

Servo motor control circuits monitor and maintain the speed and control the direction of the print head by pulsing the voltage or reversing the current to the dc servo drive motor.




FIGURE 3-12. PRINT HEAD DRIVE AND MONITORING

Print Head Monitoring (Figure 3-12). The position of the print head is monitored by an optical reader mounted to the print head support assembly. As the print head moves horizontally back and forth the optical reader monitors a fixed mylar code strip. The code strip contains windows that when monitored indicate the 132 character positions as well as the left and right home position of the print head.

The 125 lpm printer with two heads uses a two channel optical reader and a code strip with two rows of horizontal windows. The first row of windows indicate the 132 character positions and the second row has two windows that indicate the left and right home position.

The 70 lpm printer with one head uses a four channel optical reader and a code strip with 4 rows of windows. The first two rows of windows indicate the 132 character positions and the left and right home positions when printing in the standard 10 characters per inch mode. The bottom two rows of windows indicate the 217 character positions when printing in the optional (compressed pitch) 16.5 characters per inch mode. When printing in the compressed pitch mode, the long windows on all four rows are used to indicate the left and right home position of the print head.

In both the 10 and 16.5 characters per inch modes it should be noted that the odd character position windows are in one row and the even character position windows are in the adjacent row. The staggering of these windows is done to help keep track of the heads position seeking functions.

Paper Motion System (Figure 3-13)

The paper motion system can be activated by a manual control panel forms feed switch or by an electrical command from the controller.

The vertical forms advance is driven by a dc servo motor, while the distance the forms travel is controlled by a code disk and optical reader. The standard 70 and 125 L. P. M. printers are provided with 6 line per inch spacing. An optional operator selectable 6/8 line per inch option is also available.

When a paper motion pulse is received, forward drive current is applied to the servo motor. The servo motor gear drives the tractor drive shaft. The tractor drive shaft drives the tractor sprockets, which engage the forms, causing paper motion. Servo motor control circuits monitor and maintain the speed of the servo motor by controlling the amount of forward drive current applied to the motor. To stop the motor a reverse drive current is applied to the servo motor. Once the servo motor is stopped a one way bearing on the tractor drive shaft prevents reverse rotation of the drive shaft.

The distance the forms travel is measured by a code disk mounted on the servo motor drive shaft. The code disk, in conjunction with a two channel optical reader generates the pulses used to generate the stop the paper (STP) pulse. The standard code disk generates both 6 and 8 line per inch pulses which are read by the 2 channel optical reader and sent to the controller. On standard printers the controller only accepts the 6 line per inch pulses. On printers with the 6/8 line per inch option installed, the controller will only accept the pulses of the line per inch mode selected.




FIGURE 3-13. PAPER MOTION SYSTEMS

The standard controller will respond to the four ASCII control codes: Line Feed (LF), Form Feed (FF), Vertical Tab (VT), and Carriage Return (CR). The standard paper motion system without the EVFU (Electronic Vertical Format Unit) Option installed will not respond to two of the ASCII codes -Forms Feed (FF) and Vertical Tab (VT) and converts them into Line Feeds (LF) whenever they are detected at the interface.

EVFU (Electronic Vertical Format Unit) may be installed as an option to the standard paper motion system. The EVFU consists of a format brush reader and a load EVFU switch.

The primary function of the EVFU is to read a punched format tape and load it into a controller memory where it is combined with code disk pulses to determine the line spacing.

When the EVFU paper tape is loaded in the reader and the load switch (mounted on the Vertical Transducer Printed Circuit Card Assembly) is actuated, the tape will pass through the reader until two successive form feeds (channel 1 top of form) are sensed, then, the tape is automatically re-read to check the loaded data. The tape will stop when a successful load and check has occurred. The tape may then be removed.

The maximum length of the format tape loaded into EVFU may not exceed 176 lines. The format tape must be re-loaded whenever the 6/8 line per inch mode is changed.

The Paper Runaway Option is required in the printer whenever the EVFU option is added, and prevents a runaway condition from occurring while loading the EVFU data. No controller hardware or software changes are required to use the EVFU option.

A manual vertical forms positioning lever and knob are also provided in the paper feed assembly. The clutch retractor lever when pressed, disengages the clutch on the tractor shaft and the forms can then be moved up or down as required by turning the tractor shaft knob. An additional real time, vertical format tape, brush reader unit is also available as a special option.

HORIZONTAL AND VERTICAL SERVO SYSTEMS

General

Since the control loop for both the horizontal (head motion) and vertical (paper motion) servo amplifiers are identical, only one (the vertical paper motion) will be explained up to the point where the velocity command section diverges.

Servo Control Loop (Figures 3-14 and 3-15)

The servo operates by the back EMF (Electro Motor Force) voltages feedback control theory. For example a voltage, scaled to a desired velocity is introduced at the summing input of the error amplifying T4 chip. The actual voltage on the motor is then fed back to the summing input to drive an error correction voltage which is then amplified by a power amplifier to a sufficient level to drive the motor. The motor current which is indicative of the load on the motor is sampled and converted to a voltage proportionate to the current and amplified by T4 chip. This voltage is added to the original velocity command voltage signal and compensates for a varying load on the motor.

The detailed operation of the Servo Control Loop is as follows (Figure 3-9). The velocity command voltage is injected at the inverting summing input of error amplifier T4 together with the motor terminal voltage feedback through R92 and motor current sampling through R91. Motor current is sampled and converted to a voltage by a .39 ohm resistor on the Power Supply Board and applied to the input pins 1 and 2 of differential amplifier T4. The resistor capacitor networks around the amplifier selects the amplifier gain and forms a lead/lag network for servo loop stability. The combined signals applied to error amplifier T4 pin 7 are amplified to obtain an error control signal at the input of the power amplifier. The power amplifier then raises the small error signal to a voltage and current level sufficient to operate the DC motor. The power amplifier quiescent operating point is set by two constant current sources implemented by transistor Q15 or Q6. Diodes CR5 and CR6 establish approximately a 1.3 volt level on the base of Q15 and Q6. The emitters will naturally be .65 volts below the base potential. This forces the remaining .65 volts to be dropped across the remaining resistors R45 or R35. Since this voltage is constant the value of the emitter current is nearly identical to the collector current. Q15 then operates with a collector current of approximately 2.7 milli amps. This current is equally divided between the 2 collectors of Q14. The 1.35 milli amps of one collector is divided between current flow through collector load R59 and base current from Q7. The base current of Q7 is amplified by transistor action of Q7 such that Q7 collector current will equal A6's collector current established at approximately 18 milli amps by resistor R6. The output voltage at the collectors of Q7 and Q6 is fed back through R63 and R62 to the inverting input of differential amplifier Q14. Resistors R62 and R61 voltage divide the output voltage to set the power amplifier gain to approximately 10. The output voltage is forwarded to a pair of high power transistors on the Power Supply Board which drive the servo motors. When a control voltage is applied to the non inverting input of differential amplifier Q14 pin 2, it basically reflects in a change of the current sourcing level of Q7. Since Q6 operates as a constant current sink, the difference in collector currents between Q6 and Q7 is forwarded to the base of the power output transistors which in turn raises or lowers their collector currents which are then applied to the servo motor.

Vertical Servo System (Figure 3-14, 3-15 and 3-16)

The general operation of the paper motion velocity command circuit is as follows. The -ADJ signal coming from the microprocessor is processed through a set of logic gates and timing one shorts to a discrete voltage translating transistor switch Q19.

The 0 to 5 volt TTL logic signal is converted to a +12 volt and a -12 volt signal at the collector of Q19 (Figure 3-16). The +12V and -12V swing is then converted to a negative trapezoidal wave form at the emitter of Q24. This wave form conversion is accomplished by operational amplifier T7 and emitter follower Q24 connected as an operational integrater. The generated trapezoidal waveform is then applied to the summing input of the servo control amplifier through pit P10. The shape of the trapezoidal waveform defines the shape of the velocity profile that the paper motion motor must operate.

The detailed operation of the paper motion velocity command circuit is as follows (Figure 3-16). The -ADV




FIGURE 3-14. SERVOS FUNCTIONAL BLOCK DIAGRAM

signal from the controller is supplied to a parallel path of logic gates and fault detecting timing one shots. The optional paper runaway one shot R3 is triggered, if present, from the leading edge of the -ADV signal. If the -ADV signal is not removed before the one shot R3 times out, the -ADV signal will be inhibited from rippling through gate R1 output Pin 8. The paper motion repetitive rate limiter one shot is triggered by the trailing edge of the -ADV signal and inhibits any further advance commands from rippling through at gate R1 pin 6 during the timing period of the one shot.

Horizontal Servo System (Figure 3-8, 3-14 and 3-17)

The general operation of the head motion velocity command circuit is as follows. The Head Motion Control signal is generated in a similar manner as the Paper Advance Not command signal with the important difference that there are 2 digital inputs for the heads bi-directional requirements (Figure 3-17). The two inputs are processed to obtain the bi-polar trapezoidal velocity


command (Figure 3-8 test point 49). Again similar to the paper motion circuits there is a repetition rate limiting one shot timer N5 chip for each Move Right/Move Left input. Also there is a head runaway timer/one shot M4 (Figure 3-17) which automatically halts head-motion and disables the needle drivers when a move command exceeds approximately three (3) seconds, resulting from a logic fault. The digital signal is then converted to a positive trapezoidal waveform and then routed through a group of analog "C" MOS switches to operational amplifier T7 whose output is fed to the input of the servo control amplifiers. The signal polarity at the operational amplifiers output is controlled by the state of the "C" MOS switches which are connected in a double pole double throw switch (N3) configuration at the input of the operational amplifier T7 (Figure 3-8 and 3-17).

The detailed operation of the head motion velocity command circuit is as follows (Figure 3-17). The controller logic level signals -Mov L and -Mov R are routed through gates P5 in parallel path with the repetitive

rate limiting one shots N5, which are then combined in Or Gate P4 output pin 6. At this output a -Mov L or a -MovR command will force a logical "1", which is then processed to generate an analog trapezoidal Velocity Voltage command. A repetitive rate limiting circuit is required on 70 LPM printers only and is triggered at the trailing edge of the Move Not commands to inhibit a successive -Mov command in the same direction for a period of approximately 300 milliseconds. This 300 millisecond delay circuit is required (on 70 LPM printers only) to prevent a high repetitive rate. Due to this printers position seeking capability a high rep rate could cause overheating of the servo motor. The -Mov L or -Mov R direction command is stored in the cross coupled gate latches P4 which operate a "C" MOS quad analog switch N3, which is connected as a double pole double throw switch to route the positive voltage command signal to the inverting input or the non inverting input of operational amplifier T7 (Figure 3-8). The output of T7 then develops a positive or negative voltage level that corresponds to the selected direction of motion commanded by the controller. Recall, as stated before that the -Mov R and -Mov L signals were combined into one move signal at the output of gate P4 pin 6 (Figure 3-17). The leading edge of this signal triggers head runaway one shot M4 to enable "And Gate" P4 output pin 8 to pass the move command to the ramp generator portion of

the circuit. When one shot times out it inhibits passing the move signal to the analog section and causes the head to stop. In addition the output of the one shot is anded with MT3 pulses at gate R1 output drivers from operating. Thus should a fault occur that would cause a constant move command, head motion and printing will automatically be halted. Resetting of this fault condition is accomplished by powering down the printer. The move command is passed to the ramp generator through voltage level translating translator Q2 (Figure 3-18). The +12V or -12V signal generated at the collector of Q2 is passed to the integrating amplifier, operational amplifier P2 and emitter follower Q1. Resistor R4, R19, R25, pot P6 and C11 define the up and down ramp time of the trapezoidal waveform generated at the emitter of Q1. Potentiometer P6 is used to adjust the ramp time to the required timing specifications. The peak positive level of the waveform at the emitter of Q1 is fixed by zener clamp CR1. The zero output level is maintained by the fact that CR2 clamps the output of operational amplifier P2 pin 10 at approximately -.6V. This causes the reverse biasing of the base emitter junction of Q1 cutting off any emitter current flow. The +7 volt trapezoidal waveform at the emitter of Q1 is picked off by potentiometers P4 and P5 and is used to adjust the waveform amplitude sent to

FIGURE 3-15. SERVO MOTORS CONTROL LOOP BLOCK DIAGRAM






FIGURE 3-16. VERTICAL SERVO (PAPER MOTION) SYSTEM (1PC2)

the servo control amplifier and thus adjusting the head motion velocity according to the timing specification. The outputs of the potentiometers are routed through a pair of "C" MOS analog switches P3. These switches then select the amplitude setting of either potentiometer P4 (standard head velocity) or P5 (compressed head velocity). Switch selection is accomplished by a logic level signal coming from the controller. The positive trapezoidal waveform is then routed to the inverting/

non-inverting amplifier T7 from the previously described direction selection "C" MOS analog switch N3 (Figure 3-17). Potentiometer P7 (Figure 3-8) on the inverting/non-inverting amplifier is used to balance the head velocity in both directions of motion. Again as previously described the bi-polar trapezoidal velocity control voltage signal generated at the output of amp T7 pin 12 (Figure 3-8) is then sent to the servo loop control amplifier circuits.




FIGURE 3-17. HORIZONTAL SERVO (HEAD MOTION) SYSTEM (1PC2)

DATA INTERCHANGE TECHNIQUE

The basic controller operates on an interlocked handshaking technique. The interlocked feature simply means that there are no stringent timing requirements on the data interchange signals. Transitions from one logic level to the other rather than pulses are used to exchange data.

The data source transmits a character by placing the (-) STROBE line at a logical "0". When the printer controller has sampled the data byte, the (-) ACK line will be placed at a logical "0". The (-) STROBE line may be removed concurrently or after the data source senses the (-) ACK line. When the printer controller senses the STROBE line at a logical "1", the ACK line will be placed at a logical "1". The data lines must be stable a minimum of 200 nanoseconds before and after the generation of the STROBE signal.

DATA SEQUENCING

A full line buffer memory allows the loading of 0 through 132 characters and 1 Control Code. The data load cycle may be terminated at any time by the control code, in which case the print head will move only as far as is required to print the number of characters loaded. A control code must be loaded no later than the 133rd character time; if not, a carriage return code will be automatically substituted for the 133rd character and the print cycle initiated.

The 133rd character will not be printed since it exceeds the maximum line length and is not saved for the following line.

The code recognized as valid control codes which will terminate the input cycle are the ASCII codes: VT, FF, LF, and CR.

CONTROL CODES

Carriage Return (CR)

The ASCII code CR (or any other valid control code) terminates the print cycle. It has no function with regard to paper motion; however, it is recognized as a control code which will terminate the input cycle.

Line Feed (LF), Form Feed (FF), and Vertical Tab (VT)

The ASCII Code LF results in an advance of one line. The ASCII Code FF results in the selection of the Form Channel (Channel 1). The ASCII Code VT results in the selection of Channel 2. Channel 3 and 4 are not selectable with the standard controller.

INTERFACE REQUIREMENTS

The interface voltage levels required are: Logic 1 of 2.0V to 5.5V (inputs) and 2.4V to 5.5V (outputs). Logic 0 of 0.0V to 0.8V (inputs) and 0.0V to 0.4V (outputs). The Drivers for the signals (-) Data Bits (DB1-DB8), (-) Strobe and (-) Master Clear must be able to sink 30 MA in the logical zero state.

INTERFACE SIGNALS (FIGURE 3-19)

The definitions of the I/O adapter signals can either be used by an external device or with special interface adapters.

The 70/125 LPM interface allows use of all existing 7 X 10 inch matrix printer special adapters.

The signal names are preceded by a (+) or (-) which indicates the assertion or negation respectively. For example (-) Ready, indicates that a Ready condition exists when this signal is at a logical 0.

(-) Ready (From Controller)

This line will become active (logical "0") when the START/STOP Switch is depressed if no detectable faults exist. This line will remain active until either the START/STOP Switch is depressed or a detectable fault occurs. If this should occur while a data transfer is in process, the I/O will not accept any more data and the partial line stored in the "Print Line Buffer" will not be printed. Print cycles or paper motion cycles in progress will be completed due to depressing the START/STOP Switch and going not READY, but these cycles will not be completed due to a detectable fault (loss of +36V, +12V, -5V, -12V, or -36V which causes (-) Inhibit to become active).

(+) Busy (From Controller)

This line will become active (logical "1") upon receipt of a control code and remains active until either the print cycle has been completed, or in the case of format with no data (control code being the first byte in a transmitted line), until paper motion has been initiated. Further data codes will not be accepted while the (+) BUSY signal is at logical "1".

(-) Acknowledge (From Controller)

This line when false (logical "0") indicates to the data source that the data lines have been sampled. This signal is an interlocked signal whose duration is determined by the (-) STROBE signal.

(-) Strobe (To Controller)

This line when false (logical "0") indicates to the printer that the data lines are stable and may be sampled at the discretion of the printer. If the (-) READY is a logical "1" or (+) BUSY is at a logical "1", the printer will not respond to the (-) STROBE line.

(-) Data Bits (To Controller)

Eight (8) data lines (-) DB1 through (-) DB8 carry the information (control codes and data characters) to the printer controller. (-) DATA BIT 8 is optional and should be left in the open or high state when a 7 bit interface is used. The data must be stable on the data lines a minimum of 200 nano-seconds before and after the generation of the (-) STROBE Signal.

(-) Out of Paper (From Controller)

This line when false (logical "0") indicates that paper is not present below the print station. This signal will become active (logical "0") when the paper out switch detects the absence of paper.

A Paper Out condition will not inhibit further print or paper motion cycles in the printer. The data source must sense this condition and refrain from loading more data until paper is restored in the printer.

When the data source senses an "Out of Paper" condition during loading or (+) BUSY, either a (-) Master Clear should be generated within 1.5 milliseconds after sensing the OOP condition to inhibit

the oncoming print cycle, or if the data source is keeping track of the position of the form, allow the print cycle to be initiated as normal.

If a (-) MASTER CLEAR is sent as described above, the data line must be retransmitted in order to print that line.

(-) Master Clear (To Controller)

This line when false (logical "0") resets the printer electronics. This signal when active resets all the input logic but will not remove the printer from the Ready state and will not reset the vertical or horizontal motion electronics. The duration of the "0" level must be a minimum of 2.0 milliseconds.




FIGURE 3-19 INTERFACE TIMING




FIGURE 3-20. MICROPROCESSOR BLOCK DIAGRAM

MICROPROCESSOR SYSTEM

The following information provides the theory of operation flow of the microprocessor system. Refer to Figure 3-20 for a block description of the microprocessor. Refer to Table 3-1 for a cross-reference and identification of the chips and their location in the logic section.

Data Buss: A bi-directional path on which data can flow between the CPU and memory or I/O.

Address Buss: A uni-directional group of lines that identify a particular memory location or I/O device.

Control Buss: A uni-directional set of signals that indicate the type of activity in current process.

- Type of activities:
1. Memory Read
 2. Memory Write
 3. I/O Read
 4. I/O Write
 5. Interrupt Acknowledge.

TABLE 3-1. CHIP CROSS-REFERENCE AND IDENTIFICATION

CHIP	LOGIC CROSS-REFERENCE NO.	DESCRIPTION
558	00207	LSI Microprocessor (8080A)
74LS154	0209, 16, 17, 24	Address Buffers/Decoder
8224	00207	Clock Generator and Driver
8228	00208	Systems Controller
8255	0213, 14, 15, 23	I/O Peripheral Interface
8308 (2708)	0210, 11	Program ROM (PROM)
8308	0212	Character Generator ROM
8111	0209	Buffer Memory (RAM)
8111	0218	Buffer Scratch Pad Memory (RAM)

TABLE 3-2. MEMORY MAP

CHIP SEL.	ADDR.	DEVICE			
$\overline{CS1}$	0000 03FF	PROGRAM ROM 8308		POWER ON INITIALIZATION	0000
$\overline{CS2}$	0400 07FF	PROGRAM ROM 8308		TEST PRINT	0009
$\overline{CS3}$	0800 08FF	PROGRAM ROM 8308		PRINT CYCLE	0183
$\overline{CS4}$	0C00 0FFF	PROGRAM ROM 8308		OUTPUT CYCLE	01E3
$\overline{CS5}$	1000 13FF	EXPANSION PROGRAM ROM 8308		EXEC	0400
$\overline{CS6}$	1400 17FF	EXPANSION PROGRAM ROM 8308		LOAD VFU	04B1
$\overline{CS7}$	1800 18FF	EXPANSION PROGRAM ROM 8308		FORM FEED	053F
$\overline{CS8}$	1C00 1FFF	EXPANSION PROGRAM ROM 8308		PAPER MOTION	0557
				START HEAD MOTION	06CB
				LOAD DATA	0743
$\overline{CS9}$	2000 20FF	BUFFER MEMORY 8111 8111		BUFFER RAM	2000
	2100	BUFFER MEMORY SCRATCHPAD RAM			210F
	21FF	8111 8111	VFUTP	VFU FORMAT CODES 176 LOCATIONS	2110
	2200 23FF			END CODE (FF)	21BF
$\overline{CS10}$	2400				21C0
	24FF				21C1
	2500		VFPTR	VFU FORMAT POINTER	21C2, 21C3
	25FF		PICM	LAST DATA SENT TO PIC	21C4
$\overline{CS11}$	2600		P2BM	LAST DATA SENT TO PZB	21C5
	27FF		CONCK	COINCIDENCE 6/8 CHECK DATA	21C6
$\overline{CS12}$	2800	PPI #1	CCODE	CONTROL CODE STORAGE	21C7
	2803	8255 REF. PGZ	A FLAG	TEST PRINT STATUS FLAGS	21C8
	2804 28FF		CL9AL	COL 9 DATA FOR SOL 1A-8A	21C9
$\overline{CS13}$	2C00	PPI #2	CL9U	COL 9 DATA FOR 59A & 59B	21CA
	2C03	8255 REF. PGZ	CL9BL	COL 9 DATA FOR SOL 1B-8B	21CB
	2C04		OUTAL	COL "N" DATA FOR SOL 1A-8A	21CC
	2FFF		OUTUP	COL "N" DATA FOR 59A & 59B	21CD
$\overline{CS14}$	3000	PPI #3	OUTBL	COL "N" DATA FOR SOL 1B-8B	21CE
	3003	8255 REF. PGZ	COLMS	WIDTH OF PRINTED LINE	21CF
	3004		STEPN	STEP NUMBER STORAGE	21D0
	33FF		TIMER	REITERATION COUNT	21D1
$\overline{CS15}$	3400	PPI #4	PTEND	LAST PRTABLE CHAR ADD	21D2
	3403	8255 REF. PGZ			21D3
	3404 37FF		LCCOD	LAST CONTROL CODE	21D4
$\overline{CS16}$	3800				} SPARES
	38FF				
	3C00				21EB
	3FFF				21EC
	4000 7FFF			STACK (20 LOCATIONS)	21FF
	8000	CHAR GEN ROM (8308)			
	87FF	LOWER 8 BITS			
	8800 8FFF				
	C000	CHAR GEN ROM (8308)			
	C7FF	UPPER 8 BITS			
	C800 FFFF				

TABLE 3-3. PORT DEFINITIONS AND FLAG LOCATIONS

M/NEN	ADDRESS	IN/OUT	MODE	FORMAT							
				7	6	5	4	3	2	1	0
P1A	2800	OUT	1	SOL 8L	SOL 7L	SOL 6L	SOL 5L	SOL 4L	SOL 3L	SOL 2L	SOL 1L
P1B	2801	OUT	0	SOL 8R	SOL 7R	SOL 6R	SOL 5R	SOL 4R	SOL 3R	SOL 2R	SOL 1R
P1C	2802	OUT	-	OBF	MT3	PM CMP	LF 015	COL RDY	NXT CON CHK	SOL 9L	SOL 9R
P1 IND	2803			CTL 1	MODE 0 1		AI/O 0	CUI/O 0	MODE 0	BI/O 0	CLI/O 0
P2A	2C00	IN	0	TEST PRT	FORM FEED	LD VFU	ACK OUT	STP 8 LPI	STP 6 LPI	CHAR START OIS	NXT COL RDY
P2B	2C01	OUT	0	START ENAB	PRT BSY	8080 RDY	TEST PRT MODE	ADV	MOVE R	MOVE L	GATED OSC
P2C	2C02	IN	-	START SW	RDY ENAB	HOME R	HOME L	ODD CHST	EVEN CHST	FMT CH 2	FMT CH 1
P2 IND	2C03			CTL 1	MODE 0 0		AI/O 1	CUI/O 1	MODE 0	BI/O 0	CLI/O 1
P3A	3000	IN	1	DB7	DB6	DB5	DB4	DB3	DB2	DB1	DB0
P3B	3001	IN	0	6/8 LINE	EN DW	AUTO LF	SGL SPACE	FMS ADV	80 COL	DBL SP	AUTO TERM
P3C	3002	OUT/IN	-	STOP	ACK INT	CHNL 1	CHNL 2	STROBE	INT ACT	MC	INHB SW
P3 IND	3003			CTL 1	MODE 0 0		AI/O 1	CUI/O 0	MODE 0	BI/O 1	CLI/O 1
P4A	3400	IN	0	TP SW 7	TP SW 6	TP SW 5	TP SW 4	TP SW 3	TP SW 2	TP SW 1	TP SW 0
P4B	3401	OUT	0	SPARE	NC	LED 5	LED 4	LED 3	LED 2	LED 1	LED 0
P4C	3402	IN/OUT	-	HD RDY	6 SEC DEL	SPARE SW	CMP IN	SPARE	SEL 30 LPI	PWR ON ST.	CMP OUT
P4 IND	3403			CTL 1	MODE 0 0		AI/O 1	CUI/O 1	MODE 0	BI/O 0	CLI/O 0

FLAG B REGISTER

7	6	5	4	3	2	1	0
TEMP FLAG 1	TEMP FLAG 2	TEMP FLAG 3	REV D12	9 HIGH CHAR (ROWS)	UNUSED	START	9 WIDE CHAR (COLS)

TABLE 3-4. STEP DEFINITIONS

ROUTINE	STEP NO.	FUNCTION
POMC	1.	ROM CHECK
POMC	2.	RAM CHECK
EXEC	3.	WAIT FOR START SWITCH TO BE RELEASED
EXEC	4.	LOOP FOR SWITCH DEPRESSION
LDVFC	5.	LOOP FOR STP ("1" THEN "0") & FMT CH 1
LDVFC	6.	LOADING & CHECKING VFU CODES
LDVFC	7.	LOAD COMPLETED, WAIT FOR SWITCH RELEASE
LDVFC	8.	VFU TAPE LONGER THAN 176 LINES
STHDM	9.	MOVE HEAD TO LEFT (CANNOT FIND HOME)
EXEC	A.	SINGLE SPACE SW NOT RELEASED
LDATA	B.	WAIT FOR INPUT DATA
LDATA	C.	LOADING DATA
INTRP	D.	INTERRUPT SERVICE ROUTINE (INTERFACE LINES NOT RESET)
FMFD	E.	WAIT FOR FORM FEED SWITCH TO BE RELEASED
TSPRT	F.	WAIT FOR TEST PRINT SWITCH TO BE RELEASED
	10.	
	11.	
	12.	
	13.	
OTPUT	14.	WAIT FOR NXT COL RDY
OTPUT	15.	WAIT FOR CHAR ST O/S = 1
OTPUT	16.	WAIT FOR CHAR ST O/S = 0 (REV MOTION)
OTPUT	17.	WAIT FOR CHAR ST O/S #67 = 1 (LINE COMPLETE)
	18.	
	19.	
	1A.	
	1B.	
PMOTN	1C.	LOOKING FOR STP = 0 (FIRST PASS)
PMOTN	1D.	LOOKING FOR STP = 0 (INTERRUPT ROUTINE)
PMOTN	1E.	WAIT FOR STP INTERRUPT
	1F.	
	20.	





FIGURE 3-21. SYSTEM BLOCK FLOWCHART

POWER ON AND MASTER CLEAR



Is A. C. applied to 3CB1?

Toggle the ON/OFF Circuit Breaker on (3CB1)

Fan turns on (2TBI-1 and 3)


Generate A. C. voltages: 30V (P4-5&7); 16V (P4-2&4); 16V (P4-6&8) and 55V(P4-1&3)

Generate D. C. Voltages: (-) 36V (1PC1); 5V (1PC2) and 16V Rect. A. C. (0201) (-) 12V (1PC2) and (-) 5V (0103/J7-5) and (-) 5V I/O (0103/J1-5); 36V (Buss) respectively.

As the 5V supply is coming up (0207/A5-2) a Reset Prgm Cntr (0207/A2-12) signal holds the Microprocessor in a disabled state, until the 5V supply is up.

After the Reset Prgm Cntr signal goes away, the program will start at location zero in memory and execute POMC routine.

A1



Set 9 high character flag


Enable the START F/F at port 3C.


Jump to EXECUTIVE

- 1 The program will not advance beyond this point until the problem causing ROM or RAM errors is repaired and POMC is re-initialized.
- 2 Verifies complete program is in ROM memory.
- 3 Verifies Read/Write capability of all RAM.
- 4 Step codes are displayed in hex code on LED's

EXECUTIVE

THIS ROUTINE MONITORS FOR CONTROL PANEL SWITCH DEPRESSIONS AND UPON SENSING BRANCHES TO THE APPROPRIATE SERVICE ROUTINE.







1 The auto terminate mode terminates data transfer after the 80th (80 Col. mode) or 132nd (132 Col. mode) character has been transmitted, and generates a carriage return for a control code. If auto terminate is disabled, an 81st (80 Col. mode) or 133rd (132 Col. mode) character should be transmitted as a control code.

2 Single space line advance

TEST PRINT

THE TEST PRINT ROUTINE IS ENTERED WHENEVER THE EXECUTIVE DETECTS THAT THE TEST PRINT SWITCH HAS BEEN DEPRESSED. ALL FLAGS, MEMORY LOCATIONS, AND OUTPUTS ARE THEN SETUP SO THAT THE OUTPUT CYCLE AND PAPER MOTION ROUTINES WILL EXECUTE THE TEST PRINT PATTERN (4 CHARACTERS PRINTED FOLLOWED BY 4 BLANK POSITIONS, REPEATED ACROSS THE ENTIRE PAGE). AT THE COMPLETION OF THE PAPER MOTION SUBROUTINE, PROGRAM CONTROL RETURNS TO TEST PRINT AND PRINTING CONTINUES UNTIL THE ROUTINE DETERMINES THAT THE TEST PRINT SWITCH HAS BEEN DEPRESSED A SECOND TIME. THE ROUTINE THEN RESETS TEST PRINT MODE AND THE PROGRAM RETURNS TO EXECUTIVE.





① A Flag indicates the status of The Test Print switch and the completion of a line of print. Bit 0 = Test Print switch released. Bit 1 = Test Print switch depressed (Stop Test print). Bit 2 = Print complete.


② This counter is decremented from 65 to 0 in Right to Left head motion and incremented from 0 to 65 in Left to Right head motion in a OUTPUT CYCLE subroutine. It is decremented or incremented once for each character optioned, but not necessarily printed by Head "A" or "B".

③ If the answer is yes, this means that the Test Print switch was depressed while in the test print mode, as indicated by the Test Print switch Released flag. This action will terminate the Test Print mode when the Stop Test flag is detected.

④ One character per print head is set up for each output cycle.


FORM FEED

THIS IS THE SERVICE ROUTINE FOR THE FORM FEED SWITCH. INITIAL ENTRY IS FROM EXECUTIVE, WHEREBY THE ROUTINE LOADS THE PROPER CONTROL CODE AND BRANCHES TO PAPER MOTION. UPON COMPLETION, PAPER MOTION WILL RETURN TO FORM FEED WHICH THEN RETURNS TO EXECUTIVE ONLY AFTER THE FORM FEED SWITCH HAS BEEN RELEASED.




LOAD VFU

THE LOAD VFU ROUTINE READS FORMAT DATA FROM THE OPTIONAL VFU INTO RAM MEMORY FOR LATER USE DURING PAPER MOTION ROUTINES. ONE PAGE OF VFU DATA IS LOADED INTO MEMORY FOLLOWED BY ANOTHER PAGE BEING LOADED INTO MEMORY TO CHECK FOR ERRORS. SUCCESSIVE LOADS WILL OCCUR UNTIL NO ERRORS ARE DETECTED OR UNTIL A PAPER RUNAWAY OCCURS AT WHICH TIME PAPER MOTION WILL STOP. IF THIS ROUTINE IS NOT ENTERED BEFORE ON-LINE PAPER MOTION COMMANDS OCCUR, ALL ACTIVE FORMAT COMMANDS WILL DEFAULT TO A LINE FEED.




LOAD VFU (continued)



Is the Load VFU switch released?


Jump to EXECUTIVE




Are 176 codes stored?

Microprocessor is at Step 08 (LED's are 00 1000)


Halt program. Maximum Form length has been exceeded

 EVFU must be loaded in the 6 LPI paper advance mode

THE ROUTINE ASSURES THAT THE PRINT HEAD IS IN A HOME POSITION AND THE REV FLAG AGREES WITH THAT POSITION. WHEN THESE CONDITIONS ARE SATISFIED PROGRAM CONTROL IS RETURNED TO THE CALLING ROUTINE, WHICH MAY BE EITHER PRINT CYCLE OR TEST PRINT.




THE PRINT CYCLE ROUTINE LOADS DATA INTO THE BUFFER MEMORY USING THE LOAD DATA SUBROUTINE AND THEN DETERMINES IF BOTH PRINTING AND PAPER MOTION ARE TO OCCUR OR ONLY PAPER MOTION. IF PRINTING IS TO OCCUR, THE CHARACTER CODES FROM THE BUFFER MEMORY ARE LOADED FOR EACH HEAD AND THE OUTPUT SUBROUTINE IS CALLED FOR EACH CHARACTER PAIR. AT THE COMPLETION OF PRINTING, OR IF NO PRINTING IS TO OCCUR, THE PAPER MOTION SUBROUTINE IS CALLED. AT THE END OF EACH LINE CONTROL IS RETURNED TO EXECUTIVE.




1 Allows a Master Clear interrupt during Load Data.

OUTPUT CYCLE


THE OUTPUT CYCLE SUBROUTINE CONSTRUCTS THE NINTH COLUMN PATTERNS, AND THEN PROVIDES THE PROPER SOLENOID OUTPUT DATA USING BOTH THE CHAR GEN ROM AND THE PREVIOUSLY CONSTRUCTED NINTH COLUMN DATA. THE PRINT HEADS ARE LOCATED 66 CHARACTER POSITIONS APART AND PRINTING WILL OCCUR ALTERNATELY R TO L AND L TO R. THE PRINTED CHARACTER MAY BE EITHER 7 OR 9 ROWS HIGH, DEPENDING UPON THE CHARACTER GENERATOR ROM USED.




OUTPUT CYCLE (continued)




OUTPUT CYCLE (continued)




OUTPUT CYCLE (continued)






- ① The column counter determines which column of a character will be printed next
- ② Print data for Heads A & B are read out of the upper & lower character generator ROM's. This data determines which needles are to be fired in a particular column of a character.
- ③ MT 3 O/S fires the needles in Heads A & B. Seven MT 3 O/S pulses are generated for a 7 column character and 9 pulses for a 9 column character.
- ⑤ Return to TEST PRINT or PRINT CYCLE subroutine
- ⑥ The reverse flag determines the direction of head motion. "0" = Left to Right Head Motion, "1" = Right to Left Head motion.
- ⑦ A FF (Hex) code means that head motion was right to left and head A has passed by the last character column of its print line (Column 0). A 66 code means that head motion was left to right and head A has passed by the last character column of its print line (Column 63).
- ⑧ When the next character start is detected after head A has passed through the last character column of its print line (Column 0 or 6) Move L/R is reset and the head coasts into a home position.




PAPER MOTION

THE PAPER MOTION ROUTINE CONTROLS FORMS MOTION FOR : TEST PRINT, FORM FEED, AND ON-LINE OPERATION.
 IF A CR CODE IS LOADED, A 50 MS DELAY WILL OCCUR TO RESTRICT PRINT HEAD HORIZONTAL MOTION CYCLES.
 IF AN ERROR OCCURS IN THE STORED CONTROL CODE, OR IF THE FORMAT TAPE WAS NOT LOADED, PAPER MOTION WILL DEFAULT TO A LINE FEED.
 IF THE AUTO LINE FEED OPTION IS ENABLED, CR CODES WILL GENERATE LINE FEED COMMANDS.
 IN THE STANDARD PRINTER, ONLY 2 CHANNELS OF THE VFU TAPE WILL BE LOADED INTO MEMORY.



PAPER MOTION (continued)




- 1 If the control code is a carriage return, then no paper motion command was transmitted with the line of data.
- 2 Activated by switch on printed circuit board.
- 3 If in double space mode, this flag will be set again by the first STP interrupt to call the PMUPD subroutine (EVFU POINTER UPDATE). This will allow the next (second) STP interrupt to stop the paper, thus achieving a double space advance.
- 4 A forms advance that would originate from an interface adapter: a line counter advance.
- 5 The 30 M sec Delay is for paper settle. If no paper motion occurs, a 20 M sec Delay is added to this, because the print heads require a 50 M sec set-up time before they can be re-advanced.
- 6 Interrupts are disabled, because this routine may return to an uninterruptable subroutine. M. C. or STP are the only interrupts.


NOTE:

This subroutine may also be interrupted whenever a STP or a MC is generated which CALLS the INTERRUPT SERVICE subroutine.

EVFU POINTER UPDATE




EVFU POINTER UPDATE (continued)




- 1 Loading the EVFU is accomplished by installing a VFU tape and depressing the load VFU switch. The tape may then be removed.
- 2 The EVFU pointer is a flag that points to the present forms line number that is in front of the print station. (See memory map)
- 3 The EVFU format code will be a form feed (channel 1), or vertical tab (channel2), or the absence of both channels which is interrupted as a line feed command.
- 4 When this flag is set, paper motion will be terminated by the next STP pulse. See PAPER MOTION INTERRUPT subroutine.
- 5 Returns to the PAPER MOTION subroutine or PAPER MOTION INTERRUPT subroutine.

PAPER MOTION INTERRUPT



- ① One Line Feed O/S is generated for each line of print. This is an interface adapter signal only and does not affect the basic printer operation
- ② This flag is set in the electronic VFU UPDATE subroutine. When detected paper motion is terminated.
- ③ A memory location that is updated at every STP interrupt to point at the proper 6/8 LPI Count (0, 1, 2, 0, 1, 2 for 6 LPI and 0, 1, 2, 3, 0, 1, 2, 3, for 8 LPI)
- ④ STP generates an interrupt which would immediately interrupt a PAPER MOTION or LOAD DATA subroutine. When this interrupt has been serviced by this PAPER MOTION INTERRUPT subroutine, program control will return to the interrupted subroutine.


INTERRUPT ENABLE




- 1 Waiting for STP that generates interrupt to go false.
- 2 Allows STP interrupt during paper motion operations.
- 3 Returns to EVFU UPDATE or PAPER MOTION INTERRUPT subroutine.

LOAD DATA

THIS SUBROUTINE TRANSFERS DATA FROM THE INTERFACE INTO THE BUFFER MEMORY. DATA IS ACCEPTED UNTIL A CONTROL CODE HAS BEEN RECOGNIZED OR A SUFFICIENT NUMBER OF CHARACTERS HAVE BEEN RECEIVED TO FILL THE OUTPUT LINE. VALID CONTROL CODES ARE FF, LF, VT, & CR.



LOAD DATA (continued)



1 Allows this subroutine to be interrupted by MC or STP

2 Inhibits paper motion


3 If this path was taken, it means the 81 print characters have been loaded, rather than 80 characters and a control code. Therefore, columns must be decremented by one, so 80 and not 81 columns will be printed, if the printer is in the 80 column mode.

4 PTEND is used in the print cycle subroutine to determine if the print heads are beyond the last character to be printed in a line. If so, Head B or Head A and Head B printing is inhibited.

NOTE:

This subroutine may also be interrupted whenever a STP or MC is generated which CALLS the INTERRUPT SERVICE subroutine.

INTERRUPT SERVICE



1 Reset = FF. When PT END is other than FF, this indicates that data is to be printed. It must be cleared, because this path will re-enter the LOAD DATA subroutine.

2 When the Microprocessor receives an interrupt, it locks out further interrupts. Therefore, enable interrupts must be set when leaving this routine.

3 Return to the PAPER MOTION or LOAD DATA subroutine which was interrupted.

INSTALLATION AND CHECKOUT

WARNING

THE INSTALLATION AND CHECKOUT OF THESE PRINTERS REQUIRES THE REMOVAL OF PROTECTIVE COVERS PROVIDED TO PROTECT THE CUSTOMER AND FIELD SERVICE REPAIRMEN FROM HAZARDOUS VOLTAGES AND MECHANISMS. THE INSTALLATION AND CHECKOUT OF THESE PRINTERS SHALL ONLY BE PERFORMED BY TRAINED FIELD SERVICE REPAIRMEN WHO HAVE BEEN TRAINED TO WORK ON THESE PRINTERS WITH THE PROTECTIVE COVERS REMOVED.

INTRODUCTION

This section covers Site Planning, Unpackaging and Assembly, Installation, Check out and Disassembly and Repackaging of the 70/125 line per minute Matrix Printer. The installation and checkout of these printers should only be attempted by trained field service personnel. This entire section plus the Operating Instructions Section and the Principals of Operation Section should be read before attempting to install or check out the printer.

NOTE

WHEREVER EIGHT DIGIT PART NUMBERS APPEAR IN THE TEXT, THE PREFIX 70 SHOULD BE ADDED TO THE NUMBER TO CREATE THE TEN DIGIT NCR PART NUMBER.

SIGHT PLANNING

The important factors to be considered when choosing the printer's location include the access space necessary for operating and servicing, availability of electrical power and the environmental requirements of the printer.

SPACE REQUIREMENTS

Adequate access space must be provided for the operation and maintenance of the printer. Figure 4-1 shows the overall dimensions of the printer and Figure 4-2 shows the suggested minimum access area required around the printer for its operation and maintenance. Other points to keep in mind in selecting the printer location are: personnel traffic patterns, storage of printing forms and operator supplies.

The printer's weight may vary a few pounds depending upon model, but generally, the printer will weigh approximately 100 lbs (45.5 kg).




FIGURE 4-1. PRINTER DIMENSIONS




FIGURE 4-2. PRINTER ACCESS

Electrical Requirements

Power Cord. The standard printer is provided with a three wire (hot, neutral and earth ground) power cord of which 8 feet (2.44 meters) is external of the printer. The standard power cord is terminated with a non-locking 3 prong plug for use with 60 Hz outlets. The cord may also be fitted with plugs for use with 50 Hz outlets. Before changing power cord configurations ensure the printer is wired for the required voltage. For details on changing voltage configurations, see voltage requirements below.

Frequency. The printer may be operated from a 50 or 60 Hz (single phase) power source within the following frequency ranges:

Nominal Frequency	Tolerance Range
50 Hz	49.0 to 50.5 Hz
60 Hz	59.0 to 60.6 Hz

Voltage Requirements. Due to the difference in nominal voltage inputs between countries the printer is equipped with a multi-tap input transformer. Voltage ranges can be tap selected by changing field accessible input power connections to terminal block 2TB01.

No component changes are required when changing from 60 Hz to 50 Hz operation. The tap selectable ranges available are as follows:

Nominal (VAC)	Voltage Range
100	90 to 107
120	104 to 127
200	180 to 213
220	198 to 235
230	207 to 246
240	216 to 257
260	235 to 278

For detailed instructions and wiring diagrams on how to convert the printer to any of the above voltage ranges, see the installation section of this manual.

Current. The current requirements are as follows:

Printer	Amps	VAC	Hz
125 lpm	1.75	220	50
125 lpm	3.2	120	60
70 lpm	1.53	220	50
70 lpm	2.8	120	60

Input Power. The input power requirements are as follows:

Printer	Volt/Amps
125 lpm	384
70 lpm	336

Heat Generation. The heat generation is as follows:

Printer	Watts
125 lpm (printing)	278 (239 kcal/hour)
125 lpm (idling)	100 (86 kcal/hour)
70 lpm (printing)	243 (209 kcal/hour)
70 lpm (idling)	100 (86 kcal/hour)

Input Power Protection. A dual purpose double pole circuit breaker and illuminated On/Off switch located in the front right corner of the printer cabinet provides input power protection and is rated as follows:

Full Load = 7.5 amps rms.
Trip = 9.38 amps rms.

Cooling. The printer has internal forced air ventilation to ensure proper cooling of internal parts if the specified printer environmental requirements are maintained.

Environmental Requirements

Operating Temperature And Humidity. The printer has been designed to operate within the following ambient conditions:

- Temperature Range: 10°C-35°C (50°F-95°F)
- Temperature Change: 10°C (18°F) per hour max.
- Humidity Range: 20-80% (non condensing).
- Humidity Change: 10% per hour max.

Storage Temperature And Humidity. The printer can withstand the following temperature and humidity ranges when properly packaged for up to three months of storage:

Temperature Range: -10°C to 50°C (14°F to 122°F)

Temperature Change: 15°C (27°F) per hour max.

Humidity Range: 10% to 90% (non condensing).

Barometric Pressure. The maximum operating altitude for this printer is 6560 feet (2000 meters). Printers operating above this altitude require a special option, high altitude cooling kit.

UNPACKAGING AND ASSEMBLY

Read this entire section before unpackaging and assembling the 70/125 Line Per Minute Printer and its associated options.

The following tools are required to unpackage and assemble the printer and its associated options:

1. Tin snips or sheet metal shears.
2. Screwdriver 1/4 (0.25 inch-6.35 mm) blade.
3. Pocket knife (to cut tape, card board, cloth straps, plastic bags, etc).
4. Crescent wrench (adjustable spanner) 6 to 8 inches long.

Pedestal (Optional) Unpackaging And Assembly.

1. Open the pedestal box.
2. Remove the pedestal parts, bag of assembly hardware and the assembly instructions.
3. Check the parts against the assembly instructions to assure that none of the parts are missing or damaged.
4. Assemble the pedestal per the assembly instructions

Printer Unpackaging And assembly (Figure 4-3)

1. Cut and remove the steel strapping securing the printer carton to the wood skid (if applicable).
2. Cut the carton sealing tape and open the printer carton flaps. Remove the printer manuals.
3. Reach into the carton and remove the cushion from the top of the printer.
4. Lift the dust cover off the printer.
5. Carefully remove the printer from the box and lower cushion. Place the printer on a solid bench or table.

CAUTION

THE PRINTER WEIGHS 100LBS (45.5KG), TRYING TO LIFT THE PRINTER FROM THE CARTON WITHOUT ADEQUATE ASSISTANCE COULD CAUSE BODILY INJURY. TO PREVENT INJURY, IT IS RECOMMENDED THAT THE CARTON BE PLACED ON A TABLE AND THAT THE PRINTER BE REMOVED BY CUTTING OPEN ONE END OF THE CARTON AND SLIDING THE PRINTER OUT ON THE BOTTOM CUSHION. PLASTIC DUST COVER IS VERY SLIPPERY AND CARE SHOULD BE TAKEN WHEN LIFTING PRINTER WITH DUST COVER IN PLACE.

6. Remove the filament tape and wrapping material that was used to hold the Print Head Support Casting and Paper Weights in place during shipment.

7. Inspect the printer for shipping damage.

8. Remove the two hex head shipping screws that lock the floating printer structure to the printer base plate during shipping. These two screws are located on the bottom of the printer base plate. One screw is located on the left side, half way between the left front and left rear rubber feet. The other screw is located on the right side, half way between the right front and right rear rubber feet. These screws should be saved for re-use if the printer is ever repackaged for shipping. When removing these screws do not tilt the printer up on an edge so that its weight is resting on the cabinet. Slide one side of the printer at a time over the edge of a table until the screw is accessible.

9. If the printer is to be pedestal mounted, install the optional pedestal at this time (Figure 4-4). For detailed instructions on how to mount the printer to the pedestal, see the assembly instructions provided with the pedestal. The mounting hardware is provided with the pedestal.

10. If the printer is provided with an optional paper basket or any of the other option kits, unpackage them and install them to the printer using the assembly and installation instructions provided with each kit.

11. The printer is now ready for installation and check-out.


Paper Basket (Optional) Unpackaging And Assembly (Figure 4-5)

1. Open the paper basket box.
2. Remove the two piece paper basket and grounding strip bracket assembly, bag of assembly hardware and the assembly instructions.
3. Check the parts against the assembly instructions to assure that none of the parts are missing or damaged.
4. Mount the grounding strip and bracket assembly to the printer base plate as shown in Figure 4-5.
5. Hook the paper basket mounting rack over the printer paper tensioner shaft at the top rear of the printer (Figure 4-5)
6. Mount the paper basket into the paper basket mounting rack (Figure 4-5).

PRINTER INSTALLATION

1. Install the printer on a fairly level surface, so that the printers weight is resting evenly over all four rubber feet.

If the printer is to be installed on a table, bench or cabinet, level the top surface before placing the printer on it. If the table, bench or cabinet does not have built in levelers use shims under the legs or corners. If the printer is installed on



FIND NO.	PART NUMBER	DESCRIPTION	QTY
001	59126301	CARTON {PRINTER}	1
002	59126302	BOTTOM CUSHION	1
003	59126303	TOP CUSHION	1
004	59125407	DUST COVER	1
005	59126310	SKID {WOODEN}	1
006	59136123	EDGE PROTECTOR	4
007	59136107	STEEL STRAP	2
008	59136109	FILAMENT TAPE	30"
009	59136111	CARTON SEALING TAPE	136"

FIGURE 4-3. PRINTER PACKAGING




FIGURE 4-4. PRINTER TO PEDESTAL MOUNTING




FIGURE 4-5. PAPER BASKET INSTALLATION




FIGURE 4-6. ALTERNATE POWER CONFIGURATION FOR WIRING THE UNIVERSAL TRANSFORMER

a printer pedestal, the pedestal may or may not have optional built in adjustable levelers or casters for leveling the printer. Pedestals without levelers or casters may be leveled using shims under the legs. In general the printer will operate on a fairly unlevel surface as long as it is not allowed to rock. The main reason for requiring that the printer be level, is for form feed purposes. If the top surface of the form stack is not fairly level with the printer, the tension on the forms will be uneven as it enters the printer. Uneven tension on the forms could cause form tearing or paper jams.

2. Remove the upper cabinet cover and the lower cabinet skirt. (Figure 1-1).
3. With a volt meter, check the building line voltage at the wall socket or power outlet provided for the printer.
4. Using the wiring diagrams shown in Figure 4-6 check the wiring configuration of your printers universal transformer and the circuit breaker to terminal block 2TB01. If your printer is not wired correctly, change the wiring of terminal block 2TB01 to obtain the voltage requirements found in step 3 above. When making these wire changes make sure that the brown wire from the circuit breaker is changed along with the transformer leads.
5. The standard printer power cord is terminated with a non locking 3 prong plug for use with 120 volt 60 Hz outlets. The cord may also be fitted with plugs for use with 50 Hz outlets. If the plug supplied with the printer does not meet with local safety or electrical requirements, the plug should be removed and replaced with a plug that does.
6. The printer is now ready for checkout.

PRINTER CHECKOUT

The checkout of these printers should only be attempted by trained field service personnel.

1. Do not plug the printer power cord plug into the wall or power outlet at this time.
2. If they are not already removed, remove the upper cabinet cover and the lower cabinet skirt.
3. Using the wiring diagram shown in Figure 4-6 check to see if terminal block 2TB01 is wired for your required voltage configuration.
4. In the logic chassis at the rear of the printer, unlatch and swing down the Controller And Print Head Board (card location 1PC2) and the Power Supply Board (card location 1PC01).
5. Using Figure 4-7 locate and inspect the five fuses on the power supply board. Also inspect the connections to circuit breaker 3CB1 and line filter 3LF01.
6. Inspect and trace all interconnecting ribbon cables. Insure that all ribbon cable connectors are connected and seated properly.
7. Inspect all the printed circuit cards and insure that all chips and ROM's are seated properly.

CAUTION

INTEGRATED CIRCUITS AND MOS CHIPS ARE PRESENT ON THE PRINTED CIRCUIT BOARDS IN THIS PRINTER. THESE DEVICES ARE EASILY DESTROYED IF A STATIC ELECTRICAL CHARGE IS ACCIDENTALLY APPLIED TO A PIN THROUGH IM-

IDENT	LOCATION	FUNCTION	PART No.	AMPS	TYPE
F1	POWER SUPPLY {1PC1}	+36 VOLTS	24536202	5A	MTH5
F2	POWER SUPPLY {1PC1}	-36 VOLTS	24521723	1.6A	MDL1.6 {SLO BLOW}
F3	POWER SUPPLY {1PC1}	+5 AND +12 VOLTS	24536202	5A	MTH5
F4	POWER SUPPLY {1PC1}	-5 AND -12 VOLTS	24512920	1A	AGC1
F5	POWER SUPPLY {1PC1}	+36 VOLTS	24521723	1.6A	MDL1.6 {SLO BLOW}
3CB01	FRONT OF PRINTER	MAIN POWER BREAKER	76647100	7.5A	203-22-1-3291-1
F-6	P4A-J4A-7	30V	24521727	3A	MDL-3 {SLO BLOW}
F-7	P4A-J4A-2	16V	24521733	10A	MDL
F-8	P4A-J4A-8	16V	95650916	2A	MDL




FIGURE 4-7. FUSES AND CIRCUIT BREAKER LOCATIONS

PROPER HANDLING OR REPAIR. THESE STATIC CHARGES CAN BE MINIMIZED OR ELIMINATED IF PROPER PRECAUTIONS ARE OBSERVED.

- A. WHEN HANDLING INTEGRATED CIRCUITS OR PLUG-IN BOARDS, DO NOT TOUCH THE CIRCUITS PINS OR PLUG-IN BOARD CONNECTOR PINS. HANDLE BY THE EDGE ONLY.
 - B. WHEN REMOVING OR INSERTING A CONNECTOR OR BOARD, GROUND YOURSELF TO THE UNIT FRAME BEFORE TOUCHING THE BOARD OR CONNECTOR. DO NOT REMOVE OR INSERT A CONNECTOR OR BOARD WITH THE UNIT POWERED ON.
 - C. DO NOT REMOVE A PLUG IN BOARD OR CHIP FROM ITS SHIPPING CARTON UNTIL READY TO INSERT IT INTO THE PRINTER.
 - D. USE ONLY A THREE WIRE SOLDERING IRON WHEN REPAIRING PRINTED CIRCUIT BOARDS. LAY THE BOARD ON AN INSULATED PIECE OF MATERIAL. DO NOT LAY THE BOARD ON METAL OR PLASTIC.
8. Inspect the Controller And Print Head Board (card location 1PC2) to insure that the program and character generator ROM's are installed. Follow the precautionary measures indicated in step 7 above when installing these ROM's. See Figure 4-9 for a quick check to see whether your printer has the correct number of program and character generator ROM's for your basic printer configuration.
9. With the aid of Figure 4-10, locate switches SWN4-1 through SWN4-8, which are mounted on the controller and print head board (card location 1PC2).
- Select and actuate, the switch selectable standard features required for your printer site.
- For detailed descriptions of these features see the standard features section of Section I in this manual.
10. Locate and inspect all major assemblies for damage or loose parts.
11. With your hand, move the print head back and forth on the print head support shafts several times to assure that it moves freely.
12. Unlock the right and left tractors and slide them both from right to left. The tractors should both slide easily.
- Lock both tractors in place. The tractors should not be able to slide.
13. If the printer requires a special interface, make sure the interface adapter option kit is installed in the logic chassis at card location 1A03. See the interface kit manual for installation and check-out instructions.
14. Make sure the printer on/off switch is in the off position. Plug the printer into its power outlet.
15. Install a ribbon cassette to each head (Figure 2-3).
16. Install the forms and lower the necessary paper tension weights (Figure 2-5).
17. The printer is now ready to power on.
- To operate the printer with the cabinet removed, the interlock switch, located to the left of the control panel, must be pulled up.
- Press the on off switch to the on position.
18. Actuate the Test Print Switch located on the Controller And Print Head Board in card location 1PC2. (Figure 4-6).

NOTE

IF THE TEST PRINT CONTROL PANEL SWITCH IS ADDED, ACCESS TO THE CARD MOUNTED SWITCH IS NOT NEEDED.

19. This switch causes the printer to print the character "B" alternating with blanks across the page and then performs a single line advance (Figure 4-8). Use this pattern to check vertical and horizontal alignment of the forms.
20. Actuate the Test Print Switch. This second actuation will terminate the Test Print Operation.




FIGURE 4-8. TEST PRINT SAMPLE

21. If your printer has the 6/8 Line Per Inch Option or the Compressed Pitch Option, check them out at this time.

Do not actuate the 6/8 LPI Switch or the Compressed Pitch Switch when the printer is printing in the Test Print Mode. Terminate the Test Print Operation, actuate the option switch and then re-enter the Test Print Mode.

22. If your printer has an Electronic Vertical Format Unit installed, load the format tape into the reader. Actuate the Load EVFU Switch and load the tape into memory. Press the Form Feed Switch on the control panel. The printer should slew paper to the top of form.

23. Power off the printer by placing the on/off switch in the off position. Remove the forms from the printer.




FIGURE 4-9. PROGRAM AND CHARACTER ROM REQUIREMENTS AND TEST PRINT SWITCH LOCATION




FIGURE 4-10. CONTROLLER AND PRINT HEAD BOARD SWITCH SELECTABLE FEATURES

24. Replace the lower cabinet skirt (Figure 1-1), replace the upper cabinet cover and knobs. Assure that the two upper cabinet locking screws are backed out to their locked positions (Figure 1-1).
25. Power the printer on.
26. Load forms.
27. If the printer has Electronic Vertical Format Unit, load the format tape into memory.
28. Install the interface cable and actuate the Start/Stop Switch. The switch will illuminate and the printer is ready for on line operation.

DISASSEMBLY AND PACKAGING

Printer Disassembly And Repackaging (Figure 4-3).

1. Unplug and coil the line cord. Tape or tie the coiled cord so it will not uncoil. Place the cord on top of the printer.
2. Remove the Paper Basket, Paper Basket Mounting Rack and the Paper Basket Grounding Strip Bracket Assembly. Retain all basket mounting hardware to be packaged with the basket.
3. If the printer is pedestal mounted, remove the four screws that mount the pedestal to the printer. Retain the pedestal mounting hardware for repackaging with the pedestal.
4. Assure that all printer covers are in place and that the two upper cabinet cover locking screws (Figure 1-1) are screwed all the way in to their unlocked positions.
5. Install the two hex head (M6X8) metric shipping screws that lock the floating printer structure to the printer base plate during shipping. These two screws are installed from under the printer. One screw is installed on the left side of the base plate half way between the front and left rear rubber feet. The other screw is installed on the right side of the base plate, half way between the right front and right rear rubber feet.
If the printer is pedestal mounted, install these screws before removing the printer from the pedestal.
When installing these shipping screws on non-pedestal mounted printers, do not tilt the printer up on an edge so that its weight is resting on the cabinet. Place non-pedestal mounted printers on a table. Slide one side of the printer at a time over the edge of the table until the screw installation holes are accessible.
6. Tape the print head support castings in place with filament tape so they will not move during shipment. Wrap & tape the paper weights in place so they will not cause damage during shipment.

7. Assemble the printer carton using carton sealing tape.
8. Place the carton on the shipping skid.
9. Place the bottom cushion in the bottom of the carton.
10. Place the printer into the box and bottom cushion.


CAUTION

THE PRINTER WEIGHS 100 LBS (45.4 KG). TRYING TO PLACE THE PRINTER INTO THE CARTON WITHOUT ADEQUATE ASSISTANCE COULD CAUSE BODILY INJURY.

11. Place the dust cover over the printer.
12. Place the top cushion on top of the printer.
13. Place the printer manuals on top of the top cushion.
14. Close the carton flaps and seal them with carton sealing tape.
15. Strap the carton to the skid using steel strapping and edge protectors.
16. The printer is now packaged and ready for shipment.


Pedestal (Optional) Disassembly And Repackaging (Figure 4-11)

1. Disassemble the pedestal and place each of the following in polyethylene bags:
 - A. Left Upright
 - B. Right Upright
 - C. Bottom Frame Cross Member
2. Assemble the pedestal carton, using carton sealing tape.
3. Place the Left and Right Pedestal Uprights into the carton with a separator pad between them.
4. Place a separator pad on top of the top pedestal upright.
5. Place the Bottom Frame Cross Member into the pedestal carton on top of the separator pad.
6. Place the pedestal assembly and mounting hardware in a plastic or paper bag along with the installation instructions. Tape the bag to the inside of the bottom frame cross member, using filament tape.
7. Place crushed newspaper or packaging material on top of the bottom frame cross member to keep it from moving during shipment.
8. Close the carton flaps and seal them with carton sealing tape.



FIND NO	PART NUMBER	DESCRIPTION	QTY
001	59126304	CARTON {PEDESTAL}	1
002	59126305	SEPARATOR PAD	2
003	59125605	POLYETHYLENE BAG	3
004	59136109	FILAMENT TAPE	10"
005	59136111	CARTON SEALING TAPE	100"
006	NONE	PLASTIC OR PAPER BAG	1

FIGURE 4-11. PEDESTAL PACKAGING



FIND NO	PART NUMBER	DESCRIPTION	QTY
001	59126306	CARTON {PAPER BASKET}	1
002	59136109	FILAMENT TAPE	40"
003	59136111	CARTON SEALING TAPE	100"
004	NONE	PLASTIC OR PAPER BAG	1

FIGURE 4-12. PAPER BASKET PACKAGING

Paper Basket (Optional) Disassembly And Repackaging (Figure 4-12)

1. Assemble the carton using carton sealing tape.
2. Using filament tape, tape the paper basket to the paper basket mounting rack.
3. Place the basket Grounding Strip Assembly and its mounting hardware in a plastic or paper bag along with the paper basket installation instructions. Tape the bag to the bottom of the paper basket.
4. Place the Paper Basket Mounting Rack and Paper Basket into the carton.
5. Close the carton flaps and seal them with carton sealing tape.

MAINTENANCE

INTRODUCTION

This section contains information to aid the service personnel in maintaining the printer. Information presented in this section includes:

Maintenance Aids
Preventive Maintenance

MAINTENANCE AIDS

Maintenance aids refers to tools, materials and built in printer features that aid the service personnel in performing maintenance on the printer.

Tools And Materials

Tools and materials required to maintain the printer are listed in three groups: Standard Maintenance Tools, Special Maintenance Tools, and Maintenance Materials. Standard Maintenance Tools are items normally used by service personnel and are specifically needed for maintaining this printer (Table 5-1). Special Maintenance tools are items or special design which are not normally carried by service personnel (Table 5-2). Maintenance Materials are basic supplies used during maintenance of the printer (Table 5-3).

Test Print

The Test Print feature and option enables off line testing. The Test Print Feature is standard on all printers and is located on the Controller And Print Head Board in card location 1PC2 (Figure 4-6).

If the optional control panel mounted Test Print Switch is added, access to the card mounted switch is not needed. Activation of either switch will cause the printer to alternately print groups of characters (character "B") followed by groups of blank characters.

When a full line of this pattern is completed a single line advance occurs. The Test Print Operation will continue until the switch is activated again removing the Test Print Condition.

TABLE 5-1. STANDARD MAINTENANCE TOOLS

	DESCRIPTION
	OSCILLOSCOPE, DUAL TRACE, DC-10MHZ MIN., CALIBRATED TRIGGERED SWEEP.
	MULTIMETER, DC: 0-50V, ACCURACY 2% MIN., 20K /VOLT, AC: 0-260V., ACCURACY 3% MIN.
	RETAINING RING PLIERS, REVERSIBLE INTERNAL/EXTERNAL COMBINATION TYPE.
	SCREW DRIVER ASSORTMENT, FLAT BLADE AND PHILLIPS.
	SOLDERING IRONS, 25-27 WATT AND 37-40 WATT (RECOMMENDED).
	HEX KEY (ALLEN)-WRENCH SET, METRIC (1.5 MM -5 MM)
	WRENCH SET-OPEN END OR COMBINATION OPEN AND BOX END, METRIC (3MM-14MM)
	ADJUSTABLE CRESENT WRENCH, 6 TO 8 INCHES LONG
	GAUGE SET, THICKNESS (THICKNESS IN MILLIMETERS OR 1000 ths OF AN INCH)
	MEASURING RULER (15 CM METRIC OR 6 INCH 10-50 PARTS TO THE INCH)

TABLE 5-2. SPECIAL MAINTENANCE TOOLS

	DESCRIPTION
	VACUUM CLEANER, WITH HAND HELD BRUSH AND NOZZLE.
	PUSH-PULL SPRING SCALE WITH READINGS IN EITHER GRAMS OR OUNCES (100-1200 GRAMS OR 1/2 OZ - 3LBS)
	EYE-LOUPE MAGNEFIER (4X, WITH HEAD BAND).
	SOCKET SET, METRIC (1/4 INCH, DRIVE)
	DIGITAL COUNTER ,DC TO 10 MHZ 1 MOHM INPUT INPEDANCE, ± 1 MICROSECOND RESOLUTION, TTL INPUT COMPATABLE

TABLE 5-3. MAINTENANCE MATERIALS

	DESCRIPTION
	LINT FREE CLOTH
	SOFT DUSTING BRUSH
	LUBRICATING OIL-SUN OIL CO., SUNEK 1150 (FOR LUBRICATING THE PAPER ADVANCE WORM GEAR)
	MILD COMMERCIAL CLEANING SOLVENT OR DETERGENT (FOR CLEANING THE EXTERIOR CABINET).

PREVENTIVE MAINTENANCE

The 70/125 line per minute printers must receive a minimum of one half hour of preventative maintenance every 1280 power on hours or every 75 million characters printed. (which ever occurs first).

The preventive maintenance should be performed by trained field service personnel. It is recommended that all maintenance personnel become thoroughly familiar with the mechanical functions, logic circuits and interface requirements of the printer prior to performing any maintenance checks or adjustments. General safety precautions must be observed at all times when working within the printer. High voltage is present at the line filter (3LF01), circuit breaker (3CB01), fan (2B02), terminal block (2TB01) and power supply p.c. board 1PC1. To avoid personel injury when working on the printer with the covers removed, always unplug the printer line cord from its power

source. The following preventive maintenance procedures should be performed on the 70/125 LPM printers every 1280 power on hours or every 75 million characters printed:

Cleaning

1. Press the on/off switch to the off position. Unplug the printer line cord from its power source.
2. Remove the upper cabinet cover and the lower cabinet skirt.
3. Brush and vacuum clean the interior of the printer.
4. Clean the exterior of the cabinet with a clean lint free cloth and a mild commercial cleaning solvent or detergent. The clear plastic front cover should only be cleaned with water and a soft non-abrasive cloth.
5. Plug the printer line cord into its power source.

Lubrication

1. Lubricate the felt wick over the worm gear on the paper advance servo motor with 3 to 4 drops of lubricating oil. Use the special oil indicated in Table 5-3.

Part Replacement

1. Replace the ribbon cassette drive cords (refer to the replacement section of this manual).

Checks And Adjustments

1. Inspect the Print Head Drive Belt and the Print Head Motor Belt for sign of wear and for proper belt tension. Adjust or replace belts if necessary. (Refer to the "Mechanical Tests And Adjustments and Replacement" sections of this manual).
2. Check and adjust the Out Of Paper Switch. (Refer to the Mechanical Tests and Adjustments section of this manual).
3. Check the printout in the Test Print Mode for light or missing dots, for proper character width, and for vertical character alignment. If a problem exists adjust or replace parts as necessary (refer to the "Mechanical Test And Adjustments" and the "Replacement" section of this manual).
4. Function test all switches and options.
5. Replace the lower cabinet skirt and upper cabinet cover.

FAULT ISOLATION

INTRODUCTION

This section on fault isolation is intended to be used with the Principals Of Operation Section, Tests And Adjustments Section and the Diagrams Section of this manual. The Fault Isolation Section is divided into three parts; Fuse Functions And Locations, Binary

Code And LED Display Diagnostics, and Fault Isolation Flow Charts.

FUSE FUNCTIONS AND LOCATIONS

For fuse functions, locations and part numbers see Figure 6-1.

IDENT.	LOCATION	FUNCTION	PART NO.	AMPS	TYPE
F1	POWER SUPPLY {1PC1}	+36 VOLTS	24536202	5A	MTHS
F2	POWER SUPPLY {1PC1}	-36 VOLTS	24521723	1.6A	MDL 1.6 {SLO BLOW}
F3	POWER SUPPLY {1PC1}	+5 AND +12 VOLTS	24536202	5A	MTHS
F4	POWER SUPPLY {1PC1}	-5 AND -12 VOLTS	24512920	1A	AGC1
F5	POWER SUPPLY {1PC1}	+36 VOLTS	24521723	1.6A	MDL 1.6 {SLO BLOW}
3CB1	FRONT OF PRINTER	MAIN POWER BREAKER	76647100	7.5A	203-22-1-3291-1
F6	P4A-J4A-7	30 VOLTS	95650910	3A	MDL
F7	P4A-J4A-2	16 VOLTS	24521733	10A	MDL
F8	P4A-J4A-8	16 VOLTS	95650916	2A	MDL




FIGURE 6-1. FUSE FUNCTIONS AND LOCATIONS CHART




FIGURE 6-2 POWER SUPPLY VOLTAGE TEST POINTS AND VOLTAGE DISTRIBUTION




FIGURE 6-3. LIGHT EMITTING DIODE (LED) DIAGNOSTICS

BINARY CODE AND LED DISPLAY DIAGNOSTICS

LED Binary Display Diagnostics

The LED Diagnostics (standard optional feature) consists of 6 light emitting diodes (LED 0 thru LED 5) mounted on the Controller And Head Logic Board Assembly located in card location 1PC2 (Figure 6-3)

With this option installed the controller electronics isolates and displays on (6) LED lamps a binary code for a controller detectable error condition. A chart or these codes and their interpretation is given in Figure 6-4.

A special LED Diagnostics Display option is also available. This optional display is mounted on the left side of the printer and is accessible for viewing by removing the side cover. This led display performs the same functions as the display on 1PC2 (Figure 6-5).

Needle Driver Fault LED

A single light emitting diode (LED 8) is provided on the Controller And Head Logic Board. This LED is provided on all printer as standard equipment and when lit indicates that the current to one of the needle drivers has not turned off after firing (Figure 6-3).

Binary Diagnostics Without LED

The binary codes for LED diagnostics are generated from Port 4, pins 18 through 23 (Figure 6-3). By looking for "one's" and "zero's" at pins 18 through 23 with an oscilloscope, a binary code may be generated and applied to Figure 6-3 to identify the fault. Port 4 comes standard on 70 LPM printers, but is optional on 125 LPM printers.

BINARY LED DISPLAY*	DESCRIPTION OF THE STATUS FAULT BEING DISPLAYED
00 0001	<u>ROM CHECK</u> - THE SUMMATION OF "EXCLUSIVE OR" THROUGH MEMORY DOES NOT RESULT IN ZERO. THIS IS A SPECIAL MEMORY CHECK TO INSURE INTEGRITY OF ALL STORED DATA. A SPECIAL CHECK SUM IS USED TO CHECK THE "EXCLUSIVE OR SUM OF ALL STORED DATA.
00 0010	<u>RAM CHECK</u> - RAM IS MALFUNCTIONING AND NOT "READING" OR "WRITING" PROPERLY. THIS IS A CHECK OF THE RAMS "READ" AND "WRITE" CAPABILITY OF "ONE'S" AND "ZERO'S" INTO THE RANDOM ACCESS MEMORY.
00 0011	<u>START SWITCH NOT RELEASED</u> - START SWITCH IS BEING HELD DOWN WHEN GOING INTO A STOP MODE.
00 0100	<u>WAIT LOOP FOR SWITCH DEPRESSION</u> - NO CONTROL PANEL SWITCH HAS BEEN DE-PRESSED. EXECUTIVE LOOP WHICH MONITORS ANY CONTROL PANEL SWITCH DEPRES-SION.
00 0101	<u>MISSING STP OR FMT CHANNEL 1</u> - LOAD ELECTRONIC VERTICAL FORMAT UNIT ERROR INDICATING NO STP OR MISSING FORMAT CHANNEL 1.
00 0110	<u>EVFU TAPE LOAD ERROR</u> - LOAD ELECTRONIC VERTICAL FORMAT UNIT ERROR INDI-CATING INCORRECTLY PUNCHED TAPE OR EVFU PROGRAM ERROR.
00 0111	<u>EVFU LOAD SWITCH NOT RELEASED</u> - LOAD SWITCH HAS BEEN ACTUATED BUT HAS NOT BEEN RELEASED.
00 1000	<u>EVFU TAPE LONGER THAN 176 LINE</u> - THE MAXIMUM LENGTH OF FORMAT TAPE LOADED INTO EVFU MAY NOT EXCEED 176 LINES.
00 1001	<u>CANNOT HOME PRINT HEAD</u> - AN ATTEMPT TO MOVE THE HEAD TO LEFT HOME POSITION HAS NOT RESULTED IN MOVING THE HEAD TO THE LEFT HOME POSITION AFTER A ONE SECOND TIME OUT.
00 1010	<u>SINGLE SPACE SWITCH NOT RELEASED</u> - THE SINGLE SPACE SWITCH HAS BEEN ACTI-VATED BUT HAS NOT BEEN RELEASED.
00 1011	<u>WAIT FOR INPUT DATA</u> - PRINTER IS ATTEMPTING TO LOAD DATA BUT NO STROBE HAS OCCURRED.
00 1100	<u>LOADING DATA</u> - FIRST CHARACTER HAS BEEN LOADED BUT THE LOAD CYCLE IS NOT COMPLETE.
00 1101	<u>INTERFACE ERROR</u> - A PROCESSOR MASTER CLEAR HAS BEEN RECEIVED.
00 1110	<u>FORM FEED SWITCH NOT RELEASED</u> - THE FORM FEED SWITCH HAS BEEN ACTIVATED BUT HAS NOT BEEN RELEASED.
00 1111	<u>TEST PRINT SWITCH NOT RELEASED</u> - THE TEST PRINT SWITCH HAS BEEN ACTIVATED BUT HAS NOT BEEN RELEASED.
01 0000	POSITION SEEK IN PROCESS (PM70 ONLY).
01 0001	(NOT USED)
01 0010	(NOT USED)
01 0011	(NOT USED)
01 0100	<u>MISSING MT 3 O/S</u> - CONTROLLER IS ATTEMPTING TO PRINT THE NEXT COLUMN OF DOTS IN A PARTICULAR CHARACTER.
01 0101	<u>MISSING CHARACTER START O/S</u> - CONTROLLER IS WAITING FOR AN INDICATION OF A CHARACTER START POSITION.

FIGURE 6-4. LED AND BINARY CODE FAULT CHART

CONTINUED

BINARY LED DISPLAY*	DESCRIPTION OF THE STATUS FAULT BEING DISPLAYED
01 0110	<u>CHARACTER START O/S AT CONSTANT "1"</u> - CHARACTER START O/S IS STAYING AT A CONSTANT "1".
01 0111	<u>CHARACTER START O/S NUMBER 67 MISSING</u> - THE CHARACTER O/S FOR CODE STRIP CHARACTER POSITION 67 IS MISSING (138/218 IN PM70).
01 1000	<u>ELONGATED CHARACTER HAS STARTED-</u> THE ELONGATED CHARACTER ROUTINE IS IN PROCESS (PM70 ONLY)
01 1001	(NOT USED)
01 1010	(NOT USED)
01 1011	(NOT USED)
01 1100	<u>STP AT A CONSTANT "1" (FIRST PASS)</u> - PROCESSOR HAS BEEN INTERRUPTED BY AN STP AND STP IS MAINTAINED A CONSTANT "1".
01 1101	<u>STP AT A CONSTANT "1" (INTERRUPT ROUTINE)</u> - PROCESSOR HAS BEEN INTERRUPTED BY AN STP AND STOP IS MAINTAINED A CONSTANT "1".
01 1110	<u>WAIT FOR STP INTERRUPT</u> - WAITING FOR AN STP INTERRUPT FOR COMPLETION OF PAPER MOTION CYCLE.
01 1111	(NOT USED)

1 = LAMP LIT IN THAT POSITION

0 = LAMP NOT LIT IN THAT POSITION

* = THE MOST LEAST SIGNIFICANT DIGIT IS TO THE RIGHT

FIGURE 6-4. LED AND BINARY CODE FAULT CHART (CONTINUED)





FIGURE 6-5. LIGHT EMITTING DIODE (LED) DIAGNOSTICS

FAULT ISOLATION FLOW CHARTS



PRINTER DOES NOT POWER ON (FIGURES 3-2, 6-1 AND 6-2)

Is the building line voltage present at the wall socket or power outlet provided for the printer? Is the line cord connected to the power source?

Connect printer to proper power source and power the printer on.

Unplug the printer and check the continuity across the on/off circuit breaker switch 3CB01 when it is in the on position.


Does continuity exist?

Replace circuit breaker switch 3CB01.

Either the line filter (3LF01) is open or shorted, or there is a wiring fault (short or wire disconnected) between the power source and circuit breaker switch (3CB01). If there is a short the circuit breaker will continue to kick off on power up.

START LAMP DOES NOT COME ON WHEN START SWITCH IS DEPRESSED (FIGURES 6-1 AND 6-2)

Check the Head Ready signal (Ready = "1", Not Ready = "0" monitored at 1PC2 test point 40). All voltages must be present for Head Ready signal to go Ready. Check power supply voltages at 1PC2-J1 and adjust voltages if necessary (Figure 6-2)



Are any fuses blown?

Are any voltages low?

Bad Controller Board or bad lamp on control panel.

Are +36V (F5) or -36V (F2) fuses blown?


Probable servo driver amplifier problem. Check head servo output driver transistors Q6 and Q7 on 1PC1 for a short. Check paper motion servo output driver transistors Q9 and Q10 on 1PC1 for a short. If short exists replace board or components.

Disconnect plug 1PC2-J2 and replace +36V fuse F5 or -36V fuse F2. Power printer up, but do not go Start.

Is IPC2 test points 43 or 48 greater than +0.5V?

Board 1PC2 is bad. Replace board and reconnect 1PC2-J2

Board 1PC2 is good. The only problem was with Q6, Q7, Q9 or Q10 servo output drivers. Connect plug 1PC2-J2.



Is the +5V or +12V (F3) fuse blown, or are these voltages low?

Is the -5V or -12V (F4) fuse blown, or are these voltages low?

Disconnect Controller Board plug 1PC2-J1 to isolate the voltages on Power Supply Board 1PC1. At the interface, disconnect the plug that comes from 1PC1-J7 so that the voltages will be isolated on 1PC1. Replace blown fuse and power up.

Are the proper voltages at 1PC1-J1-1 (+12V), 1PC1-J1-3 (+5V), 1PC1-J1-5 (-5V) and 1PC1-J1-7 (-12V).

Power Supply Board 1PC1 is bad. Replace or repair board and adjust voltages.

At the interface, connect the plug that comes from 1PC1-J7. Replace blown fuses and power up.

Are the proper voltages at 1PC1-J1-1 (+12V), 1PC1-J1-3 (+5V), 1PC1-J1-5 (-5V) and 1PC1-J1-7 (-12V).


The Interface Board is bad. Replace or repair board.

Disconnect 1PC2-J3 (From Vertical Transducer Board 5PC1). Disconnect 1PC2-J4 (From Control Panel). Disconnect 1PC2-J6 (From Needle Driver Board 2PC1). Connect 1PC2-J1 (From the Power Supply Board). Replace blown fuses and power up.

Are the proper voltages at 1PC2-J1-1 (+12V), 1PC1-J1-3 (+5V), 1PC1-J1-5 (-5V) and 1PC1-J1-7 (-12V).

The Controller Board 1PC2 is bad. Replace or repair board and adjust as necessary.

By powering down and then powering up again after each connection, connect 1PC2-J3 (from Vert. transducer Board 5PC1), 1PC2-J4 (from Control Panel) and 1PC2-J6 (from Needle Driver Board 2PC1), one at a time until the +5 voltage at 1PC2-3 is either lost or found to be low. The connection that causes the lost or low voltage will identify the faulty P.C. board. If when plugging in 1PC2-J6, a faulty +5 voltage is detected, also unplug 2PC1-J2 (from the Horiz. Transducer Board 2PC2). If the +5 voltage is present, then 2PC2 is bad.



Is +5 volts present on 5PC1, the control panel, 2PC1 and 2PC2?

Replace or repair the faulty board/boards. Replace all below fuses and plugs.

Is the +36V (F1) fuse blown or is this voltage low?

Disconnect 1PC1-J3 (from the Needle Driver Board 2PC1) Replace blown fuses and power up.

Is the proper voltage at 1PC1-J1-9 (+36V)?

Power supply board 1PC1 is bad. Replace or repair board and check adjustments.

Reconnect 1PC1-J3 (from the Needle Driver Board 2PC1). Replace blown fuses and power up.


Is the proper voltage at 1PC1-J1-9 (+36V)?

Needle Driver Board 2PC1 is bad. Replace or repair board and adjust needle current.

Replace all blown fuses. Reconnect all plugs. Power up and go Start. The Head Ready signal at 1PC2 test point 40 should be at a logical "1" indicating that all voltages are present on all boards.

END

PRINTER GOES START BUT NOTHING HAPPENS



Power off printer to clear logic and center print head between the two side plates.

Power printer on. While monitoring test point 43 on 1PC2 for plus (+) or minus (-) 10 to 20 volt drive voltage, enter the Test Print mode by throwing the Test Print switch on 1PC2.

Did print head move at least to the left Home position?

Within two (2) seconds after entering test print was the plus or minus 10 to 20 volts present at test point 43?

Bad Controller Board 1PC2. (head electronics section). Repair or replace 1PC2.

Power off printer to clear logic. Unplug 1PC1-J6 (harness to horizontal servo drive motor). Power printer on. While monitoring the voltage on 1PC1-J6 pin 1 to pin 2 for a plus or minus 10 to 20 volt motor drive voltage, enter the Test Print switch on 1PC2.

Within two (2) seconds after entering Test Print, was plus or minus 10 to 20 volts present at 1PC1-J6 pin 1 to pin 2?

Bad Power Supply Board 1PC1 or bad harness from 1PC2-J2 to 1PC1-J2. Repair or replace 1PC1 or harness.

Power off printer to clear logic. Connect 1PC1-J6 (harness from 1PC2 to horizontal servo drive motor). Power printer on. While monitoring the voltage across the horizontal servo motor terminals for a plus or minus 10 to 20 volt motor drive voltage, enter the Test Print mode.

Within two (2) seconds after entering Test Print was plus or minus 10 to 20 volts present across the motor terminals?

Wiring fault exists between 1PC1-J6 and motor. Repair wiring fault.


Problem is mechanical or you have a bad motor.

Are any of the head drive belts broken or off their pulleys? Are any of the head drive pulleys loose on their shafts?

Replace necessary belts and tighten loose pulleys.

Bad horizontal servo drive motor. Replace motor.





Is the print head motion operating correctly?

Interface or data source problem or data source has no data to send.

Code strip is misaligned, or dirty, bad code strip reader or bad Controller Board 1PC2.

Power printer off and disconnect motor drive harness at 1PC1-J6.

Clean the code strip with water and a soft, non-abrasive cloth.

Check and adjust if necessary the code strip alignment to the code strip reader.

Move the head to the right home position. Power the printer on and check the reader outputs on 1PC2 at chip K4 pins 1,3,11, and 13 for single head machines and at chip K4 pins 1 and 3 for double head machines.

Are the outputs from the reader at a logical "0"?

Bad reader or wiring fault in wiring to reader. Check wiring and replace Horizontal Transducer Board 2PC2 if necessary.


With the head in the right home position, move the head slightly to the left so that the reader is off the Home window, but not in the first character window.

Are the outputs from the reader at a logical "1"?

Bad reader or wiring fault in the wiring to the reader. Check wiring and replace Horizontal Transducer Board 2PC2 if necessary.

The code strip reader is good. The fault is with 1PC2 Controller Board. Repair or replace 1PC2.

PRINT HEAD MOVES, BUT DOES NOT PRINT



Is the print head connector connected and seated to its mating flat cable connector (connection is made on the connector mounting plate under the printhead)?

Make connections and assure that connectors are properly seated.

Are the Needle Driver Board (2PC1) connectors J1, J3, J4 and J5 connected and properly seated?

Make connections and assure that connectors are properly seated.

Is +36 volts present across capacitor C7 on Needle Driver Board 2PC1.

Bad cable from Power Supply Board to 2PC1-J3 or cable is unplugged at power supply board 1PC1-J3.

Is approximately 1.13 volts present across resistor R20 on Needle Driver Board 2PC1 (Note: +5 volts is required on this board to get the 1.13 volt level. Absence of the +5 volts would cause improper horizontal head motion from an inoperative transducer)?

Bad 2PC1. Repair or replace 2PC1.

Enter test print mode.


Are -NDLENAB pulses present on Needle Driver Board (2PC1) IC05 pin 1 (each pulse is approximately 550 micro seconds at a 625 micro second rep rate. 7 pulses equal a character)?


Bad J4 cable to the Needle Driver Board (from 1PC2-J6), bad Controller Board 1PC2 or bad character generator Rom on 1PC2.


Are SELECT pulses present on needle driver board (2PC1) IC04 pin 5?


Bad J4 cable to the Needle Driver Board (from 1PC2-J6), bad Controller Board 1PC2 or bad character generator ROM on 1PC2.

Bad Needle Driver Board (2PC1). Repair or replace 2PC1.









TESTS AND ADJUSTMENTS

MECHANICAL TESTS AND ADJUSTMENTS

PULLEY ASSEMBLY-RIGHT HAND

Tools Required

1. Feeler gage .005 in. (0.13 mm) thick.
2. Allen wrench 2 mm hex (metric).
3. Screwdriver (flat blade type).

Tests (Figure 7-1)

1. Check for .003 to .014 in. (0.08 to 0.38 mm) clearance between the large 44 tooth pulley and the thrust bearing.

Adjustments (Figure 7-1)

1. Loosen the screws that hold the two pulleys to the shaft.
2. Center the shaft so that its ends are sticking out the same distance on either side of the pulley support casting.




FIGURE 7-1. PULLEY ASSEMBLY - RIGHT HAND

3. Slide the small 30 tooth pulley and thrust bearing to the left against the needle bearing in the pulley support casting. Rotate the pulley so that its two screws are in line with the flats on the shaft. Tighten the pulley to the shaft.
4. Place a .005 in. (0.13 mm) feeler gage between the large 44 tooth pulley and the thrust bearings on the right. While pushing the shaft to the left, push the large pulley, feeler gage and thrust bearings to the right. Tighten the pulley screws to the flats on the shaft.

PULLEY ASSEMBLY-LEFT HAND

Tools Required (Figure 7-2)

1. Feeler gage .005 in. (0.13 mm) thick.
2. Screwdriver (flat blade type).




FIGURE 7-2. PULLEY ASSEMBLY - LEFT HAND

Tests (Figure 7-2)

1. Check for .003 to .014 in. (0.08 to 0.38 mm) clearance between the 30 tooth pulley and the thrust bearing.

Adjustments (Figure 7-2)

1. Loosen the screws that hold the pulley and the sleeve to the shaft.
2. Center the shaft so that its ends are in line with or sticking out the same distance on either side of the pulley support casting.
3. Slide the sleeve and thrust bearing to the left against the needle bearing in the pulley support casting. Rotate the sleeve so that its screw is in line with the flat on the shaft. Tighten the sleeve to the shaft.
4. Place a .005 in. (0.13 mm) feeler gage between the 30 tooth pulley and the thrust bearing on the right. While pushing the shaft to the left, push the pulley, feeler gage and thrust bearing to the right. Tighten the pulley screws to the flats on the shaft.

HEAD DRIVE BELT TENSION AND ALIGNMENT

Tools Required

1. Push pull spring scale with readings in either grams or ounces (100-1200 grams or $\frac{1}{2}$ oz. - 3 lb.)
2. 7 mm open end or box wrench.
3. Screwdriver - flat blade type.
4. Measuring ruler (15 cm metric or 6 inch 10-50 parts to the inch).

Tests (Figure 7-3)

1. Remove the two screws that hold the belt retaining clamp to the bottom of the print head support casting. On units with two heads, remove the clamp from each head.
2. Position the end of a measuring ruler against the plate under the head drive belt. Center the ruler in the belt span so it is perpendicular to the belt.
3. Note the reading on the ruler where the upper belt span crosses the ruler.
4. Apply a force that will cause a $.39^{+}.04$ in. ($10^{+}1$ mm) deflection of the belt. Note the spring scale reading. The reading should be 0.77 lbs. (350 G).
5. The left and right hand pulley assemblies should be adjusted so that the belt has minimal side contact with its flanged pulleys.

6. With the belt retaining clamps in place, slide the print heads from side to side. The print head should cause a minimum amount of deflection or lift to the belt. This check is accomplished by standing a measuring ruler on end at either side of the structure and checking the deflection and lift of the upper belt span as the heads are moved from side to side.

Adjustments (Figure 7-3)

1. The Left Hand Bracket Support, Left Hand Pulley Assembly and Right Hand Pulley Assembly have been positioned with fixtures at the factory to assure proper print head drive belt tension and alignment. Adjustments to the Right And Left Hand Pulley Assemblies or the Left Hand Bracket Support should not be necessary for the life of the printer, except when it is necessary during parts replacement. The location of these pulley assemblies and brackets should be marked with a pencil or scribe before removal or adjustment is attempted.
2. Belt Tension Adjustment
 - a. Mark the location of the left hand pulley assembly on the left hand bracket support, using a pencil or scribe.
 - b. Loosen the two left hand pulley assembly mounting screws (use a 7 mm open end or box wrench).
 - c. Move the left hand pulley assembly to achieve the proper belt tension. Use the pencil or scribe marks to aid in the alignment. Align the belt before tightening the two mounting screws.
 - d. Replace the belt retaining clamps.
3. Belt Alignment
 - a. After adjusting the belt tension, manually move the print head across the print line to see if the belt is tracking in the center of the pulleys. If the belt is dragging on a pulley edge, the left pulley assembly may be turned slightly or moved sideways to align the belt travel.
 - b. The ideal alignment of the printhead drive belt should be such that when the print head is moved from side to side, the print head does not lift or deflect the belt. This alignment should not require adjusting unless the right hand pulley assembly is moved or replaced or the left hand bracket support is moved. This adjustment is made by moving the left hand bracket support and/or the right hand pulley assembly either up or down to achieve minimum print head lift or deflection of the belt.




FIGURE 7-3 PRINT HEAD BELT DRIVE SYSTEM - ADJUSTMENTS

APR., 78

PRINT HEAD MOTOR AND DRIVE BELT

Tools Required

1. Push-pull spring scale with readings in either grams or ounces (100-1200 grams or $\frac{1}{2}$ oz. - 3 lbs.).
2. 7 mm open end or box wrench.
3. Screwdriver-flat blade type
4. Measuring ruler (15 cm metric or six inch 10-50 parts to the inch).
5. 2 mm hex key (allen) wrench.

Tests (Figure 7-3)

1. Position the end of a measuring ruler against the right side of the print head structure so it is perpendicular to the belt. Center the ruler in the belt span and note the reading on the ruler where the belt crosses the ruler.
2. Apply a force that will cause a .16 in. (4 mm) deflection of the belt. Note the spring scale force reading. The reading should be 2.26 lbs. (1025 G).
3. Slide the print head from one side of the printer to the other. The motor drive belt should track in the center of the 44 tooth pulley on the right hand pulley assembly.

Adjustments (Figure 7-3)

1. Belt Tension Adjustments

- a. Mark the location of the motor mounting bracket on the side of the print head structure using a pencil or scribe.
- b. Loosen the three screws that mount the horizontal servo motor and mounting bracket assembly to the right side of printhead structure (use a 7 mm open end or box wrench). Swing logic cards down to gain access.
- c. Move the horizontal servo motor and mounting bracket assembly down to achieve the proper belt tension. Use the pencil or scribe marks to aid in the alignment. Align the belt before tightening the three mounting screws.

2. Belt Alignment

- a. After adjusting the belt tension, manually move the print head across the print line to see if the motor drive belt is tracking in the center of the pulleys. If the belt is not tracking properly, the horizontal servo motor and mounting bracket may be turned slightly or the servo motor pulley may be adjusted. The belt is permitted to wander, provided that it does not overlap either edge of the large 44 tooth pulley.

VERTICAL SERVO WORM GEAR ALIGNMENT

Tools Required

1. Screwdriver - flat blade type
2. 1.5 mm hex key (allen) wrench.
3. Measuring ruler (15 cm metric or six inch 10-50 parts to the inch)
4. 7 mm open end or box wrench.

Tests (Figure 7-5)

1. The location of the worm gear on the motor shaft should be .16 \pm .04 inches (4 \pm 1 mm) from the front surface of the motor mounting bracket as shown in Figure 7-5.
2. Check for maximum backlash of .002 inch (0.05 mm) between the worm gear on the motor and the gear on the clutch assembly, assuring that there is no binding and that the motor runs freely.
3. With the clutch engaged with the tractor drive shaft and the tractors locked at any position between the left and right format plates, the motor slew current should average .3 amps, with maximum peaks of .8 amps.

Adjustments (Figure 7-5)

1. Loosen the set screws that secure the worm gear to the motor shaft. Position and tighten the gear on the shaft to the dimension shown above and in Figure 7-5.
2. Loosen the three screws that mount the vertical servo motor assembly to the side of the print head structure. Adjust and tighten the servo motor assembly so that minimum backlash exists between shaft and the gear on the clutch assembly. Assure that there is no binding and that the motor runs freely.

CODE DISK AND OPTIONAL READER CLEARANCE

NOTE

CHECK THAT FORMAT TAPE IS INSTALLED

Tools Required

1. 5.5 mm open end or box wrench.
2. Screwdriver - flat blade type.

Tests (Figure 7-5)

1. Check to see if the vertical transducer board assembly is 90° to the code disk and that the code disk is centered in the optical reader.
2. Check to see if the optical reader is positioned to the code disk as shown in Figure 7-5.

Adjustments (Figure 7-5)

1. Loosen the two screws that mount the vertical transducer board assembly to the format plate assembly. Adjust the vertical transducer board assembly and its optical reader to the code disk as shown in Figure 7-5. Tighten the two mounting screws.

FORMAT READER BRUSH BLOCK

Tools Required

1. Screwdriver - flat blade type
2. 1.5 mm hex key (allen) wrench.




FIGURE 7-4. FORMAT READER AND CODE DISK SYNCHRONIZATION.




FIGURE 7-5. VERTICAL PAPER MOTION AND FORMAT READER ADJUSTMENTS

3. Measuring ruler (15 cm metric or six inch 10-50 parts to the inch).
4. Oscilloscope, dual trace, DC-10 MHz min, calibrated triggered sweep.

Tests (Figure 7-4/7-5)

1. Check the distance the ends of the three brushes are from the step in the brush block (Figure 7-5).
2. With an Oscilloscope monitor chip H3 pin 8 (brush reader format channel 1). Now ground pin 13 of test plug TJ1 or pin 1 of chip R2 to logic ground to cause a constant paper slew. Chip H3, test plug TJ1 and chip R2 are located on the Controller And Head Logic board in card location 1 PC2. The format channel 1 signal should be visible and pulsing.

Adjustments (Figure 7-4/7-5)

1. Loosen the brush retaining screws and locate the brushes at the proper length per Figure 7-5.
2. Adjust the adjusting screw which is located on the front of the brush block. Turn the screw clockwise until you see format channel 1 as a pulsing signal on the oscilloscope while monitoring chip H3 pin 8. The sprocket should deflect the tips of the brushes from .03 to .06 inches (0.76 to 1.52 mm) when adjusted properly.
3. When the brush adjusting screw is turned counterclockwise, the bracket holding the brush block must be free to move by the action of the spring force with no external help.

FORMAT READER AND CODE DISK SYNCHRONIZATION (FIGURE 7-4/7-5)

Tools Required

1. Screwdriver - flat blade type.
2. Oscilloscope dual trace, DC-10 MHz min., calibrated triggered sweep.

Tests (Figure 7-4/7-5)

1. Install a 6 LPI format tape in the format reader and power the printer on.
2. With an oscilloscope monitor chip H3 pin 8 (brush reader format channel 1) and chip H3 pin 13 (6 LPI STP from the code disk optical reader). Now ground pin 13 of test plug TJ1 or pin 1 of chip R2 to logic ground to cause a constant paper slew. Chip H3, test plug TJ1 and chip R2 are located on the Controller And Head Logic Board (card location 1PC2). Trigger the oscilloscope on the positive edge of format channel 1 signal. If the format reader and the code disk are synchronized properly, the 6 LPI STP signal should be centered within the brush reader channel 1 signal as shown in Figure 7-4.

Adjustments (Figure 7-4/7-5)

1. Continue to monitor chip H3 pins 8 and 13 per step 2 of tests above.
2. Remove ground from TJ1 pin 13 or chip R2 pin 1, stopping paper slew and code disk movement. Loosen the screw that retains the code disk. Rotate the code disk slightly and tighten the screw.
3. Repeat steps 1 and 2 until the 6 LPI STP signal is centered within the brush reader channel 1 signal as shown in Figure 7-4.

TRACTOR ASSEMBLY

Tools Required

1. Screwdriver - flat blade type
2. Feeler gage set

Tests (Figure 7-6)

1. Check the clearance between the front face of the tractor body and the tractor body cover per Figure 7-6.




FIGURE 7-6 TRACTOR ASSEMBLY

Adjustments (Figure 7-6)

1. Loosen the four screws that mount the body bracket assembly to the tractor body.
2. Adjust the body bracket assembly to obtain the clearance shown in Figure 7-6.
3. Tighten the four screws that hold the body bracket assembly in place.

PAPER FEED ASSEMBLY

Tools Required

1. Screwdriver - flat blade type
2. Retaining ring pliers, reversible internal/external combination type.
3. Feeler gage set.
4. 1.5 mm hex key (allen) wrench.

Tests (Figure 7-7)

1. Tractor Drive Shaft And Bearing End Play (Figure 7-7)
 - a. Grasp the tractor drive shaft and move it from side to side. Check .001 in (0.02 mm) maximum end play between the shaft retaining ring and the spacer.
2. Clutch Hub Engagement (Figure 7-7)
 - a. With the clutch release lever in its released position, try to rotate the lower tractor shaft counter clockwise. The shaft should not turn.
 - b. With the clutch release lever held against the left hand format plate assembly, hand rotate the lower tractor shaft. There should be no contact of the teeth on the clutch gear with the teeth on the clutch hub.




FIGURE 7-7. PAPER FEED ASSEMBLY

Adjustments (Figure 7-7)

1. Tractor Drive Shaft And Bearing End Play Adjustments (Figure 7-7)

- a. Remove as much bearing end play as possible by adding shims between the bearing housing and the bearing.
- b. Remove as much tractor shaft end play as possible by adding shims between the thick spacer and the bearing.

2. Clutch Hub Engagement Adjustment (Figure 7-7)

- a. Add or remove spacers between the right hand format plate assembly and the bearing housing until the clutch gear engages and disengages the clutch hub properly (Figure 7-7). This can be accomplished by shimming the bearing housing so that the distance between the left hand format plate assembly and the clutch gear is $.222 \pm .001$ in. (5.64 ± 0.02 mm).

SHAFT ALIGNMENT BRACKETS (FIGURE 7-8)

The shaft alignment brackets are located on either side of the print head structure. These brackets are used to locate the two print head support shafts to the platen. The shaft alignment brackets have been located to the print head structure at the factory, using a special setup fixture and should never need adjusting in the field.

CAUTION

DO NOT ADJUST OR LOOSEN THE SHAFT ALIGNMENT BRACKETS. THE MOUNTING SCREWS FOR THESE BRACKETS HAVE BEEN MARKED WITH RED GLYPTOL VARNISH FOR IDENTIFICATION AND SHOULD NEVER BE LOOSENEED.

PRINT HEAD TO PLATEN

Tools Required

- 1. Screwdriver - flat blade type.
- 2. 7 mm open end wrench.
- 3. Feeler gage set.

Tests (Figure 7-8)

1. Platen To Head Parallelism

- a. Turn the density control knob counter clockwise so that the distance between the platen and the print head face can be measured with a feeler gauge.

- b. Move the print head all the way to the right and check the clearance between the print head face and the platen.

- c. Move the print head to the center and then all the way to the left checking the clearance between the print head face and the platen.

- d. The clearances should be the same within $\pm .001$ in. (± 0.02 mm).

2. Head To Platen Clearance (Not required on 70 LPM printers with operator replaceable head)

- a. Turn the density control knob all the way counter clockwise so that the platen is in its forward most position.
- b. Printers with five detent positions ; Move the print head along the platen from one side to the other checking the clearance between the print head face and the platen. The clearance should be $.020 \pm .001$ in. (0.5 ± 0.02 mm).
- c. Printers with multiple detent positions; Move the print head along the platen from one side to the other checking the clearance between the print head face and the platen. The clearance should be $.010$ to $.020$ in. (0.25 to 0.50 mm).

Adjustments (Figure 7-8)

1. Platen To Head Parallelism

- a. This is a factory adjustment and should only require readjusting when the platen is removed or replaced.

Loosen the stop screws on the right and/or left platen advance bracket assembly and rotate the adjusting eccentric nuts until an identical clearance is achieved between the platen and the print head face.

- b. Tighten the stop screws and recheck.

2. Head To Platen Clearance (Not required on 70 LPM printers with operator replaceable head)

- a. Printers with five detent positions; Loosen the two print head retaining screws and shim the print head to achieve $.020 \pm .001$ in. (0.5 ± 0.02 mm) clearance between the print head face and the platen (Figure 7-8).
- b. Printers with multiple detents positions; Loosen the two print head retaining screws and shim the print head to achieve $.010$ to $.020$ in. (0.25 to 0.50 mm) clearance between the print head and the platen (figure 7-8).

LOWER PAPER SLIDE TO PLATEN

Tools Required

- 1. Screwdriver - flat blade type.

2. Feeler gage set.

Tests (Figure 7-8)

1. With the platen in its forward most position check for a clearance of .010 to .059 in (.25 to 1.50 MM) between the lower paper slide and the platen. This check should be made along the entire edge of the paper slide.

Adjustments (Figure 7-8)

1. Loosen the two lower paper slide mounting screws located on the inside of the print head structure and just under the platen on either side. Adjust the lower paper slide to achieve the required clearance between the slide and the platen.
2. Tighten the mounting screws and recheck.

LINE FINDER TO PLATEN

Tools Required

1. Screwdriver - flat blade type.
2. Feeler gage set.

Tests (Figure 7-8)

1. With the platen set at $.020 \pm .001$ in (0.5 ± 0.02 mm) from the face of the print head check for a clearance of .005 to .009 in. (0.125 to 0.225 mm) between the line finder and the platen.

Adjustments (Figure 7-8)

1. Loosen the two line finder mounting screws located on the top surface of the print head support casting. Adjust the line finder to achieve the required clearance between the line finder and the platen.

PRINT HEAD TO PRINT HEAD (125 L.P.M. ONLY)

Tools Required

1. Screwdriver - flat blade type.
2. 7 mm open end wrench.

Tests (Figure 7-8)

1. Vertical Alignment
 - a. Using the test print mode print several full lines of 132 characters. Visually check the vertical alignment of columns 67 through 132. The eye should not be able to see any vertical misalignment.
 - b. Visually look at the straight side of the "B"s printed by both heads. The straight sides of the "B"s should be parallel from line to line and perpendicular to the print line.

2. Horizontal Alignment

- a. Using the test print mode print several full lines of 132 characters. With a measuring ruler check the horizontal alignment (distance between the print wires of the two heads). This measurement should be $6.6 \pm .005$ in. (167.6 ± 0.13 mm) and should be measured between the leading edge of column 1 to the leading edge of column 67. This measurement should only be made on lines printed from left to right.
- b. If a measuring ruler is not available, the visual check method may be used. Visually check the distance between column 66 and 67. This distance should be the same as the distance between adjacent columns.

Adjustments (Figure 7-8)

1. Vertical Alignment

- a. Loosen the two screws that mount either one of the print heads to its support casting. Move the print head up or down so that the head mounting screws are centered in the vertical adjusting slots in the support casting. Make sure the line of print wires is perpendicular to the print line before tightening the screws.
- b. Using the test print mode, obtain a print sample.
- c. If the other print head is vertically misaligned, loosen its mounting screws and move it up or down as required. Make sure the line of print wires are perpendicular to the print line before tightening the screws.
- d. Run the test print program and readjust the print head if necessary until proper alignment is obtained.

2. Horizontal Alignment

- a. The distance between print heads may be adjusted by turning the adjustment eccentrics which are located at either end of the print head adjustment brace. The adjustment brace joins the two print head casting. Loosen the two belt retaining clamps that clamp the drive belt to the bottom of the print head support castings before loosening or adjusting the eccentrics. Loosen one or both of the eccentric locking screws and adjust the eccentrics to obtain the proper horizontal alignment between the two print heads.




FIGURE 7-8. PRINT HEAD, PLATEN, LINE FINDER, PAPER SLIDE AND OUT OF PAPER SWITCH ADJUSTMENTS.

- b. Tighten the two eccentric locking screws.
Tighten the belt retaining clamps on each print head support casting.
Enter the test print mode and recheck horizontal alignment.

OUT OF PAPER SWITCHES (FIGURE 7-8)

All printers are provided with an out of paper switch on the lower paper slide which is located to the rear of the platen. Units with the optional bottom form feed have an additional out of paper switch mounted on the rear paper shroud which is located under the platen.

Tools Required

1. Screwdriver - flat blade type.
2. Measuring ruler.

Tests (Figure 7-8)

1. The switches must indicate paper presence when the lever arms are prevented from passing through the slots in the upper paper slide and the front paper shroud. The lever arms must indicate the absence of paper when the levers extend through both slots in the upper and lower paper slides and the front and rear paper shrouds. The switches must activate in both directions within the angle "E" shown in figure 7-8.

Adjustments (Figure 7-8)

1. Adjust the out of paper switches and bend the lever arms to accomplish the functions indicated in the tests above.

CODE STRIP TO READER ALIGNMENT

Tools Required

1. Screwdriver - blade type

Tests (Figure 7-9)

1. While moving the print head and horizontal transducer board from one side of the printer to the other, make the following checks:
 - a. The code strip should be clean and free of smudges.
 - b. The code strip should be centered in the optical reader and parallel to its sides when the reader is in its right and left home positions.
 - c. The tension on the code strip should be such that the strip is straight for its entire length. Bend the finger of the bracket in or out for spring tension.
 - d. The alignment marks on the side of the optical reader should be centered in the top two rows of the windows on the code strip when the reader is in its right and left home positions.

Adjustments (Figure 7-9)

1. Loosen the three screws on either side of the print head structure that mount the right and left hand code strip brackets and adjust the code strip to the optical reader. Tighten the screws and retest.




FIGURE 7-8. CODE STRIP ALIGNMENT

ELECTRICAL TESTS AND ADJUSTMENTS

POWER SUPPLY BOARD ASSEMBLY

Tools Required

1. Multimeter.
2. Screwdriver flat blade type.
3. Use digital meter to check voltages.

Tests And Adjustments (Figure 7-10, 7-17 and 7-18).

1. With power supplied to the card, adjust potentiometer P1 to obtain $+36V \pm 0.5V$ on a multi-meter between connector J3 pin 1 and J3 pin 3 (voltage may also be checked at 1PC2-J1 between pin 9 and pin 10).
2. With power supplied to the card, adjust potentiometer P2 to obtain $+5V \pm 0.02V$ on a multi-meter between connector J1 pin 3 and J1 pin 4 (voltage may also be checked at 1PC2-J1 between pin 3 and pin 4).




FIGURE 7-10. POWER SUPPLY BOARD ASSEMBLY (CARD LOCATION 1PC1)

NEEDLE DRIVER BOARD ASSEMBLY

Tools Required

1. Multimeter.
2. Oscilloscope.
3. Screwdriver - flat blade type.

Tests And Adjustments (Figure 7-12 and 7-17).

1. With power applied, set potentiometer P1 to obtain $1.13 \pm .03V$ on a multimeter across resistor R20. Enter the printer into the test print mode.

NOTE

TO PREVENT THE PRINTHEAD NEEDLES FROM FIRING DURING ADJUSTMENT UNPLUG CONNECTOR J3 ON POWER SUPPLY BOARD.




FIGURE 7-12. NEEDLE DRIVER BOARD ASSEMBLY (CARD LOCATION 2PC1)




FIGURE 7-13. CONTROLLER AND HEAD LOGIC BOARD ASSEMBLY (CARD LOCATION 1PC2)

HORIZONTAL SERVO SYSTEM (PRINT HEAD MOTION)

Tools Required

1. Oscilloscope.
2. Screwdriver - flat blade type.

Test And Adjustments (Figure 7-13 and 7-17).

1. To prevent the print head needles from firing during adjustment steps 2 through 6, unplug connector J3 on the power supply board.
2. While in the Test Print Mode, trigger the oscilloscope on the zero-going edge of TP35 and observe wave from at TP49. Set potentiometer P6 to obtain a 30 ± 1 milli-seconds slope at the leading edge of waveform (Figure 7-14).




FIGURE 7-14. WAVEFORM (POT P6)

NOTES FOR STEPS 3 AND 4:

1. These adjustments are best made when the machine is warm after several hours of operation.
2. If excessive jitter is encountered, it may frequently be corrected by cleaning the code strip with a mild household window cleaner and a soft cloth. Alignment of the code strip to the horizontal transducer should be rechecked after this cleaning procedure. Slowing the head velocity slightly to reduce the jitter effect is acceptable provided the average period does not exceed 5.6 milliseconds; otherwise, replacement of the transducer and/or code strip may be required.
3. Head Speed should be set up by looking at the odd channel only, namely K4-2 of controller and head logic P. C. B:
Synchronize and measure the positive going edges of K4-2. Adjust head speed (Pot P4) and balance head speed (Pot P7) so that the average period T, is 10930 usec ± 180 µsec in both directions this corresponds to an average head speed of 18.3 ± .31PS (Figure 7-15).
- a. If a digital counter is not available, head speed should be set up while triggering on and observing character start pulses at TP 15 with a calibrated-sweep oscilloscope. Adjust head speed (P4) and balance head speed (P7) so that the average period (positive-going edge to positive going edge) is 5.5 milliseconds in both directions of head travel. Confirm that in no case does the period drop below 5.0 milliseconds with jitter.




FIGURE 7-15. HEAD SPEED (POT P4)

4. Potentiometer P5 is used for units with the Compressed Pitch option only. Set P5 to obtain 5.5 ± .01 milliseconds rep rate on the character start pulses when the head is moving from left to right in the Compressed Pitch Mode (viewed from front of machine). P7 does not need to be readjusted for compressed pitch. Trigger the oscilloscope and observe the pulses of the Character Start One Shot at TP15 (TP15 comes from 1PC2-H1 pin 5) while adjusting potentiometers.
5. While viewing the printout, adjust pot P2 until right to left and left to right printing of the character columns are aligned from one line of print to the next. This alignment should be examined on characters within the center of the print line and can be done more easily while in the 8 LPI mode. After standard width characters have been aligned as accurately as possible, the printer should be put on line and run in Elongated character mode (enable Elongated mode by activating dip switch 4, switch 1, as shown in Figure 4-10). The alignment of left to right and right to left printing is adjusted by the character start O/S (Pot P2) while in test print or printing all one character on line (e.g. h's). Standard characters should be aligned first, as accurately as possible near the center of the print line. However, slight misalign-

ment of up to .008" (.210 mm) is allowable, but only in one direction. The horizontal line-to-line misalignment for the entire line may not exceed .015" (Figure 7-17). Check alignment of Elongated Characters from one line of print to the next. If characters are out of alignment, adjust pot P2 until the Elongated characters are in line. Standard with characters should then be re-examined to insure that they are in line.

FACTORY ADJUSTMENT ONLY RTV
SEALED POTENTIOMETERS P1 AND P3

Potentiometer P1 was adjusted at the factory with a digital counter. Do not attempt to readjust this potentiometer in the field without a digital counter. To adjust the print head needle firing rate, connect a digital counter to TP28 to monitor the -MT3 signal. A counter mode must be selected which allows measurement of the rep rate of the -MT3 signal (negative edge to negative edge). While operating the printer in the Test Print Mode, adjust potentiometer P1 until the -MT3 rep rate (negative edge to negative edge) is set from 620 to 625 microseconds (Figure 7-16). The resolution of the digital counter used, must be ± 1 microsecond.

Potentiometer P3 was adjusted at the factory with a digital counter. Do not attempt to readjust this potentiometer in the field without a digital counter. Connect a digital counter to TP28 and adjust potentiometer P3 until the -MT3 pulse width (negative going edge to positive going edge) is set from 540 to 550 microseconds (Figure 7-16).




FIGURE 7-16. WAVEFORM (POT P1 AND P3)

VERTICAL SERVO SYSTEM (PAPER MOTION)

Tools Required

1. Oscilloscope
2. Screw driver - flat blade type.

Tests And Adjustments (Figure 7-13)

1. Trigger the oscilloscope from TP45 and observe wave form at TP46. On positive going edge of TP45 signal, set potentiometer P8 to obtain a ramp of 9 ± 1 milliseconds of wave form at TP46 (Figure 7-18).
2. Ground pin 13 of test plug TJ1 or pin 1 of chip R2 to logic ground to cause a constant paper slew (with paper removed) and observe STP pulses at TP30 (TP30 comes from 1PC2-H3 pin 13). Set pot P10 to obtain a rep rate of 22 ± 1 milliseconds for the 6 L. P. I. channel STP.




FIGURE 7-17. CHARACTER ALIGNMENT




FIGURE 7-18. WAVEFORM (POT P8)

POWER SUPPLY BOARD ASSEMBLY (CARD LOCATION 1PC2)	
POTENTIOMETER	POTENTIOMETER FUNCTION
1PC1-P1	USED TO ADJUST THE +36 VDC
1PC1-P2	USED TO ADJUST THE + 5 VDC
NEEDLE DRIVER BOARD ASSEMBLY (CARD LOCATION 2PC1)	
POTENTIOMETER	POTENTIOMETER FUNCTION
2PC1-P1	USED TO ADJUST THE CURRENT SUPPLIED THE PRINT HEAD SOLENOIDS
CONTROLLER AND HEAD LOGIC BOARD ASSEMBLY (CARD LOCATION 1PC2)	
POTENTIOMETER	POTENTIOMETER FUNCTION
1PC2-P1	USED TO SET THE HORIZONTAL DOT REP RATE (-MT3 REP RATE). ALSO AFFECTS CHARACTER WIDTH
1PC2-P2	USED TO ALIGN THE CHARACTER COLUMNS FROM ONE LINE OF PRINT TO THE NEXT.
1PC2-P3	USED TO ADJUST THE PRINT HEAD SOLENOID CURRENT PULSE WIDTH (-MT3).
1PC2-P4	USED TO ADJUST THE LEFT TO RIGHT HEAD VELOCITY. ALSO USED IN CONJUNCTION WITH POTENTIOMETER 1PC2-P7 TO CONTROL HEAD SPEED IN RIGHT TO LEFT DIRECTION.
1PC2-P5	USED TO ADJUST THE RIGHT TO LEFT AND LEFT TO RIGHT HEAD SPEED FOR COMPRESSED PITCH. (70 LPM PRINTERS ONLY).
1PC2-P6	USED TO ADJUST THE ACCELERATION AND DECELERATION VELOCITY OF THE PRINT HEADS HORIZONTAL MOTION.
1PC2-P7	USED TO EQUALIZE THE RIGHT TO LEFT AND LEFT TO RIGHT HEAD VELOCITIES.
1PC2-P8	USED TO ADJUST THE DECELERATION (STOPPING DISTANCE) OF VERTICAL PAPER MOTION.
1PC2-P9	NONEXISTENT
1PC2-P10	USED TO ADJUST THE SLEW VELOCITY OF PAPER MOTION

FIGURE 7-19. POTENTIOMETER FUNCTION CHART




FIGURE 7-20. POWER SUPPLY VOLTAGE TEST POINTS

PARTS REPLACEMENT

INTRODUCTION

This section includes disassembly and assembly procedures required for parts replacement in the field. This section should be used in conjunction with the printer Assembly Parts Lists and the Tests And Adjustments section in this manual.

PRINthead REPLACEMENT (FOR UNITS WITHOUT OPERATOR REPLACEABLE HEAD)

Tools Required

1. Screwdriver - flat blade type.

Removal (Figure 8-1)

1. Remove the ribbon cassette from the top of the print head support casting.
2. Remove the spring clip that clamps the print head harness connector to the print head flat cable connector and unplug the print head connector.
3. Remove the ty-rap that secures the print head wire harness to the print head support casting.
4. Remove the two screws and related mounting hardware that mount the print head to the print head support casting.
5. Remove the print head and print head shims. These shims may vary in quantity from printer to printer and head to head. Retain the shims removed with the print head so they may be used with that same print heads replacement.

Installation (Figure 8-1)

1. Mount the new print head to the print head support casting using the same shims and mounting hardware removed with the old print head.
2. Plug the new print head harness connector into the print head flat cable connector and replace the spring clip that clamps these two connectors together.
3. Secure the print head harness to the side of the print head support casting with a ty-rap. If a ty-rap is not available, lacing cord, electrical tape or insulated solid wire may be used. The print head harness should be secured so when the head is moving from side to side the harness does not touch the print head support shaft, print head drive belt or the right side of the print head structure.

4. Using the Mechanical Tests And Adjustments section of this manual check and adjust the print head to platen clearance.
5. If the unit is two headed 125 line per minute printer check the Mechanical Test And Adjustments section of this manual for necessary print head to print head tests and adjustments.
6. Replace the Ribbon Cassette.
7. Check ribbon drive cords for wear.

PRINthead REPLACEMENT (FOR UNITS WITH OPERATOR REPLACEABLE HEAD)

1. See Operating Procedures section of this manual for printhead replacement procedure.




FIGURE 8-1. PRINT HEAD REPLACEMENT

**PRINT HEAD FLAT CABLE ASSEMBLY
REPLACEMENT (70 AND 125 LPM)**

Tools Required

1. Screwdriver - flat blade type.
2. 5.5 mm open end or box wrench.

Removal (Figure 8-2)

1. Remove the spring clip that clamps the print head harness connector to the print head flat cable assembly connector (Figure 8-1). Unplug the print head harness connector.
2. Unplug the print head flat cable from the Needle Driver Board Assembly.
3. Remove the cable clamp that secures the print head flat cable to the bottom of the connector mounting plate.

4. Remove the two cable clamps that secure the print head flat cable to the top of the front plate.
5. Remove the two screws that mount the print head flat cable assembly connector to the connector mounting plate.
6. Remove the print head flat cable assembly from the printer.

Installation (Figure 8-2)

1. Using the old print head flat cable assembly as a pattern, bend and lightly crease the new print head flat cable to match the bend and creases in the old flat cables.
The connectors on either end of the print head flat cable are not the same and care should be taken to assure that the connectors on the old and new harnesses are matched before folding the new cable.

CAUTION

THESE CABLES SHOULD NOT BE CREASED MORE THAN ONCE IN THE SAME PLACE OR DAMAGE COULD OCCUR.




FIGURE 8-2. PRINT HEAD FLAT CABLE ASSEMBLY REPLACEMENT, AND HORIZONTAL TRANSDUCER BOARD AND CABLE ASSEMBLY REPLACEMENT.

2. Reversing the removal procedure, mount and clamp the new print head flat cable assembly in place. Assure that the flat cable grounding wire is connected to the mounting plate.

HORIZONTAL TRANSDUCER BOARD AND CABLE ASSEMBLY REPLACEMENT

Tools Required

1. Screwdriver - flat blade type.

Removal (Figure 8-2)

1. Unplug the horizontal transducer board cable connector from the Needle Driver Board Assembly.
2. Remove the cable clamp that secures the horizontal transducer board flat cable to the front plate.
3. Remove the two screws that mount the Horizontal Transducer Board Assembly to the horizontal transducer board mounting bracket.
4. Remove the Horizontal Transducer Board and Cable Assembly from the printer.

Installation (Figure 8-2)

1. Using the old Horizontal Transducer Board and Cable Assembly as a pattern, bend and lightly crease the new horizontal transducer board flat cable to match the bends and creases in the old flat cable.

CAUTION

THIS CABLE SHOULD NOT BE CREASED MORE THAN ONCE IN THE SAME PLACE OR DAMAGE COULD OCCUR.

2. Reversing the removal procedure, mount and clamp the new horizontal transducer board and cable assembly in place. Use Figure 8-2 to aid in cable routing.

CODE STRIP REPLACEMENT

Tools Required

1. Screwdriver - flat blade type.

Removal (Figure 8-3)

1. Loosen the code strip adjustable bracket locking screw that holds the adjustable code strip bracket in place.
2. Unhook the code strip spring from the code strip bracket (right side) and remove the spring from the code strip grommet hole.
3. Remove the code strip mounting screw that fastens the code strip to the adjustable code strip bracket.
4. Thread the code strip through the rectangular cut out in the code strip bracket (right side) and remove the code strip from the printer.

Installation (Figure 8-3)

1. Thread the new code strip through the rectangular cut out in the code strip bracket (right side). The code strip should be installed such that the code strip part number is to the right and can be read correctly when standing in front of the printer.
2. Mount the code strip to the adjustable code strip bracket with the code strip mounting screw. Do not tighten screw.
3. Hook one end of the code strip spring through the grommet hole in the code strip and the other end of the spring over the tab on the code strip bracket (right side).
4. While putting a slight tension on the code strip by pushing the adjustable code strip bracket to the left, tighten the code strip mounting screw. Care should be taken to assure that the tightening of this screw does not distort the code strip.
5. Adjust the code strip to the reader per the Mechanical Tests And Adjustments section of this manual.

CASSETTE DRIVE CORD ASSEMBLY REPLACEMENT
(70 AND 125 LPM)

Tools Required

1. Pliers - long nose or needle nose

Removal (Figure 8-4)

1. Disconnect both ends of the upper and lower cassette drive cord assemblies from the four cassette drive cord brackets and remove both drive cord and springs.

Replacement (Figure 8-4)

1. With the aid of Figure 8-4, install the new cassette drive cord assemblies. Care should be taken to assure that the ring terminals and springs are attached to the proper side of the printer as shown in Figure 8-4. Figure 8-4 shows the typical installation of drive cords on a two headed (125 L. P. M.) printer. Installation of drive cords on one head (70 L. P. M.) printers is identical except for the additional full turn of the cords around the right hand cassette drive pulleys.
2. With the ribbon cassettes installed move the heads from side to side to assure that there is ribbon motion and that the cords are tracking properly.




FIGURE 8-3. CODE STRIP REPLACEMENT




FIGURE 8-4. CASSETTE DRIVE CORD REPLACEMENT

PULLEY ASSEMBLY-LEFT HAND (DISASSEMBLY AND ASSEMBLY)

Tools Required

1. Screwdriver - flat blade type

Disassembly (Figure 8-5)

1. Loosen the screws that hold the pulley and the sleeve to the shaft.
2. Remove the shaft, thrust bearing, sleeve, pulley, belt and thrust bearing.

Assembly (Figure 8-5)

1. Insert the shaft through the left side of the pulley support casting, thrust bearing, sleeve, pulley, thrust bearing, belt and right side of the pulley support casting.
2. Adjust the pulley assembly and belt per the Tests And Adjustments section of this manual.

PULLEY ASSEMBLY-RIGHT HAND (DISASSEMBLY AND ASSEMBLY)

Tools Required

1. 2 mm hex key (Allen) wrench.
2. Screwdriver - flat blade type

Disassembly (Figure 8-6)

1. Loosen the screws that hold the two pulleys to the shaft.
2. Remove the shaft, thrust bearing, 30 tooth pulley, 44 tooth pulley, belts and the two thrust bearings.

Assembly (Figure 8-6)

1. Insert the shaft through the left side of the pulley support casting, thrust bearing, 30 tooth pulley, 44 tooth pulley, two thrust bearings, belts and right side of the pulley support casting.
2. Adjust the pulley assembly and belts per the Tests And Adjustments section of this manual.




FIGURE 8-5. PULLEY ASSEMBLY-LEFT HAND (DISASSEMBLY AND ASSEMBLY)




FIGURE 8-6. PULLEY ASSEMBLY-RIGHT HAND (DISASSEMBLY AND ASSEMBLY)

HORIZONTAL SERVO MOTOR REPLACEMENT

Tools Required

1. 7 mm open end or box wrench.
2. Screwdriver - flat blade type.
3. 2 mm hex key (Allen) wrench.

Removal (Figure 8-7)

1. Loosen the three screws that mount the horizontal servo motor mounting bracket to the right hand side of the print head structure. Slide the bracket and motor upward to relieve tension of the motor drive belt.
2. Remove the motor drive belt from the motor pulley.
3. Remove the screw that mounts the green ground wire to the rear of the motor.

4. Unplug the red and black wires from the motor terminals.
5. Remove the motor pulley from the motor shaft.
6. Remove the three screws that mount the motor to the motor mounting bracket and remove the motor.

Installation (Figure 8-7)

1. Mount the motor to the motor mounting bracket using the three mounting screws.
2. Mount the motor pulley on the motor shaft.
3. Mount the motor drive belt.
4. Connect the green ground wire to the rear of the motor with its mounting screw.
5. Adjust the tension on the print head motor drive belt and align the motor per the Test And Adjustment section of this manual.




FIGURE 8-7. HORIZONTAL SERVO MOTOR REPLACEMENT

6. Plug the red and black motor harness wires onto the motor terminals (connect either wire to either terminal at this time).
7. Move the print head/heads to the center of the printer. Enter the printer into test print while watching the print head/heads. If the head/heads move to home left and start printing, the red and black motor wires are connected correctly. If the head moves to the right and stops, power the printer off and reverse the red and black wire connections on the motor.

VERTICAL SERVO MOTOR REPLACEMENT

Tools Required

1. Screw driver - flat blade type.
 2. 1.5 mm hex key (Allen) wrench.
 3. Measuring ruler (15 cm metric or six inch 10-50 parts to the inch).
 4. 7 mm open end or box wrench.
- Removal (Figure 8-8)
1. Remove the code disk from the rear of the motor.
 2. Remove the oiler pad assembly.
 3. Remove the screw that mounts the green ground wire to the rear of the motor.
 4. While holding the motor with one hand remove the three screws that mount the motor mounting bracket to the left side of the paper motion assembly.
 5. Unplug the red and black wires from the motor terminals and remove the motor from the printer.
 6. Remove the worm gear from the motor shaft.
 7. Remove the three screws that mount the motor to the motor mounting bracket and remove the motor.




FIGURE 8-8. VERTICAL SERVO MOTOR REPLACEMENT

Installation (Figure 8-8)

1. Mount the motor to the motor mounting bracket using the three mounting screws.
2. Mount the worm gear to the motor shaft. See Figure 7-5 for gear mounting dimension.
3. While holding the motor in your hand plug the red and black motor harness wires on to the motor terminals (connect either wire to either terminal at this time).
4. Power the printer on and press the form feed or single space switch while looking at the worm gear end of the motor. The worm gear should be rotating counter clockwise, if the gear is rotating clockwise, power the printer off and reverse the red and black wire connection on the motor.
5. Mount the motor mounting bracket to the left side of the paper motion assembly with the three mounting screws.
6. Mount the green ground wire to the rear of the motor with its mounting screw.
7. Per the Tests And Adjustment section of this manual adjust for minimum back lash between the worm gear on the motor and the gear on the clutch assembly.
8. Mount the code disk to the rear of the motor. The vertical transducer board may need adjusting in order to mount the code disk.
9. Mount the oiler pad assembly. Make sure the felt pad is in contact with the worm gear.
10. Per the Tests And Adjustments section of this manual adjust the optical reader to the code disk.
11. If your printer has an Electronic Vertical Format Unit, synchronize the format reader and code disk per the Tests And Adjustments section of this manual.

TRACTOR ASSEMBLY REPLACEMENT

Tools Required

1. Screwdriver - flat blade type.
2. 10 mm open end or box wrench.
3. 1.5 mm hex key (Allen) wrench.

Removal (Figure 8-9)

1. Release both tractor clamp levers and slide both tractors to the center of the printer.
2. Remove the three screws that mount the bearing housing to the right hand format plate.
3. Slide the lower tractor shaft and bearing housing to the right until the clutch hub clears the clutch gear and is approximately 6 inches from the left hand format plate assembly.

4. Remove the bearing housing spacers.
5. Loosen the set screw and remove the clutch hub.
6. Slide the tractor spacer to the left and off the end of the lower tractor shaft.
7. Remove the two screws that mount the upper tractor shaft.
8. Lift the left end of the upper tractor shaft until it clears the left hand format plate assembly. Slide the shaft to the left and out of the two tractor assemblies.
9. The tractor assemblies may now be removed by sliding them to the left and off of the lower tractor shaft.

Installation (Figure 8-9)

1. Slide the tractor assemblies onto the lower tractor shaft.




FIGURE 8-9. TRACTOR ASSEMBLY REPLACEMENT

2. Lift the left end of the lower tractor shaft and the two tractor assemblies until there is clearance above the left hand format plate to install the upper tractor shaft into the upper holes in the tractors.
3. Slide the upper tractor shaft through the upper holes and clamps on the tractors.
4. Mount the upper tractor shaft between the right and left format plates with its two mounting screws.
5. Slide the tractor spacer over the end of the lower tractor shaft until it is flush with the end of the hex portion on the shaft.
6. Mount the clutch hub on the end of the lower tractor shaft with its set screw.
7. Install the bearing housing spacers between the bearing housing and the right hand format plate.
8. Slide the lower tractor shaft to the left. Slide the hole in the end of the tractor shaft over the clutch shaft until the clutch hub and clutch gear are engaged.
9. Mount the bearing housing and bearing housing spacers to the right hand format plate with the three mounting screws.

TRACTOR FLAP REPLACEMENT

Tools Required

1. Screwdriver - flat blade type.
2. Pliers - long nose or needle nose

Removal (Figure 8-10)

1. Remove the tractor flap spring.
2. Remove the upper retaining ring from the tractor flap hinge pin.
3. Slide the hinge pin down slightly and remove the lower retaining ring from the hinge pin.
4. Slide the hinge pin upwards and remove it from the tractor flap and body bracket assembly.
5. Remove the tractor flap.

Installation (Figure 8-10)

1. Reverse the removal procedures and install the new tractor flap.
2. Adjust the tractor flap per the Tests And Adjustments section of this manual.

TRACTOR TIMING BELT REPLACEMENT

Tools Required

1. Screwdriver - flat blade type

Removal (Figure 8-10)

1. Remove the tractor assembly per Tractors Assembly Replacement instructions found in this section of the manual.
2. Remove the four screws that mount the body bracket assembly to the tractor body and remove the body bracket assembly.
3. Remove the drive pulleys and tractor timing belt.

Installation (Figure 8-10)

1. Mount the drive pulleys and tractor timing belt to the tractor body.
2. Mount the body bracket assembly to the tractor with the four mounting screws.
3. Install the tractor assembly per Tractor Assembly Replacement instructions found in this section of the manual.
4. Adjust the tractor flap per the Tests And Adjustments section of this manual.

CLUTCH ASSEMBLY REPLACEMENT

Tools Required

1. Screwdriver - flat blade type.

Removal (Figure 8-11)

1. Release both tractor clamp levers and slide both tractors to the center of the printer.




FIGURE 8-10. TRACTOR FLAP AND TIMING BELT REPLACEMENT

2. Remove the three screws that mount the bearing housing to the right hand format plate (Figure 8-9).
3. Slide the lower tractor shaft and bearing housing to the right until the clutch hub clears the clutch gear and is approximately 6 inches from the left hand format plate assembly (Figure 8-9).
4. Remove the bearing housing spacers (Figure 8-9).
5. Remove the oiler pad assembly.
6. Remove the four screws that mount the two clutch lever brackets.
7. Remove the two clutch lever brackets, clutch lever, two plastic spacers and roller spacer.
8. Remove the clutch gear and clutch lever spring.
9. Remove the three screws that mount the clutch assembly to the left hand format plate.
10. Remove the clutch assembly. It may be necessary to loosen the vertical servo motor mounting bracket and slide the bracket and motor upward in order to remove the clutch assembly.

Installation (Figure 8-11)

1. Reversing the removal procedures, install the new clutch assembly. Use Figure 8-11 to aid with the installation.
2. Adjust the vertical motor worm gear and optical reader per the Tests And Adjustments section of this manual.
3. If your printer has an Electronic Vertical Format Unit, synchronize the format reader and code disk per the Tests And Adjustments section of this manual.




FIGURE 8-11. CLUTCH ASSEMBLY REPLACEMENT

CONTROL PANEL LENS AND LAMP REPLACEMENT

Tools Required

1. Screwdriver - flat blade type.

Removal (Figure 8-12)

1. Remove power to the printer at the power source.
2. Remove the lens by placing a screwdriver in the screwdriver prying groove on the top or bottom edge of the lens and pry up.
3. Place a screwdriver under the tab on the lamp puller and pull it out until the lamp is disengaged from it's socket.
4. Remove the lamp.

Installation (Figure 8-12)

1. Push down on the lamp puller tab until it is seated.
2. Place a new lamp in the switch and lamp housing socket so that the lamp contacts are in line with the right and left socket contacts.
3. Using your little finger push down on the top of the lamp until it is seated in the lamp housing socket.




FIGURE 8-12. CONTROL PANEL LENS AND LAMP REPLACEMENT

4. Place the lens on top of the switch and lamp housing socket and push down on the lens until it snaps in place.

REAR FAN REPLACEMENT

Tools Required

1. Screwdriver - flat blade type.
2. 7 mm open end or box wrench.

Removal (Figure 8-13)

1. Remove the two screws that mount the rear fan duct to the rear fan. Remove the fan duct.
2. Remove the four screws that mount the rear fan to the left side panel. Remove the fan.
3. Unplug the two wires from the fan.

Installation (Figure 8-13)

1. Reversing the removal procedures, install the new fan.




FIGURE 8-13. FRONT AND REAR FAN REPLACEMENT

FRONT FAN REPLACEMENT

Tools Required

1. Screwdriver - flat blade type.
2. 7 mm open end or box wrench.

Removal (Figure 8-13)

1. Remove the four screws, two short spacers and two long spacers that mount the front fan duct to the front fan. Remove the front fan duct.
2. Remove the four screws that mount the front fan and screen to the base plate. Remove the fan and screen.
3. Trace and remove the white and black wires that run from the fan to terminal block 2TB01, which is located on the right side of the print head structure.
4. Remove the terminal block cover and disconnect the white fan wire from 2TB01-2 and the black fan wire from 2TB01-4.

Installation (Figure 8-13)

1. Reversing the removal procedures, install the new fan and harness assembly.

PLATEN ADVANCE SHAFT ASSEMBLY REPLACEMENT

Tools Required

1. 2 mm hex key (Allen) wrench.
2. Screwdriver - flat blade type.

Removal (Figure 8-14)

1. Remove the three mounting screws that mount the upper paper slide to the platen assembly and

remove the paper slide. The out of paper switch arm on the lower paper slide should be held in the down position to prevent damage to the arm when removing the upper paper slide,

2. Loosen the allen set screw in the left hand platen adjustment eccentric and remove the eccentric.
3. Remove the platen advance shaft retaining ring from the platen advance shaft.
4. Withdraw and remove the platen advance shaft assembly from the right side of the printer. Remove the flat washer from the shaft as it is removed.

Installation (Figure 8-14)

1. Reversing the removal procedures, install the platen advance shaft assembly.

PLATEN ASSEMBLY REPLACEMENT

Tools Required

1. Screwdriver - flat blade type.
2. 7 mm open end wrench.

Removal (Figure 8-14)

1. Remove the three mounting screws that mount the upper paper slide to the platen assembly and remove the paper slide. The out of paper switch arm on the lower paper slide should be held in the down position to prevent damage to the arm when removing the upper paper slide.
2. Remove the left and right platen springs.
3. Remove the rear mounting screw on both the left hand and right hand platen advance supports.
4. Remove the screw that mounts the platen ground wire to the platen assembly.
5. Remove the front mounting screw, two nuts and two lock washers that mount both the left hand and right hand platen advance supports to the platen assembly.

Remove both platen advance supports.

6. Remove the platen assembly from the printer.

Installation (Figure 8-14)

1. Reversing the removal procedures, install the platen assembly.
2. Adjust the platen and print head per the Tests And Adjustments section of this manual.

HEAD SUPPORT SHAFTS AND PRINT HEAD SUPPORT CASTING REPLACEMENT

Tools Required

1. Screwdriver - flat blade type

Removal (Figure 8-15)

1. Remove the ribbon cassettes.
2. Remove the code strip.
3. Remove the cassette drive cords.
4. Remove the belt retainer clamps.
5. Remove the head support casting connecting rod and eccentrics (on 125 L. P. M. units only).
6. Unplug the head connectors at the print head connector mounting plate.
7. Remove the two screws that mount the print head flat cable connectors to the print head connector mounting plates.
8. Remove the cable clamps that secure the print head flat cable to the bottom of the print head connector mounting plate.
9. Remove the two screws that mount the horizontal transducer board to the bottom of the print head.
10. Remove the screw that mounts the front print head support shaft to the left side of the print head structure.




FIGURE 8-14. PLATEN ADVANCE SHAFT ASSEMBLY REPLACEMENT AND PLATEN ASSEMBLY REPLACEMENT




FIGURE 8-15: HEAD SUPPORT SHAFTS AND PRINT HEAD SUPPORT CASTING REPLACEMENT

11. Slide the front print head support shaft to the right through the head support bearings and out the right side of the print head structure. Remove the head support bearings as the shaft is withdrawn from them.
12. Remove the screw in either end of the rear print head support shaft that mount it to the right and left sides of the print head structure.
13. Slide the rear print head support shaft to the right through the left hand head stop bumper, through the print head support castings, through the right hand head stop bumper and out the right side of the print head structure. Remove the print head


support castings and bumpers as the shaft is withdrawn from them.

Installation (Figure 8-15)

1. Reversing the removal procedures, install the print head support castings and support shafts.
2. Adjust the code strip, print heads and platen as necessary per the tests and adjustments section of this manual.

DIAGRAMS

SHEET NO.	REV	CROSS REF. NO.	MODULE LOCATION	TITLE
1	F			CONTENTS SHEET
2	A			KEY TO DIAGRAMS-PARTS LOCATOR
3	A			KEY TO DIAGRAMS-PCB COMPONENT LOCATIONS
4	A			KEY TO DIAGRAMS-PCB COMPONENT LOCATIONS
5	A			SPECIAL NOMENCLATURE
6	C			GENERAL NOTES & ELECTRICAL ADJUSTMENTS
7	A	WD01		WIRING DIAGRAM-CONNECTOR LOCATIONS
8	G	WD02		WIRING DIAGRAM-AC POWER
9	A	WD03		WIRING DIAGRAM-PRINT HEADS,CONTROL PANEL
10	B	WD04		WIRING DIAGRAM-NEEDLE DRIVER,HORIZ XDCR
11	A	BD01		BLOCK DIAGRAM-LOGIC
12	A	BD02		BLOCK DIAGRAM-SERVOS FUNCTIONAL
13	A	SD03		BLOCK DIAGRAM-SERVO MOTORS CONTROL LOOP
14	A	TD01		TIMING DIAGRAM-SERVO WAVEFORMS
15	A	0101	1PC1	POWER SUPPLY PCB -+36V -36V
16	A	0102	1PC1	POWER SUPPLY PCB- +5V +12V
17	F	0103	1PC1	POWER SUPPLY PCB- -12V -5V SERVO DRIVERS
18	B	0200	1PC2	PRINT HEAD & CONTROLLER JUMPERS
19	E	0201	1PC2	CONTROLLER & HEAD LOGIC PCB-NEEDLE DRIVER STROBES
20	B	0202	1PC2	CONTROLLER & HEAD LOGIC PCB-HEAD MOTION CONTROL
21	A	0203	1PC2	CONTROLLER & HEAD LOGIC PCB-HEAD MOTION CONTROL
22	B	0204	1PC2	CONTROLLER & HEAD LOGIC PCB-HEAD MOTION LINEAR AMPS
23	A	0205	1PC2	CONTROLLER & HEAD LOGIC PCB-PAPER MOTION
24	A	0206	1PC2	CONTROLLER & HEAD LOGIC PCB-PAPER MOTION
25	A	0207	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
26	A	0208	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
27	A	0209	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
28	A	0210	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
29	A	0211	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
30	A	0212	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
31	A	0213	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
32	S	0214	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
33	A	0215	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
34	A	0216	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
35	B	0217	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
36	A	0218	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
37	G	0219	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
38	E	0220	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
39	A	0221	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
40	A	0222	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
41	C	0223	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
42	A	0224	1PC2	CONTROLLER & HEAD LOGIC PCB-MICRO PROCESSOR
43	A	0401	4PC1	CONTROL PANEL PCB
44	F	0501	2PC1	NEEDLE DRIVER PCB
45	A	0502	2PC1	NEEDLE DRIVER PCB
46	A	0601	2PC2	HORIZONTAL TRANSDUCER PCB
47	A	0701	5PC1	VERTICAL TRANSDUCER & OPTION SELECT PCB
48				
49				
50				



PARTS ABBREVIATION CODE

- AD • ASSEMBLY
- BD • MOTOR OR FAN
- CB • CIRCUIT BREAKER
- JD • CONNECTOR
- LF • LINE FILTER
- PC • PRINTED CIRCUIT BOARD
- SD • SWITCH
- TB • TERMINAL BLOCK
- WD • WIRE OR CABLE

AREA 1 • CARD RACK (3 CARDS)

- AREA 2 • MAIN STRUCTURE
- AREA 3 • BASE PLATE
- AREA 4 • CONTROL PANEL
- AREA 5 • PAPER MOTION STRUCTURE

2501 & 2502 • OUT OF PAPER SWITCHES
(NOT SHOWN)

4509 • INTERLOCK SWITCH
(NOT SHOWN)

PARTS IDENTIFIER CODE


PARTS ARE IDENTIFIED BY A FOUR DIGIT ALPHANUMERIC CODE.

THIS DIGIT INDICATES THE AREA WHERE THE PART IS LOCATED

THESE DIGITS ARE THE PARTS ABBREVIATION CODE

THIS DIGIT INDICATES THE NUMBER OF PARTS IN THE AREA

MACHINE AREA AND PARTS LOCATOR		DATA BASE	DWG NO	REV
		A	C	A
		PR70/125	SHEET 2	



PHYSICAL LOCATION CODES

THE DRAWINGS TO THE LEFT DEPICT A TYPICAL STANDARD PC BOARD USED IN THIS EQUIPMENT. SEE INDIVIDUAL ASSEMBLY DRAWINGS FOR COMPLETE COMPONENT LOCATION INFORMATION.

THE 2 DIGIT LOCATION CODE SHOWN INSIDE THE COMPONENT OUTLINES IS USED INSIDE THE SYMBOL OUTLINE ON THE LOGIC SHEETS, THE PACKAGE LOCATION CODE, WHERE APPLICABLE, FOLLOWS A COORDINATE NUMBERING SYSTEM.

CONNECTORS ALL WIRING CONNECTIONS TO THE BOARDS ARE DESIGNATED "J", IF CONNECTION IS MADE BY A PLUG & SOCKET CONNECTION OR WIRED DIRECTLY TO THE BOARD.

TEST POINTS ALL TEST POINTS ARE LOCATED ALONG THE EDGE OF THE PC BOARDS. TEST POINTS ARE SHOWN ON THE LOGIC SHEET AS AN OPEN CIRCLE CONNECTED TO SIGNAL LINE.


KEY TO DIAGRAMS- PCB COMPONENT LOCATIONS		DATA BASE A	C	DWG NO	REV A
		PM 28/125	SMU 3		

CONTROLLER &
PRINT HEAD ELECTRONICS
0200-0224


IPC1

IPC2

POWER SUPPLY
9101-0102



DATA BASE	DWG. NO.	REV.
A	C	A
PH 70/125		SHEET 4



SPECIAL NOMENCLATURE

ABBREVIATION	DEFINITION
CHAR ST 1 *	CHARACTER START 1
CHAR ST 2 *	CHARACTER START 2
CHAR ST 3 *	CHARACTER START 3
CHAR ST 4 *	CHARACTER START 4
CHPRS PITCH *	COMPRESSED PITCH SELECT
HD RDY *	HEAD READY
H BD *	HORIZONTAL BASE DRIVE (HEAD MOTION SERVO)
H IFB *	HORIZONTAL CURRENT FEEDBACK
H VFB *	HORIZONTAL VOLTAGE FEEDBACK
INTLK *	INTERLOCK SWITCH
I SENSE *	CURRENT SENSE
MOV R-L *	MOVE HEAD FROM RIGHT TO LEFT
MOVE L-R *	MOVE HEAD FROM LEFT TO RIGHT
MTR *	VERTICAL MOTOR (PAPER MOTION SERVO)
NDL ENAB *	NEEDLE ENABLE
P.G. *	POWER SUPPLY GROUND
SEL *	SELECT
SHOT DN *	36V SUPPLY SHUT DOWN
V REF *	VOLTAGE REFERENCE
V BD *	VERTICAL BASE DRIVE (PAPER MOTION SERVO)
V VFB *	VERTICAL VOLTAGE FEEDBACK
V IFB *	VERTICAL CURRENT FEEDBACK
6 LPI STP *	6 LINES PER INCH STOP THE PAPER
6 LPI SEL *	6 LINES PER INCH SELECT
10 CPI SEL *	10 CHARACTERS PER INCH SELECT
*18V REC AC *	*18V RECTIFIED AC REFERENCE

DATA BASE		DWG NO	REV
A	C		A
PPH 7/0/125		SMU 5	

SPECIAL NOMENCLATURE

GENERAL NOTES

1. DUE TO THE LARGE NUMBER OF CIRCUITS ON EACH BOARD, MORE THAN ONE LOGIC SHEET IS USUALLY REQUIRED FOR EACH BOARD. THE BOARD NAME, MODULE LOCATION AND CROSS REFERENCE NUMBERS APPEAR ON EACH SHEET, EACH SYMBOL IN THE DIAGRAMS REFLECTS THE LOGIC FUNCTION PERFORMED, COMPONENT TYPE OR ELEMENT IDENTIFIER AND LOCATION OF ALL OR PART OF AN IC PACKAGE OR DISCRETE COMPONENT(S), FOR DETAILED INFORMATION ON SYMBOLS AND PACKAGE TYPE REFER TO CIRCUIT DESCRIPTIONS IN THE KEY TO THE LOGIC SYMBOLS-CPI DWG NO. 55307500-MANUAL NO. 95300100.

2. OFFSHEET REFERENCES TO IAO3 INDICATE CONNECTIONS TO THE OPTIONAL INTERFACE ASSEMBLY-SEE INTERFACE LOGIC SET(S).

3. LOGIC LEVELS

HIGH OUTPUT VOLTAGE=5.5V MAX TO 2.4V MIN
LOW OUTPUT VOLTAGE=0.4V MAX TO 0V MIN
HIGH INPUT VOLTAGE=5.5V MAX TO 2V MIN
LOW INPUT VOLTAGE=0.8V MAX TO 0V MIN

4. POWER SUPPLY CONNECTIONS

ALL STANDARD IC PACKAGES HAVE THE FOLLOWING POWER SUPPLY CONNECTIONS WHICH ARE NOT SHOWN AS PART OF THE LOGIC SYMBOL.
14 PIN DEVICE -GROUND ON PIN 7 AND +5V ON PIN 14
16 PIN DEVICE -GROUND ON PIN 8 AND +5V ON PIN 16

ALL NON STANDARD IC PACKAGES WILL HAVE THE NON STANDARD GROUND AND SUPPLY CONNECTIONS SHOWN AS PART OF THE LOGIC SYMBOL.

5. REPETITIVE DETAILS

ALL LOGIC PRINTED CIRCUIT CARDS HAVE FILTER CAPACITORS GENERALLY LOCATED CLOSE TO THE INPUT CONNECTOR/FILTER CAPACITORS FROM 33UF TO 150UF ARE USED DEPENDING ON THE BOARD.
HIGH FREQUENCY FILTER CAPACITORS (.01UF) ARE LOCATED BETWEEN USED IC LOCATIONS (1 CAP PER 3 IC'S). THESE CAPACITORS ARE NOT SHOWN ON LOGIC DRAWINGS.

ELECTRICAL ADJUSTMENTS

- 1. POWER SUPPLY BOARD (1FC1)
1.1 ADJUST POT P1 TO OBTAIN +36V ± 0.5V BETWEEN CONNECTOR J3- PINS 1 & 3
- 1.2 ADJUST POT P2 TO OBTAIN +5V ± 0.02V BETWEEN CONNECTOR J1- PINS 3 & 4

- 2. SERVO SYSTEMS (1FC2) -HORIZONTAL DRIVE (PRINT HEAD MOTION)
2.1 TRIGGER OSCILLOSCOPE FROM TP35 AND OBSERVE WAVEFORM FROM TP48. SET POT P6 TO OBTAIN A 30 ± 1 MILLISEC SLOPE AT LEADING EDGE OF WAVEFORM.
- 2.2 TRIGGER SCOPE AND OBSERVE PULSES OF CHARACTER START TRANSDUCER AT TP15.

2.3 ON THE CHARACTER START PULSES WHEN THE HEADS ARE MOVING LEFT TO RIGHT (VIEWED FROM FRONT OF MACHINE)
SET P4 TO OBTAIN 5.5 ± 0.1 MILLISEC REP RATE

- 2.5 SET P7 TO OBTAIN EQUAL REP RATE TIME IN STEP 2.3 ABOVE FOR RIGHT TO LEFT MOTION-NOTE-- P4 AFFECTS HEAD SPEED IN BOTH DIRECTIONS OF TRAVEL.P7 AFFECTS ONLY ONE DIRECTION OF TRAVEL AND IS USED TO EQUALIZE VELOCITIES.

2.6 POT P5 IS USED IN THE SAME MANNER AS POT P4 FOR MACHINES WITH COMPRESSED PITCH OPTIONS.POT P7 DOES NOT NEED TO BE RE-ADJUSTED FOR THIS PURPOSE.

- 2.7 A DIGITAL COUNTER IS REQUIRED TO ADJUST THE NEEDLE FIRING RATE. CONNECT COUNTER TO TP28 TO MONITOR THE -M3 SIGNAL. COUNTER MODE MUST BE SELECTED WHICH ALLOWS MEASUREMENT OF THE REP RATE OF THE -M3 SIGNAL. (NEG EDGE TO NEG EDGE). WHILE OPERATING IN TEST PR. ADJUST POT P1 UNTIL REP RATE IS 620/625 USEC COUNTER RESOLUTION MUST BE 1/USEC.
ON TP28 ALSO ADJUST POT P3 UNTIL THE -M3 PULSE WIDTH (NEGATIVE GOING EDGE TO POSITIVE GOING EDGE) IS SET TO FROM 540 TO 550 USEC.

2.8 TRIGGER SCOPE AND OBSERVE PULSES ON TP15 WHILE IN TEST PRINT OR PRINTING ALL ONE CHARACTER ON LINE. ADJUST POT P2 UNTIL RIGHT TO LEFT AND LEFT TO RIGHT PRINTING ARE ALIGNED. TYPICAL *CHAR START D/S PULSE WIDTH (POSITIVE TO NEGATIVE EDGE) IS 1.2 MILLISEC.


- 3. VERTICAL SYSTEM (PAPER MOTION)
3.1 TRIGGER SCOPE FROM TP45 AND OBSERVE WAVEFORM AT TP48.
3.2 ON POSITIVE GOING EDGE OF TP45 SIGNAL SET P9 TO OBTAIN A RAMP OF 9 ± 1 MILLISEC OF WAVEFORM AT TP46

3.3 GROUND PIN 13 OF TEST PLUG T/J OR PIN 1 OF CHIP R2 TO LOGIC GROUND TO CAUSE A CONSTANT PAPER SLEW AND OBSERVE STP PULSES AT TP(30). SET POT P10 TO OBTAIN A REP RATE OF 22 ± 1 MILLISEC FOR THE 6 LPI CHANNEL STP.

- 4. NEEDLE DRIVER
4.1 SET POT P1 ON NEEDLE DRIVER PCB TO OBTAIN 1.15V ± 0.03V MEASURED ACROSS RESISTOR R20.


GENERAL NOTES & ELECTRICAL ADJUSTMENTS

DATA BASE	A	C	DWG NO
REV	C		
	PH 7/8/125	SHEET 6	




DATA BASE		DMC NO	REV
A	C		H
PHI 70/125		SHEET 7	CONTR. REF. NO. HD01

LOC. CROSS REF. NO. HD01



LOC.	C	DWG NO.	1
CROSS REF NO. W002	PH 70	SHEET 8	1


LOC.	C	DWG NO.	1
CROSS REF NO. W002	PH 70	SHEET 8	1




REV	A
REVISED	WD03
SHEET	9
PHI	70/125
DATA BASE	A C
DWG NO	

WIRING DIAGRAM-
PRINT HD-CNTRL PNL
AND VERT TRANSDUCER


LOC.
CROSS
REF. NO. WD03



- SELECT NEEDLE 1, L, HEAD
- SELECT 2L
- SELECT 3L
- SELECT 4L
- SELECT 5L
- SELECT 6L
- NO STB
- SELECT 7L
- N.C.
- SELECT 8L
- N.C.
- SELECT 9L
- +5V
- +5V
- LOGIC GND
- LOGIC GND
- CHAR START 4
- LOGIC GND
- CHAR START 3
- LOGIC GND
- CHAR START 2
- LOGIC GND
- CHAR START 1
- LOGIC GND
- LOGIC GND
- 1 SENSE
- SELECT NEEDLE 2, R, HEAD
- SELECT 2R
- SELECT 3R
- SELECT 4R
- SELECT 5R
- SELECT 6R
- SELECT 7R
- SELECT 8R
- SELECT 9R
- SELECT 10R
- SELECT 11R
- SELECT 12R
- SELECT 13R
- SELECT 14R
- SELECT 15R
- SELECT 16R
- SELECT 17R
- SELECT 18R
- SELECT 19R
- SELECT 20R
- SELECT 21R
- SELECT 22R
- SELECT 23R
- SELECT 24R
- SELECT 25R
- SELECT 26R
- SELECT 27R
- SELECT 28R
- SELECT 29R
- SELECT 30R
- SELECT 31R
- SELECT 32R
- SELECT 33R
- SELECT 34R



LOC.
CROSS
REF NO. B001




- NOTES--
- 1 SINGLE HEAD MACHINE.
 - 2 COMPRESSED PITCH OPTION FOR SINGLE HEAD MACHINE ONLY.

DATA BASE	BWG NO	REV
-A	C	A
PH 70/125	SHEET 12	CROSS REF NO B002

LOC.
CROSS
REF NO. B002


CHANG BY 1/72



BLOCK DIAGRAM SERVO MOTORS CONTROL LOOP		DATA BASE	DWG NO	REV
		A	C	A
		PH 78/135	SM11 13	CROSS REF NO 8003

LOC.
CROSS
REF NO. 8003

4 3 2 1



LOC. CROSS REF NO. TD01

DATA BASE A C DWG NO. REV A

PH 78/128 SHEET 14 CROSS REF NO. TD01

REV A

1 2 3 4

- NOTES
- HEAD RECYCLE TIME IS DEPENDENT ON WHETHER DATA IS AVAILABLE TO BE PRINTED. MINIMUM TIME IS 55 MSEC.
 - AVAILABLE ON SINGLE HEAD MACHINE ONLY.
 - AMPLITUDE OF WAVEFORM DEPENDENT ON PARTICULAR OPTION OF MACHINE.
 - HEAD MOTION TIME DEPENDENT ON MACHINE OPTION-- 425 MSEC TYP FOR 2 HEAD MACHINE 60 MSEC TO 800 MSEC TYP FOR SINGLE HEAD MACHINE.

LOCATION


IPC1

POWER SUPPLY BOARD


BOARD NUMBER
See Chart Below

PAGE NO.
9-16 A-D/E

IPC1 POWER SUPPLY ASSEMBLY	MODEL	I/O HARNESS 44571709	I/O SUPPLY 44571994
95419903	PM 125	-	-
95419904	PM 125	X	-
95419905	PM 125	X	X
95419953	PM 70	-	-
95419954	PM 70	X	-
95419955	PM 70	X	X




POWER SUPPLY BOARD 95419903 / 04 / 05 / 53 / 54 and 55



- 1 .05 OHM 8W IN 2 HEAD MACHINE
.10 OHM 5W IN 1 HEAD MACHINE
- 2 DO NOT SHORT OUT R10 WHILE UNDER POWER AND LOAD


- (A) +36V
- (B) -36V
- (C) +20V
- * D2, R3, R5, CL2, CR9 NOT USED IN ONE HEAD MACHINE.
- * JUMPER "A" NOT USED IN TWO HEAD MACHINE.

DATA BASE	LOC IPC1	UNW. NO	REV
A	C	15	A
POWER SUPPLY - +36V -36V			CROSS REF NO. 0101



DATA BASE	DWG NO	REV
A	C	A
LOC 1PC1		CROSS REF NO 0102
POWER SUPPLY -		SHEET 16
+5V		
+12V		

LOC. 1PC1
CROSS
REF NO. 0102



DATA BASE		DWG. NO.	
A	C	A	
LOC IPC1		SHEET 17	
CROSS REF. NO. 0103		REV. 0103	

POWER SUPPLY -
-12V -5V AND
SERVO DRIVERS

LOC. IPC1
CROSS REF. NO. 0103

- LAST "O" USED-C
- LAST "CL" USED-3
- LAST "VR" USED-5
- LAST "C" USED-44
- LAST "CR" USED-37
- LAST "Q" USED 10
- LAST "R" USED-82
- LAST "P" USED-5
- LAST "SCR" USED-U
- LAST "P" USED-2


LOCATION

IPC2

CONTROLLER AND HEAD LOGIC BOARD

BOARD NUMBER
95440196/95440195

PAGE NO.
9-18 A-Z/AA



CONTROLLER AND HEAD LOGIC BOARD 95440196/95440195


CROSS REF NUMBER	LOC. 1PC2	LOC. 1PC2	CROSS REF NO. 0200
0208	J1	X	HOLD
0207	J2	X	BEL BUS
0223	J3	X	SOFTWARE CD (F)
0223	J4	X	OP (OPERATOR CONF)
0223	J5	X	OP GND
0223	J6	X	OP GND
0222	J7	X	SINGLE HEAD MACHINE
0222	J8	X	TWO HEAD MACHINE
0222	J8	X	CHAR ST 3
0222	J10	X	PAPER RUNAWAY
0222	J11	X	DUAL PITCH
0222	J12	X	BLANK CODE 7
0205	J13	X	BLANK CODE 8
0205	J14	X	BLANK CODE 5
0221	SW1-1	X	BLANK CODE 3
0221	SW1-2	X	BLANK CODE 2
0221	SW1-3	X	BLANK CODE 1
0221	SW1-4	X	BLANK CODE 0
0221	SW1-5	X	TEST PRINT BIT 7
0221	SW1-6	X	TEST PRINT BIT 6
0221	SW1-7	X	TEST PRINT BIT 5
0221	SW1-8	X	TEST PRINT BIT 4
0221	SW1-9	X	TEST PRINT BIT 3
0221	SW1-10	X	TEST PRINT BIT 2
0218	SH2-1	X	TEST PRINT BIT 1
0218	SH2-2	X	TEST PRINT BIT 0
0218	SH2-3	X	SEC DEL SEC
0218	SH2-4	X	EN DA
0218	SH2-5	X	OFF
0218	SH2-6	X	RECAL
0218	SH2-7	X	BB COL
0218	SH2-8	X	DB. SP
0215	SH4-1	X	AUTCRH
0215	SH4-2	X	DJUN DATA BUS
0215	SH4-3	X	CS DATA BUS
0215	SH4-5	X	START/STOP (STD MACH)
0215	SH4-6	X	START/STOP (LW/INT FAX)
0219	J15	X	
0219	J16	X	

NOTE.
SEE APPLICABLE ASSY DWG FOR POSITION OF SWITCHES
AND FOR JUMPERS ASSEMBLED.

PRINT HEAD & CONT. JUMPERS

CROSS REF NO.	REV
DATA BASE A	B
LOC. 1PC2	C
SHEET 18	
CROSS REF NO. 0200	


LOC. 1PC2
CROSS REF NO. 0200



DATA BASE	A	C	DWG NO	REV	B
CROSS REF NO	LOC. 1PC2		SHEET	18	CROSS REF NO 0201


REFERENCE DESIGNATORS:
 01-25
 P1-10
 CR1-15
 C1-60
 R1-160
 (A) (EX)

LOC. 1PC2
 CROSS REF NO. 0201




DATA BASE	A	C	DWG NO	REV	B
LOC. 1PC2	CONTROLLER/HD LOGIC (HEAD MOTION CONTROL)			CROSS REF NO	0202
LOC. 1PC2				SHEET	20

LOC. :PC2
 CROSS REF. NO. 0202




- 1 JUMPER J14 IS INSERTED WHEN OPTION 2 IS NOT SELECTED
- 2 ALL COMPONENTS IN DASHED BOX ARE INSERTED FOR THIS OPTION.
- 3 ADJUST FOR L-R MOTION VEL. (VIEWING FROM OPERATOR'S SIDE OF MACHINE).
- 4 ADJUST FOR RAMP DECELL TIME. SYNC FROM TP31.

DATA BASE	A	C	REV	A
CROSS REF NO.	LOC 1PC2		SHEET	21
CONTROLLER/HD LOGIC (HEAD MOTION CONTROL)				
CROSS REF NO. 203				




1 R → L • L → R DESIGNATION IS REFERENCING HEAD DIRECTION MOTION LOOKING FROM THE FRONT (OPERATOR'S SIDE) OF THE MACHINE



LOC. IPC2
CROSS
REF NO. 0205

DATA BASE
A C
LOC IPC2
SHEET 23
REV 'A'
REV NO
REF NO. 0205

- 1 THESE COMPONENTS ARE INSERTED ONLY FOR A SPECIAL FUNCTION OPTION
- 2 THESE COMPONENTS ARE INSERTED ONLY FOR THE PAPER RUNWAY OPTION



DATA BUS		DWC NO		REV	
A	C	A	C	A	A
LOC IPC2		SHEET 24		CROSS REF NO 0206	


CONTROLLER/HD LOGIC (PAPER MOTION)

LOC. IPC2
CROSS REF NO. 0206

SEE ADAPTER KIT (JB-33) BELL

BELL

SEE AUDIBLE ALARM KIT




REV	A
DWG NO	C
CROSS REF NO	0207
LOC	IPC2
SHEET	25


MATRIX MICROPROCESSOR CONTROLLER

* AVAILABLE BUT TYPICALLY NOT ASSEMBLED

LOC. IPC2
CROSS REF NO. 0207




LOC. : PC2	DRWG. NO.	REV.
CROSS REF NO. 0208		A
	CODE (FRMT)	
	BASE (DI)	C
	LOC. : IPC2	
	DATE: 26	




CODE IDENT	DWG NO	REV
DATA	C	A
BASE OI		
LOC IPC2	SHEET 27	CROSS REF NO 0208

LOC. IPC2	CROSS REF NO. 0209
-----------	--------------------



LOC IDENT	DWG NO	REV
DATA	C	A
BASE 01		
LOC IPC2	SHEET 28	CROSS REF NO 0210

MATRIX MICROPROCESSOR CONTROLLER	
LOC : PC2	
CROSS REF NO. 0210	




CODE IDENTITY	REV
DATA	A
BASE OI	C
LOC IPC2	SHEET 29
CROSS REF NO. 0211	

MATRIX MICROPROCESSOR CONTROLLER

LOC. IPC2
CROSS REF NO. 0211

* NOT ASSEMBLED FOR STD PM 125. SEE APL FOR ASSY DATA.




REV	A
DWG NO	C
CROSS REF NO	0212
SHEET	30
LOC.	IPC2


MATRIX
MICROPROCESSOR
CONTROLLER

LOC. IPC2
CROSS REF NO. 0212

PORT 1




LOC. 1PC2	CROSS REF. NO. 0213	CODE IDENT. DATA BASE A	DWG. NO. C	REV. A
MATRIX MICROPROCESSOR CONTROLLER		LOC. 1PC2	SHEET 31	CROSS REF. NO. 0213



SEE ADAPTER KIT
SEE ADAPTER KIT

MATRIX MICROPROCESSOR CONTROLLER

LOC. 1PC2
CROSS REF NO. 0214




COORDINATE	DATE	DWG NO	REV
LOC. 1PC2	BASE 01	C	A
LOC. 1PC2		SHEET 33	CROSS REF NO 0215

LOC. 1PC2
CROSS REF NO. 0215

* AVAILABLE, BUT TYPICALLY NOT ASSIGNED

COMP. BY J/M





CODE IDENT	DWG NO	REV
DATA	C	A
BASE D1		
LOC 1PC2	SHEET 34	CROSS REF NO 0216

MATRIX MICROPROCESSOR

LOC. 1PC2
CROSS REF NO. 0216

* AVAILABLE BUT TYPICALLY NOT ASSEMBLED





TEST PRINT CHARACTER CODES (OPTIONAL)

4 3 2 1


REV	A
DWG NO	C
COR IDENT	BASE 01
LOC	IPC2
SHEET	38
CROSS REF NO	0218

MATRIX MICROPROCESSOR CONTROLLER

4 3 2 1

LOC. IPC2
CROSS REF NO. 0218


* AVAILABLE BUT TYPICALLY NOT ASSEMBLED



REV	B
DWG NO	C
CODE UNIT	LOC IPC2
BASE OI	SHEET 38
CROSS REF NO	0220

MATRIX MICROPROCESSOR CONTROLLER

LOC. IPC2
CROSS REF NO. 0220




CODE (ORNT)	DWG NO	REV
DATA	C	A
BASE 01	LOC 1PC2	CROSS
	SHEET 38	REF NO 0221

MATRIX MICROPROCESSOR CONTROLLER


LOC. 1PC2
CROSS
REF NO. 0221

* AVAILABLE BUT TYPICALLY NOT ASSEMBLED

BLANK CODE (OPTION)



PORT 4 (REQ'D FOR PM70, OPTIONAL FOR PM125)



REV	C
DWG NO	C
COD. UNIT	LOC 1PC2
BASE A	SHEET 41
CROSS	REF NO 0223


LOC. 1PC2
CROSS
REF NO. 0223

MATRIX
MICROPROCESSOR
CONTROLLER

0761-SPC1-J1-14

SEE I/O KIT

ALL EVEN PINS IN CON.
J7 ARE GND
* AVAILABLE BUT TYPICALLY
NOT ASSEMBLED



LOC IDENT	DWG NO	REV
DATA	C	A
BASE 01	LDC IPC2	CROSS REF NO 0224
SHEET 42		1

MATRIX
MICROPROCESSOR
CONTROLLER

△ ALL EVEN PINS GND
* AVAILABLE BUT TYPICALLY NOT ASSEMBLED

LOC. 1PC2
CROSS REF NO. 0224

LOCATION


4PC1

CONTROL PANEL BOARD


BOARD NUMBER
See Chart Below

PAGE NO.
9-20 A-B/C

4PC1 CONTROL PANEL ASSY	SWITCHES AND LAMPS															
	S1	L1	S2	L2	S3	L3	S4	L4	S5	L5	S6	L6				
95440400	START STOP	X	FORM FEED	-	-	-	-	-	-	-	-	-				
95440401	START STOP	X	FORM FEED	-	-	-	SINGLE SPACE	-	-	-	-	-				
95440402	START STOP	X	FORM FEED	-	TEST PRINT	X	SINGLE SPACE	-	-	-	-	-				
95440403	START STOP	X	FORM FEED	-	TEST PRINT	X	-	-	-	-	-	-				



CONTROL PANEL BOARD 95440400/01/02 and 03



- NOTES--
- S2 THRU S6 ARE OPTIONAL
 - L2 THRU L6 ARE OPTIONAL
 - S1 & S9 ARE CONTROLLER HARD WIRED AND MAY NOT CHANGE FUNCTION.
 - S2 AND S4 THRU S9 CAN BE FUNCTION PROGRAMMED.
 - S7 AND S8 ARE SPECIAL FUNCTION SELECT SWITCHES AND ARE NOT OPERATOR ACCESSIBLE.
 - J2-A THRU J2-J ARE HOLES FOR HIRING EXTERNAL SWITCHES S7, S8, S9.
 - A, B AND C ARE JUMPERS USED WHEN THE SWITCH IS NOT INSTALLED.

LAST "C" USED-C2
 LAST "9" USED-S9
 LAST "L" USED-L6
 LAST "1C" USED-1C3

LOC. 4PC1
 CROSS REF NO. 0401

DATA BASE	REV
A	A
C	
LOC 4PC1	CROSS REF NO 0401
SHEET 43	

LOCATION


2PC1

NEEDLE DRIVER BOARD


BOARD NUMBER
See Chart Below

PAGE NO.
9-22 A-C

2PC1 NEEDLE DRIVER ASSY	MODEL
9542020/04/08	PM 70 - 7 WIRE
9542020/05/09	PM 125 - 7 WIRE
9542020/06/10	PM 70 - 9 WIRE
9542020/07/11	PM 125 - 9 WIRE




9-22 A



9-22 A

NEEDLE DRIVER BOARD 95420200/-1/02/03/04/05/06/07/08/09/10/11

OCT. , 78



DATA BASE	A	REV	A
LOC 2PC1	C	DWG NO	
CROSS REF NO	0501	SHEET	44

LOC 2PC1	0205-1PC2- J6-22
CROSS REF NO	0501
REF NO	0501

NEEDLE DRIVERS

1 R13 510 5W Tab 04 Thru 11 Board Assy's
R13 3.5K OHMS 1/2W Tab 00, 01, 02 & 03 BOARD ASSY'S

D C B A

1

2

3

4

D C B A

1

2

3


4

OFF. SHEET REFERENCES	DATA INPUT CONN., J4	FUNCTION	I.C. GATE		DRIVER COIL OUTPUT			
			IDENT	INPUT	OUTPUT	CONN.	-PIN	-PIN
0213-1PC2-P6-30	30	SELECT 1R	IC3	5	6	J1	13	12
0213-1PC2-P6-29	29	SELECT 2R	IC3	3	4	J1	5	4
0213-1PC2-P6-32	32	SELECT 3R	IC3	1	2	J1	11	10
0213-1PC2-P6-33	33	SELECT 4R	IC3	9	8	J1	3	2
0213-1PC2-P6-31	31	SELECT 5R	IC3	11	10	J1	9	8
0213-1PC2-P6-34	34	SELECT 6R	IC3	13	12	J1	24	23
0213-1PC2-P6-26	26	SELECT 7R	IC2	5	6	J1	7	6
0213-1PC2-P6-28	28	SELECT 8R	IC2	3	4	J1	22	21
0213-1PC2-P6-27	27	SELECT 9R	IC2	1	2	J1	20	18
0213-1PC2-P6-1	1	SELECT 1L	IC4	5	6	J5	13	12
0213-1PC2-P6-3	3	SELECT 2L	IC4	3	4	J5	5	4
0213-1PC2-P6-5	5	SELECT 3L	IC4	1	2	J5	11	10
0213-1PC2-P6-2	2	SELECT 4L	IC4	13	12	J5	3	2
0213-1PC2-P6-4	4	SELECT 5L	IC4	11	10	J5	9	8
0213-1PC2-P6-6	6	SELECT 6L	IC4	9	8	J5	24	23
0213-1PC2-P6-8	8	SELECT 7L	IC5	13	12	J5	7	6
0213-1PC2-P6-10	10	SELECT 8L	IC5	11	10	J5	22	21
0213-1PC2-P6-12	12	SELECT 9L	IC5	9	8	J5	20	18

NEEDLE DRIVER

DATA BASE	SWG NO	REV
A C		A
LOC 2PC1	SHEET 45	CROSS REF NO 0502

SPARE GATES



LAST "C" USED-C7
 LAST "CR" USED-CRS
 LAST "R" USED-R21
 LAST "Q" USED-Q7

LOC. 2PC1
 CROSS REF NO. 0502


LOCATION

2PC2


HORIZONTAL TRANSDUCER BOARD

BOARD NUMBER PAGE NO.
See Chart Below 9-24 A-B/C

2PC2	
HORIZONTAL TRANSDUCER	MODEL
44670302	PM 325
44670303	PM 70



HORIZONTAL TRANSDUCER BOARD 44670302 and 03.



NOTE

△ -2 CHANNEL READER USED IN 2 HEAD PRINTER.
CHAR ST 3 AND CHAR ST 4 NOT USED.

-4 CHANNEL READER USED IN 1 HEAD PRINTER.

DATA BASE		DWG NO	REV
A	C		A
LOC. 2PC2		SHEET 46	CROSS REF NO 0601

HORIZONTAL TRANSDUCER

LOC. 2PC2
CROSS REF NO. 0601

LOCATION



5PC1

VERTICAL TRANSDUCER BOARD


BOARD NUMBER
See Chart Below

PAGE NO.
9-26 A-B/C

SPC1 VERTICAL TRANSDUCER ASSY	SWITCHES				READER				EVFU OPT- ION	
	S1 EVFU	S2	S3	S4	2	CH	4	CH		
		6/8 LPI	10/16-5 LPI	SPARE						
95432100 (6)										
95432101 (4)	X								X	X
95432102 (2)		X							X	X
95432103 (0)									X	
95432104 (8)										
95432105 (6)									X	X
95432106	X	X	X						X	X
95432107	X	X	X						X	X



VERTICAL TRANSDUCER BOARD 95432100/01/02/03/04/05/06 and 07



DATA BASE	DWG NO	REV
A	C	A
LOC 5PC1	SHEET 47	CROSS REF NO 0701

LOC. 5PC1
CROSS REF NO. 0701

- NOTES-
- ▲ JUMPER "A" IS IN WHEN S1 IS NOT INSTALLED.
 - ▲ CHANNELS 3 & 4 ARE OPTIONAL FOR SPECIAL FUNCTIONS. CHANNEL 1 MAY BE EITHER 8 LPI OR 10 LPI STP.
 - ▲ JUMPER B OR SWITCH S2, AND JUMPER C OR SWITCH S4, MUST BE INSTALLED WHENEVER THE OPTIONAL IC1 IS INSTALLED.

LOGIC TERM INDEX

LOCATION	REF. NO.	TERM
<u>A</u>		
1PC2	0216	-ACK
1PC2	0215	ACK INT
1PC2	0214	ACK OUT
1PC2	0216	ADDRESS 0 - ADDRESS 7
1PC2	0224	ADDRESS 8 - ADDRESS 15
1PC2	0207	ADDRESS BUS
1PC2	0214	ADV
1PC2	0208	-ADV
1PC2	0208	-A14
<u>B</u>		
1PC2	0207	BELL
1PC2	0221	BLK CODE 0-7
2PC2	0501	BUSS BAR A1 + B1
1PC2	0216	BUSY
<u>C</u>		
1PC2	0222	CH3
5PC1	0701	CHAN 1-8
1PC2	0208	-CHAR READ
1PC2	0222	CHAR ST
2PC2	00501	CHAR ST 1-4
1PC2	0215	CHNL 1
1PC2	0215	CHNL 2
1PC2	0220	CHR STRT O/S
1PC2	0221	CLK 2
1PC2	0221	-CLK 2
1PC2	0221	CLK 4
1PC2	0223	-CMP
5PC1	0701	COM
5PC1	0701	-COMPRESSED PITCH SELECT
1PC2	0213	CONCR
1PC2	0207	CPU DATA BUS
1PC2	0209	-CS 1 - -CS 16
1PC2	0216	CS ADDRESS BUS
<u>D</u>		
1PC2	0217	D0 - D7
1PC2	0211	DB0 - DB3
1PC2	0210	DB4 - DB7
1PC2	0207	DBIN
1PC2	0216	-DIEN ADDRESS BUS
<u>E</u>		
1PC2	0222	EVEN CH ST
<u>F</u>		
1PC2	0219	FMT CH 1
1PC2	0219	FMT CH2
1PC2	0216	-FORM FEED
<u>G</u>		
1PC2	0214	GATE OSC
1PC1	0101	GND
<u>H</u>		
1PC2	0204	HBD
1PC2	0201	HD RDY
1PC1	0103	HIFB
1PC1	0103	HIFB RETURN
1PC2	0207	HLDA
1PC2	0222	HOME L
1PC2	0222	HOME R
1PC2	0204	HVFB
<u>I</u>		
1PC2	0207	INTE
4PC1	0401	INTLR
1PC2	0222	INTRPT
1PC2	0208	-I/O READ
1PC2	0208	-I/O WRITE
2PC1	0501	I SENSE

LOGIC TERM INDEX (continued)

LOCATION	REF. NO.	TERM
<u>L</u>		
1PC2	0219	-LD VFU
1PC2	0213	LINE FEED O/S
<u>M</u>		
1PC2	0219	MC
1PC2	0208	-MEM READ
1PC2	0208	-MEM WRITE
1PC2	0214	MOVE HD L
1PC2	0214	MOVE HD R
1PC2	0208	-MOV L
1PC2	0208	-MOV R
1PC2	0220	-MT 3
1PC1	0103	MTR
<u>N</u>		
1PC2	0201	-NDL ENAB
1PC2	0213	NXT COL RDY
<u>O</u>		
1PC2	0213	OBF
1PC2	0222	ODD CH ST
1PC2	0219	-OOP
<u>P</u>		
1PC2	0217	-PM CMPL
1PC2	0213	PM COMP
1PC2	0214	-PRT BUSY
1PC2	0223	-PWR ON ST EN
<u>R</u>		
1PC2	0219	-READY
1PC2	0207	RESET
1PC2	0219	RDY ENABL
<u>S</u>		
1PC2	0213	SEL 1L - 9L
1PC2	0213	SEL 1R - 9R
1PC2	0223	-SEL 30 MODE
1PC2	0201	SERVO INHIB
1PC2	0201	-SHUT DOWN
1PC2	0223	SPARE
1PC2	0214	START ENABL
1PC2	0219	-START LAMP
1PC2	0219	START/STOP
1PC2	0223	STATUS BIT 0-5
1PC2	0215	-STOP
1PC2	0216	STROBE
1PC2	0207	-STST B
1PC2	0208	SYSTEM DATA BUS
<u>T</u>		
1PC2	0220	-TEST PRINT
1PC2	0219	-TEST PRINT LAMP
1PC2	0214	TEST PRINT MODE
1PC2	0201	-TOP OPEN
1PC2	0218	TP BIT 0 - 7
<u>V</u>		
1PC2	0206	VBD
1PC1	0103	VIFB
2PC1	0501	VREF
1PC2	00206	VVFB
<u>W</u>		
1PC2	0207	WAIT
1PC2	0207	-WR

LOGIC TERM INDEX (continued)

LOCATION	REF. NO.	TERM
<u>NUMERIC</u>		
1PC2	0212	0
1PC2	0212	1 - 5
1PC2	0212	5V
1PC1	0103	-5V
1PC1	0103	-5V I/O
5PC2	0201	6 LPI SEL
1PC2	0216	6 LPI STP
5PC1	0701	-6 LPI STP
1PC2	0215	6/8 LINE
1PC2	0220	8 LPI STP
5PC1	0701	-8 LPI STP
1PC2	0214	8080 RDY
1PC1	0102	12V
1PC1	0103	-12V
1PC1	0102	12V I/O
1PC1	0101	-36V

UNIQUE CDC PRINTER CONFIGURATIONS

INTRODUCTION

This section is designed to supplement Sections 1 through 9 of this manual by defining the unique CDC configurations and special features not previously defined. This section is divided into two parts; Special Features, and Configurations.

SPECIAL FEATURES

This section defines the unique CDC special features that have been factory installed in the various models of the CT104 Matrix Printers as part of the original equipment configurations.

These special features are described in detail below.

Operator Visible LED Diagnostics Feature

The operator visible LED diagnostics feature consists of 6 light emitting diodes mounted on the left side plate of the printer and replaces the standard LED diagnostics option which is available on the controller electronics card 1PC2.

With this feature installed, the operator may view the LED indicators without having to remove the printer covers to gain access to 1PC2 board assembly. The operator visible LED indicators may be viewed by removing the side cover on the left side of the cabinet cover.

With this feature installed, the controller electronics isolates and displays on the six (6) LED lamps, a binary code for a controller detectable error condition. A summary of these codes and their interpretation is

given in Figure 6-4 in the Fault Isolation Section of this manual.

The operator visible LED diagnostics feature functions in the same manner as the 1PC2 mounted version, with the exception that the fault signals are routed by a cable from connector 1PC2-J13 to the side of the printer for display (see Figure 10-2).

Printer To Data Source Fault Detection Feature

With this feature installed, the printer isolates and transmits a binary code to the data source whenever the printer controller detects an error condition or operation (a summary of these binary codes and their interpretation is given in Figure 6-4 in the Fault Isolation Section of this manual). The data source then uses this binary code information to control data transmission and printer status. In addition to the standard interface signals, there are six (6) status lines which convey these binary codes through the printer interface connector to the data source (see Figure 10-1).

Printer Interfaces

Three different interfaces are presently used on ODC printers, the Standard Interface, the Standard Interface With Fault Detection Feature and the RS-232 Interface. The Standard Interface and the Standard Interface With Fault Detection Feature are both shown in Figure 10-1. For additional information on the Standard Interface see Page 1-8 or the Introduction to this manual. The RS-232 Interface is shown in Figure 10-2. For additional information on the RS-232 Interface see the separate RS-232 Interface manual, publication number 95445069.




FIGURE 10-1. STANDARD INTERFACE PIN ASSIGNMENTS




FIGURE 10-2. RS-232 INTERFACE PIN ASSIGNMENTS

CONFIGURATIONS

This section defines the basic configuration of CDC equipments CT104A, CT104B, CT104C, CT104D and CT104E.

CDC Matrix Printer Equipment CT104A (TLA 95453000)

Printing Rate = 70 lines per minute (7x7 character pattern).

Character Pitch = 10 characters per inch.

Characters Per Line = 132 max. via a 4 channel code strip reader.

Print Head = One, nine wire print head capable of printing matrix dot patterns of 7x7, 7x9, 9x7 and 9x9.

Vertical Line Spacing = 6 Lines per inch via a 2 channel code disc reader and a 2 channel Electronic Vertical Format Unit (EVFU) brush reader.

Voltage and Frequency = 120 VAC standard with tap selectable ranges from 90 VAC to 278 VAC. Frequency is 50/60 HZ (49.0 to 60.6 HZ)

Control Panel Switches = Start/Stop and Form Feed.

Interface = RS-232 Buffered Interface (Figure 10-2).

Features:

- | | |
|--|-----------------------|
| 1. Automatic Line Feed | Pg. 1-9 and 4-8 |
| 2. Automatic Double Space | Pg. 1-9 and 4-8 |
| 3. Test Print (1PC2 Controller Board mounted) | Pg. 1-9 |
| 4. Electronic Vertical Format Unit (EVFU) | Pg. 1-10, 2-2 and 2-5 |
| 5. Elongated Character | Pg. 1-9 and 4-8 |
| 6. 80 Column | Pg. 1-9 and 4-8 |
| 7. LED Diagnostics (1PC2 Controller Board mounted) | Pg. 1-11. |
| 8. Character Generator Rom Set (U.S. 64 Char ASCII, 7x7) 95448900. | Pg. A-3 |

CDC Matrix Printer Equipment CT104B (TLA 95453001)

Printing Rate = 70 lines per minute (7x7 character pattern)

Character Pitch = 10 characters per inch.

Characters Per Line = 132 max. via a 4 channel code strip reader.

Print Head: One, nine wire print head capable of printing matrix dot patterns of 7x7, 7x9, 9x7 and 9x9.

Vertical Line Spacing = 6 lines per inch via a 2 channel code disc reader and a 2 channel Electronic Vertical Format Unit (EVFU) brush reader.

Voltage and Frequency = 120 VAC standard with tap selectable ranges from 90 vac to 278 VAC. Frequency is 50/60 HZ (49.0 to 60.6 HZ).

Control Panel Switches = Start/Stop and Form Feed.

Interface = None (unit is not supplied with interface connector or interface).

Features:

- | | |
|--|-----------------------|
| 1. Automatic Line Feed | Pg. 1-9 and 4-8 |
| 2. Automatic Double Space | Pg. 1-9 and 4-8 |
| 3. Test Print (1PC2 Controller Board mounted) | Pg. 1-9 |
| 4. Electronic Vertical Format Unit (EVFU) | Pg. 1-10, 2-2 and 2-5 |
| 5. Elongated Character | Pg. 1-9 and 4-8. |
| 6. 80 Column | Pg. 1-9 and 4-8 |
| 7. LED Diagnostics (1PC2 Controller Board mounted) | Pg. 1-11. |
| 8. Character Generator Rom Set (U.S. 64 Char. ASCII 7x7) 95448900. | Pg. A-3 |

CDC Matrix Printer Equipment CT104 C (TLA 95453002).

Printing Rate = 70 lines per minute (7x7 character pattern).

Character Pitch = 10 characters per inch.

Characters Per Line = 132 max. via a 4 channel code strip reader.

Print Head = One, nine wire print head capable of printing matrix dot patterns of 7x7, 7x9, 9x7 and 9x9.

Vertical Line Spacing = 6 lines per inch via a 2 channel code disc reader and a 2 channel Electronic Vertical Format unit (EVFU) brush reader.

Voltage and Frequency = 120 VAC standard with tap selectable ranges from 90 VAC to 278 Vac. Frequency is 50/60 HZ (49.0 to 60.6 HZ).

Control Panel Switches = Start/Stop , Form Feed and Test Print.

Interface = Standard 36 pin interface connector connected directly to the printer Controller Board 1PC2 (Figure 10-1).

Features:

- | | |
|--|-----------------------|
| 1. Automatic Line Feed | Pg. 1-9 and 4-8 |
| 2. Automatic Double Space | Pg. 1-9 and 4-8. |
| 3. Test Print (1PC2 Controller Board mounted switch plus control panel mounted switch) | Pg. 1-9 and 1-12. |
| 4. Electronic Vertical Format Unit (EVFU) | Pg. 1-10, 2-2 and 2-5 |
| 5. Elongated Character | Pg. 1-9 and 4-8 |
| 6. 80 Column | Pg. 1-9 and 4-8 |
| 7. LED Diagnostics (1PC2 Controller Board mounted) | Pg. 1-11. |
| 8. Character Generator Rom Set (U.S. 64 Char ASCII, 7x7) 95448900. | Pg. A-3 |

CDC Matrix Printer Equipment CT104D (TLA 95453003).

Printing Rate = 70 lines per minute (7x7 character pattern).

Character Pitch = 10 characters per inch (standard pitch) or 16.5 characters per inch (compressed pitch).

Characters Per Line = 132 max. via a 4 channel code strip reader.

Print Head = One, nine wire print head capable of printing matrix dot patterns of 7x7, 7x9, 9x7, and 9x9.

Vertical Line Spacing = Switch selectable 6 or 8 lines per inch via a 2 channel code disc reader and a 2 channel Electronic Vertical Format Unit (EVFU) brush reader.

Voltage and Frequency = 120 VAC standard with tap selectable range from 90 VAC to 278 VAC. Frequency is 50/60 HZ (49.0 to 60.6 HZ).

Control Panel Switches = Start/Stop, Form Feed and Test Print.

Interface = RS-232 Buffered Interface (Figure 10-2).

Features:

- | | |
|--|-----------------------|
| 1. Automatic Line Feed | Pg. 1-9 and 4-8. |
| 2. Automatic Double Space | Pg. 1-9 and 4-8. |
| 3. Test Print (1PC2 Controller Board mounted switch plus control panel mounted switch) | Pg. 1-9 and 1-12. |
| 4. Electronic Vertical Format Unit (EVFU) | Pg. 1-10, 2-2 and 2-5 |
| 5. Elongated Character | Pg. 1-9 and 4-8 |
| 6. 80 Column | Pg. 1-9 and 4-8. |
| 7. LED Diagnostics (operator visible LED display mounted on side plate of printer) | Pg. 10-1 |
| 8. 6 x 8 Line Per Inch | Pg. 1-11 and 2-8. |
| 9. Compressed Pitch | Pg. 1-12 and 2-8. |
| 10. Character Generator Rom Set (U.S. 96 Char. ASCII, 9x7) 44676070. | Pg. A-3 |

CDC Matrix Printer Equipment CT014E (TLA 95453004)

Printing Rate = 70 Lines per minute (7x7 character pattern).

Character Pitch = 10 characters per inch (standard pitch) or 16.5 character per inch (compressed pitch).

Characters Per Line = 132 max. via a 4 channel code strip reader.

Print Head = One, nine wire print head capable of printing matrix dot patterns of 7x7, 7x9, 9x7, and 9x9.

Vertical Line Spacing = Switch selectable 6 or 8 lines per inch via a 2 channel code disc reader and a 2 channel Electronic Vertical Format Unit (EVFU) brush reader.

Voltage and Frequency = 120 VAC standard with tap selectable range from 90 VAC to 278 VAC. Frequency is 50/60 HZ (49.0 to 60.6 HZ).

Control Panel Switches = Start/Stop, Form Feed and Test Print.

Interface. = Standard 36 pin interface connector connecting 29 interface signals and 6 diagnostic status bits directly to and from the printer Controller Board 1PC2 (Figure 10-1).

Features:

- | | |
|--|------------------------|
| 1. Automatic Line Feed | Pg. 1-9 and 4-8. |
| 2. Automatic Double Space | Pg. 1-9 and 4-8. |
| 3. Test Print (1PC2 Controller Board mounted Switch plus control panel mounted switch) | Pg. 1-9 and 1-12. |
| 4. Electronic Vertical Format Unit (EVFU) | Pg. 1-10, 2-2 and 2-5. |
| 5. Elongated Character | Pg. 1-9 and 4-8 |
| 6. 80 Column | Pg. 1-9 and 4-8 |
| 7. Diagnostics (Printer To Data Source Fault Detection) | Pg. 10-1 |
| 8. 6/8 Line Per Inch | Pg. 1-11 and 2-8. |
| 9. Compressed Pitch | Pg. 1-12 and 2-8. |
| 10. Character Generator Rom Set (U.S. 96 Char ASCII, 9x7) 44676070. | Pg. A-3 |

APPENDIX A

PROGRAM AND CHARACTER ROM SETS

GENERAL

This appendix contains all of the various Program and Character ROM sets presently offered for use with the 70/125 LPM Matrix Printers. Also included in this appendix are tables to insure that the ROMS from any given Character or Program set are installed in their correct locations.

This appendix also contains the Character Definition and Code Drawings for each of the Character ROM sets.

CAUTION

INTEGRATED CIRCUITS AND MOS CHIPS ARE ABOUT TO BE HANDLED AND ARE PRESENT ON THE PRINTED CIRCUIT BOARDS IN THIS PRINTER. THESE DEVICES ARE EASILY DESTROYED IF A STATIC ELECTRICAL CHARGE IS ACCIDENTALLY APPLIED TO A PIN THROUGH IMPROPER HANDLING OR REPAIR. THESE STATIC CHARGES CAN BE MINIMIZED OR ELIMINATED IF PROPER PRECAUTIONS ARE OBSERVED.*

- A.* WHEN HANDLING INTEGRATED CIRCUITS OR PLUG-IN BOARDS, DO NOT TOUCH THE CIRCUITS, PINS OR PLUG-IN BOARD CONNECTOR PINS.* HANDLE BY THE EDGE ONLY.*
- B.* WHEN REMOVING OR INSERTING A CHIP OR BOARD, GROUND YOURSELF TO THE UNIT FRAME BEFORE TOUCHING THE CHIP OR BOARD.* DO NOT REMOVE OR INSERT A CHIP OR BOARD WITH THE UNIT POWERED ON.*
- C.* DO NOT REMOVE A PLUG IN BOARD OR CHIP FROM ITS SHIPPING CARTON UNTIL READY TO INSERT IT INTO THE PRINTER.*
- D. USE ONLY A THREE WIRE SOLDERING IRON WHEN REPAIRING PRINTED CIRCUIT BOARDS. LAY THE BOARD ON AN INSULATED PIECE OF MATERIAL.* DO NOT LAY THE BOARD ON METAL OR PLASTIC.

PROGRAM ROM SET AND LOCATION TABLE

PROGRAM ROM SET ¹	LOCATION A1 ²	LOCATION B1 ²	LOCATION C1 ²	LOCATION D1 ²	LPM			STATUS	REPLACED BY
					50	70	125		
44673465	44673466	44673467	44673468	44673469		X		INACTIVE	44674588
44674088	44674090	44674089	Not Used	Not Used			X	INACTIVE	44674879
44673463	44673464	44673470	Not Used	Not Used			X	INACTIVE	44674882
44674091	44674092	44674093	44674094	44674095		X		INACTIVE	44673471
44674588	44674589	44674590	44674591	44674592		X		INACTIVE	44675515
44674879	44674880	44674881	Not Used	Not Used			X	ACTIVE	-----
44674882	44674883	44674884	Not Used	Not Used			X	ACTIVE	-----
44673471	44673480	44673481	44673482	44673483		X		INACTIVE	44675513
44675513	44673480	44673481	44675514	44673483		X		INACTIVE	} ³ ----- ----- -----
44675513	15153216	15153217	15153218	15153219		X		ACTIVE	
44675515	44674589	44674590	44675516	44674592		X		ACTIVE	
44675651	44675653	44674590	44675654	44674592	X			ACTIVE	

¹ THE PART NUMBERS SHOWN IN LOCATIONS A1, B1, C, AND D1 ARE FOR INSTALLATION IDENTIFICATION PURPOSES ONLY. WHEN ORDERING REPLACEMENT ROMS REFER TO THE PROGRAM ROM SET NUMBERS.

² SEE PAGE A4 TO DETERMINE THE LOCATION OF A1, B1, C1 AND D1 ON THE CONTROLLER AND PRINT HEAD BOARD IN CARD LOCATION IPC2.

³ PROGRAM ROM SET 44675513 IS LISTED TWICE, THE FIRST LISTING USES EPROMS IN LOCATIONS A1 THRU D1 AND HAS BEEN REPLACED BY THE SECOND LISTING WHICH USES ROMS IN LOCATIONS A1 THRU D1. BOTH OF THESE PROGRAM ROM SETS ARE INTERCHANGEABLE.

CHARACTER GENERATOR ROM SET AND LOCATION TABLE

GENERATOR ROM SET ¹	DESCRIPTION	LOCATION E1 ²	LOCATION F1 ²	FOR CHARACTER DEFINITION SEE PAGE
44674594 ³	FARSI (9x9)	44674595	44674596	A-5 AND A-6
44674158	RETAIL APPLICATION	44674159	44674160	A-7, A-8, A-9 AND A-10
95452100	U.S. 64 CHAR. ASCII (. 7x7)	15153201		A-11
95452200	WEST EUROPEAN (7x7)	95452200 or 15153204		A-12
95452300	KATAKANA (9x7)	95452300 or 15153205		A-13 AND A-14
95452400	SPANISH (7x7)	95452400 or 15153203		A-15
95452500	UNITED KINGDOM (7x7)	95452500 or 15153202		A-16
95452600	U.S. UPPER/LOWER (9x7)	95452600 or 15153206		A-17 AND A-18
95452700	PORTUGUESE (7x7)	95442700		A-19
95452800	SWEDEN-FINLAND (7x7)	95452800		A-20
95452900	DENMARK-NORWAY (7x7)	95452900		A-21
95454100	U.S. 96 CHAR. ASCII (7x7)	95454100		A-22 AND A-23
95454600	CYRILLIC/LATIN (7x7)	95454600		A-24 AND A-25
44675194 ³	FARSI -(9x9)	44676895	44676896	A-26 AND A-27
44675197	SWEDISH (7x7)	44675197		A-28 AND A-29
44674653	UNITED KINGDOM 95 CHAR ASCII (7x7)	44674653		A-30 AND A-31
44674889	DANISH (7x7)	44674889		A-32 AND A-33
44676913	UK ASCII (96 CHAR)	44676913		A-34 AND A-35
44676914	SWEDISH-FINNISH (96)	44676914		A-36 AND A-37
44676915	DANISH-NORWAY (96)	44676915		A-38 AND A-39
44676070	U.S. 96 CHAR ASCII (7x9)	95455600	95455601	A-40 AND A-41
95455652	SCANDINAVIAN (7x7)	95455652		A-42 AND A-43
95455659	HEBREW 96 CHAR (7x7)	95455659		A-44 AND A-45
95455667	SOUTH AFR 64 CHAR (7x7)	95455667		A-46
95455668	TURKISH 64 CHAR (7x7)	95455668		A-47
95455669	GREEK 64 CHAR (7x7)	95455669		A-48
95455670	YUGOSLAV 64 CHAR (7x7)	95455670		A-49
44677533 ⁴	THAILAND 128 CHAR (9x9)	95455671	95455672	A50 AND A-51
44681888	KOREAN 97 CHAR (9X7)	95455678		A-53
44682594	GERMAN 96 CHAR (7x9)	95455682	95455683	A-55
44683798	ESC 95 CHAR (7x7)	95455684		A-57
44685284	ESC 96 CHAR (7x7)	95455685		A-59
44685591	ESC 96 CHAR (7x7) (Greek)	95455686		A-61

¹ THE PART NUMBERS SHOWN IN LOCATIONS E1 AND F1 ARE FOR INSTALLATION IDENTIFICATION PURPOSES ONLY. WHEN ORDERING REPLACEMENT ROMS REFER TO THE GENERATOR ROM SET NUMBERS.

² SEE PAGE A-4 TO DETERMINE THE LOCATION OF E1 AND F1 ON THE CONTROLLER AND PRINT HEAD BOARD IN CARD LOCATION 1PC2. THE PART NUMBERS IN E1 & F1 ARE THE PART NUMBERS THAT WILL APPEAR ON THE ROMS.

³ A FINAL HORIZONTAL SERVO ADJUSTMENT PROCEDURE IS NECESSARY IN SETS UTILIZING 9 WIDE CHARACTER GENERATOR ROMS. FOR REFERENCE LOCATION OF CONTROLLER AND PRINT HEAD BOARD (CARD LOCATION 1PC2) SEE FIGURES ON PAGE A-4.

A. MAKE THE ADJUSTMENTS IN THIS STEP WITH THE 7 WIDE CHARACTER GENERATOR ROM INSTALLED:

1. TRIGGER THE OSCILLOSCOPE ON THE CHARACTER START O/S PULSES AT TP15 (TP15 COMES FROM 1PC2-H1, PIN 5)
2. SET THE OSCILLOSCOPE HORIZONTAL TIME BASE TO 1 MSEC. /DIVISION.
3. ADJUST HEAD SPEED (POT P4) AND BALANCE HEAD SPEED (POT P7) SO THE TIME BETWEEN THE CHARACTER START PULSES IS 9.2 MSEC. ± .1 MSEC. IN BOTH DIRECTIONS.

NOTE

THE SLOWER SPEED MAY CAUSE THE PRINT HEAD TO HANG UP NEAR THE RIGHT OR LEFT HOME POSITION. IF THIS OCCURS THE PRINTER MUST BE POWERED OFF AND ON, AND THE ADJUSTMENT PROCEDURE RESUMED.

B. REMOVE THE 7 WIDE CHARACTER GENERATOR ROM FROM CHIP SOCKET LOCATION E1 AND INSTALL THE 9 WIDE CHARACTER GENERATOR ROM.

C. ADJUST POT P2 UNTIL RIGHT-TO-LEFT AND LEFT-TO-RIGHT PRINTING OF THE CHARACTER COLUMNS ARE ALIGNED FROM ONE LINE OF PRINT TO THE NEXT.



⁴ ALSO USED IN HANGUL CHARACTER KIT 44681896

































































CONTROLLER AND PRINT HEAD BOARD
{CARD LOCATION 1PC2}

PROGRAM ROMS

CHARACTER GENERATOR ROMS









TEST PRINT SWITCH




								
1000 0000	1000 0001	1000 0010	1000 0011	X010 0100	1000 0101	1000 0110	1000 0111	1000 1000
								
1000 1001	1000 1010	1000 1011	1000 1100	1000 1101	1000 1110	1000 1111	1001 0000	1001 0001
								
1001 0010	1001 0011	1001 0100	1001 0101	1001 0110	1001 0111	1001 1000	1001 1001	1001 1010
								
1001 1011	1001 1100	1001 1101	1001 1110	1001 1111	X010 0000	X010 0001	X010 0010	X010 0011
								
X010 0100	X010 0101	X010 0110	X010 0111	X010 1000	X010 1001	X010 1010	X010 1011	X010 1100
								
X010 1101	X010 1110	X010 1111	X011 0000	X011 0001	X011 0010	X011 0011	X011 0100	X011 0101
								
X011 0110	X011 0111	X011 1000	X011 1001	X011 1010	X011 1011	X011 1100	X011 1101	X011 1110
								
X011 1111								


X100 0000	X100 0001	X100 0010	X100 0011	X100 0100	X100 0101	X100 0110	X100 0111	X100 1000
X100 1001	X110 1010	X100 1011	X100 1100	X100 1101	X100 1110	X100 1111	X101 0000	X101 0001
X101 0010	X101 0011	X101 0100	X101 0101	X101 0110	X101 0111	X101 1000	X101 1001	X101 1010
X101 1011	X101 1100	X101 1101	X101 1110	X101 1111	X110 0000	X110 0001	X110 0010	X110 0011
X110 0100	X110 0101	X110 0110	X110 0111	X110 1000	X110 1001	X110 1010	X110 1011	X110 1100
X110 1101	X110 1110	X110 1111	X111 0000	X111 0001	X111 0010	X111 0011	X111 0100	X111 0101
X111 0110	X111 0111	X111 1000	X111 1001	X111 1010	X111 1011	X111 1100	X111 1101	X111 1110
X111 1111								

44674158 (44674159)











44674158 (44674159)






44674158 (44674160)




7 X 7 CHAR DEFINITION & CODE (ASCII) 64

95452100



7 X 7 CHAR DEFINITION (EUROPEAN)

95452200



9 X 7 CHAR DEFINITION (KATAKANA) (1 OF 2)

95452300

*1000 0000	*1000 0001	*1000 0010	*1000 0011	*1000 0100	*1000 0101	*1000 0110	*1000 0111	*1000 1000
*1000 1001	*1000 1010	*1000 1011	*1000 1100	*1000 1101	*1000 1110	*1000 1111	*1001 0000	*1001 0101
*1001 0010	*1001 0111	*1001 0100	*1001 0101	*1001 0110	*1001 0111	*1001 1000	*1001 1001	*1001 1010
*1001 1011	*1001 1100	*1001 1101	*1001 1110	*1001 1111	X010 0000	X010 0001	X010 0010	X010 0011
X010 0100	X010 0101	X010 0110	X010 0111	X010 1000	X010 1001	X010 1010	X010 1011	X010 1100
X010 1101	X010 1110	X010 1111	X011 0000	X011 0001	X011 0010	X011 0011	X011 0100	X011 0101
X011 0110	X011 0111	X011 1000	X011 1001	X011 1010	X011 1011	X011 1100	X011 1101	X011 1110
X011 1111								

95452300




X100 0000




X100 0001




X100 0010




X100 0011



X100 0100



X100 0101




X100 0110




X100 0111




X100 1000




X100 1001




X100 1010



X100 1011



X100 1100



X100 1101



X100 1110




X100 1111




X101 0000




X101 0001




X101 0010



X101 0011




X101 0100



X100 0101



X101 0110



X101 0111




X101 1000



X101 1001




X101 1010




X101 1011




X101 1100



X101 1101



X101 1110



X101 1111



X110 0000



X110 0001



X110 0010



X110 0011




X110 0100



X110 0101




X110 0110



X110 0111




X110 1000



X110 1001




X110 1010



X110 1011



X110 1100



X110 1101




X110 1110



X110 1111



X111 0000



X111 0001




X111 0010




X111 0100



X111 0101




X111 0110




X111 0111



X111 1000



X111 1001



X111 1010



X111 1011




X111 1100



X111 1101




X111 1110



X111 1111


7 X 7 CHAR DEFINITION (SPAIN & LAT AMERICA LESS BRAZIL)

95452400




7 X 7 CHAR DEFINITION (U.K.)


95452500




20 21 22 23 24 25 26 27 28




29 2A 2B 2C 2D 2E 2F 30 31




32 33 34 35 36 37 38 39 3A




3B 3C 3D 3E 3F 40 41 42 43




44 45 46 47 48 49 4A 4B 4C










4D 4E 4F 50 51 52 53 54 55



56 57 58 59 5A 5B 5C 5D 5E




5F



9 X 7 CHAR DEFINITION (96 CHAR ASCII)

95452600



6i




61




62



63



64



65




66




67



68




69



6A



6B




6C



6D



6E




6F



70




71




72



73



74



75



76



77



78




79




7A



7B




7C



7D




7E



7F


7 X 7 CHAR DEFINITION (PORTUGUESE)

95452700




7 X 7 CHAR DEFINITION (SWEDEN - FINLAND)


95452800




20




21




22




23




24




25




26




27




28




29




2A




2B




2C




2D




2E




2F




30




31




32




33




34




35




36




37




38




39




3A




3B



3C




3D




3E




3F




40




41



42




43




44




45




46




47




48




49



4A



4B




4C




4D




4E




4F




50




51




52




53




54



55




56




57




58




59




5A




5B




5C



5D




5E




5F

7 X 7 CHAR DEFINITION (DENMARK-NORWAY)


95452900




20




21




22




23




24



25




26




27




28




29




2A




2B




2C




2D




2E




2F




30




31




32




33




34




35




36




37




38




39




3A




3B




3C




3D




3E




3F




40




41




42




43




44




45




46




47




48




49




4A




4B




4C




4D




4E



4F




50




51




52




53




54




55




56




57




58




59




5A




5B




5C




5D




5E




5F




20




21




22




23




24



25




26




27




28




29




2A




2B




2C




2D




2E




2F




30




31




32




33




34




35




36




37




38




39




3A




3B




3C




3D




3E




3F




40




41




42




43




44




45



46




47




48




49




4A




4B




4C




4D




4E




4F




50




51




52




53




54




55




56




57




58




59




5A




5B




5C



5D




5E




5F

7 X 7 CHAR DEFINITION U.S. 96 ASCII


95454100




60




61




62




63




64




65




66




67




68




69




6A




6B




6C




6D




6E




6F




70




71




72




73




74




75




76




77




78




79




7A




7B




7C



7D




7E




7F


95454600




41/61




62




42/77




67




64




45/65




76




7A




69




6A




4B/6B




6C




4D/6D




4E/6E




4F/6F




7C




50/72




43/73




54/74




75




66




58/68




63




7E




7D




79




78




7C




60




71




3C




21




22




23




24




25




26




27




82




29




2A




2B




2C




2D




30




31




32




33




34




35




36




37




38




39




3A




3B




3C




3D




3F




2E



2F




5F




40


95454600




44




46




47




49




4A




4C




4E




51




52




53




55




56




57




20




59




5A




5B



5C





5D



5E

44675194





60



61




62



63



64



65




67




68




69



69



6A



6B



6C



6D




6E



6F




70




71




72



73




74



75



76



77




78




79



7A




7B




7C




7D




7E




7F




20



21




22




23



24




25




26




27




28




29




2A




2B



2C




2D




2E




2F




30




31




32




33




34




35




36




37




38



39




3A




3B



3C




3D




3E




3F




40




41




42




43




44




45




46




47



48




49




4A




4B




4C




4D



4E




4F



50




51




52




53




54




55




56




57




58




59




5A




5B




5C



5D








5E




5F

44675197







44674653




60




61




62




63




64




65




66




67




68




69




6A




6B




6C




6D




6E




6F




70




71




72




73




74




75




76




77




78




79




7A




7B




7C



7D




7E




7F


44674889




20




21




22




23




24




25




26




27




28




29




2A




2B




2C




2D



2E




2F




30




31




32




33




34




35




36




37




38




39




3A




3B




3C




3D




3E




3F




40




41




42




43




44




45




46




47




48




49




4A




4B




4C




4D




4E




4F




50




51




52




53




54




55



56




57




58




59




5A




5B




5C



5D




5E




5F


44674889




60




61




62




63




64




65




66




67




68




69




6A




6B




6C




6D




6E




6F




70




71




72




73




74




75




76




77




78




79




7A




7B




7C




7D





7E




7F









20




21




22



23



24




25




26




27




28




29




2A




2B




2C




2D




2E




2F




30




31




32




33




34




35




36




37




38




39




3A




3B




3C




3D




3E




3F




40




41




42




43




44




45




46




47




48




49




4A




4B




4C




4D




4E




4F




50




51




52




53




54



55




56




57




58




59




5A




5B




5C







5D





5E




5F












20




21




22




23




24




25




26




27




28




29




2A




2B




2C




2D




2E




2F




30




31




32




33




34




35




36




37




38




39




3A




3B




3C




3D




3E




3F




40




41




42




43




44




45




46




47




48




49




4A



4B




4C




4D




4E




4F




50




51




52




53




54




55




56




57




58




59




5A




5B




5C




5D




5E




5F







CODE CHARACTER DEFINITION SCANDINAVIAN (7x7)
95455652




CODE CHARACTER DEFINITION SCANDINAVIAN (7x7)
95455652




7 X 7 CHAR DEFINITION 96 CHARACTER HEBREW
95455659




60




61




62




63




64




65




66




67




68




69




6A




6B




6C




6D




6E




6F




70




71




72




73




74




75




76




77




78




79




7A




7B




7C




7D





7E




7F







CODE CHARACTER DEFINITION 64 CHARACTER YUGOSLAVIAN 95455670



*X010 0000	*X010 0001	*X010 0010	*X010 0011	*X010 0100	*X010 0101	*X010 0110	*X010 0111	*X010 1000
*X010 1001	*X010 1010	*X010 1011	*X010 1100	*X010 1101	*X010 1110	*X010 1111	*X011 0000	*X011 0001
*X011 0010	*X011 0011	*X011 0100	*X011 0101	*X011 0110	*X011 0111	*X011 0000	*X011 1001	*X011 1010
*X011 1011	*X011 1100	*X011 1101	*X011 1110	*X011 1111	*X100 001X	*X100 001X	*X100 0010	*X100 0011
*X100 0100	*X100 0101	*X100 0110	*X100 0111	*X100 1000	*X100 1001	*X100 1010	*X100 1011	*X100 1100
*X101 1011	*X101 1110	*X101 1111	*X101 001X	*X100 0100	*X101 0010	*X101 001X	*X101 0010	*X101 0101
*X101 0110	*X101 0111	*X101 0000	*X101 1001	*X101 1010	*X101 1011	*X101 1100	*X101 1101	*X101 1110
*X101 1111								

X110 0000	X110 0001	X110 0010	X110 0011	X110 0100	X110 0101	X110 0110	X110 0111	X110 1000
X110 1001	X110 1010	X110 1011	X110 1100	X110 1101	X110 1110	X110 1111	X111 0000	X111 0001
X111 0010	X111 0011	X111 0100	X111 0101	X111 0110	X111 0111	X111 1000	X111 1001	X111 1010
X111 1011	X111 1100	X111 1101	X111 1110	X111 1111	1000 0000	1000 0001	1000 0010	1000 0011
1000 0100	1000 0101	1000 0110	1000 0111	1000 1000	1000 1001	1000 1010	1000 1011	1000 1100
1000 1101	1000 1110	1000 1111	1001 0000	1001 0001	1001 0010	1001 0011	1001 0100	1001 0101
1001 0110	1001 0111	1001 1000	1001 1001	1001 1010	1001 1011	1001 1100	1001 1101	1001 1110
1001 1111								

010 0000	010 0001	010 0010	010 0011	010 0100	010 0101	010 0110	010 0111	010 1000	010 1001
010 1001	010 1010	010 1011	010 1100	010 1101	010 1110	010 1111	011 0000	011 0001	011 0010
011 0010	011 0011	011 0100	011 0101	011 0110	011 0111	011 1000	011 1001	011 1010	011 1011
011 1011	011 1100	011 1101	011 1110	011 1111	100 0000	100 0001	100 0010	100 0011	100 0100
100 0100	100 0101	100 0110	100 0111	100 1000	100 1001	100 1010	100 1011	100 1100	100 1101
100 1101	100 1110	100 1111	101 0000	101 0001	101 0010	101 0011	101 0100	101 0101	101 0110
101 0110	101 0111	101 1000	101 1001	101 1010	101 1011	101 1100	101 1101	101 1110	101 1111
101 1111									
101 1111									

000 0011	001 1010	001 1011	001 1100	001 1101	001 1110	001 1111	110 0000	110 0001	110 0010
110 0011	110 0100	110 0101	110 0110	110 0111	110 1000	110 1001	110 1010	110 1011	110 1100
110 1101	110 1110	110 1111	111 0000	111 0001	111 0010	111 0011	111 0100	111 0101	111 0110
111 0111	111 1000	111 1001	111 1010						








·010 0000	·010 0001	·010 0010	·010 0011	·010 0100	·010 0101	·010 0110	·010 0111	·010 1000	
·010 1001	·010 1010	·010 1011	·010 1100	·010 1101	·010 1110	·010 1111	·011 0000	·011 0001	
·011 0010	·011 0011	·011 0100	·011 0101	·011 0110	·011 0111	·011 1000	·011 1001	·011 1010	
·011 1011	·011 1100	·011 1101	·011 1110	·011 1111	·100 0000	·100 0001	·100 0010	·100 0011	
·100 0100	·100 0101	·100 0110	·100 0111	·100 1000	·100 1001	·100 1010	·100 1011	·100 1100	
·100 1101	·100 1110	·100 1111	·101 0000	·101 0001	·101 0010	·101 0011	·101 0100	·101 0101	
·101 0110	·101 0111	·101 1000	·101 1001	·101 1010	·101 1011	·101 1100	·101 1101	·101 1110	
·101 1111									





·110 0000	·110 0001	·110 0010	·110 0011	·110 0100	·110 0101	·110 0110	·110 0111	·110 1000	
·110 1001	·110 1010	·110 1011	·110 1100	·110 1101	·110 1110	·110 1111	·111 0000	·111 0001	
·111 0010	·111 0011	·111 0100	·111 0101	·111 0110	·111 0111	·111 1000	·111 1001	·111 1010	
·111 1011	·111 1100	·111 1101	·111 1110	·111 1111					

CODE CHARACTER DEFINITION 95 7x7 CHARACTER ESC 44683798

										010 0000	010 0001	010 0010	010 0011	010 0100	010 0101	010 0110	010 0111	010 1000				
										010 1001	010 1010	010 1011	010 1100	010 1101	010 1110	010 1111	011 0000	011 0001				
											011 0010	011 0011	011 0100	011 0101	011 0110	011 0111	011 1000	011 1001	011 1010			
												011 1011	011 1100	011 1101	011 1110	011 1111	100 0000	100 0001	100 0010	100 0011		

110 0000	110 0001	110 0010	110 0011	110 0100	110 0101	110 0110	110 0111	110 1000
110 1001	110 1010	110 1011	110 1100	110 1101	110 1110	110 1111	111 0000	111 0001
111 0010	111 0011	111 0100	111 0101	111 0110	111 0111	111 1000	111 1001	111 1010
111 1011	111 1100	111 1101	111 1110	111 1111				





010 0000	010 0001	010 0010	010 0011	010 0100	010 0101	010 0110	010 0111	010 1000
010 1001	010 1010	010 1011	010 1100	010 1101	010 1110	010 1111	011 0000	011 0001
011 0010	011 0011	011 0100	011 0101	011 0110	011 0111	011 1000	011 1001	011 1010
011 1011	011 1100	011 1101	011 1110	011 1111	100 0000	100 0001	100 0010	100 0011
100 0100	100 0101	100 0110	100 0111	100 1000	100 1001	100 1010	100 1011	100 1100
100 1101	100 1110	100 1111	101 0000	101 0001	101 0010	101 0011	101 0100	101 0101
101 0110	101 0111	101 1000	101 1001	101 1010	101 1011	101 1100	101 1101	101 1110
101 1111								

110 0000	110 0001	110 0010	110 0011	110 0100	110 0101	110 0110	110 0111	110 1000
110 1001	110 1010	110 1011	110 1100	110 1101	110 1110	110 1111	111 0000	111 0001
111 0010	111 0011	111 0100	111 0101	111 0110	111 0111	111 1000	111 1001	111 1010
111 1011	111 1100	111 1101	111 1110	111 1111				

CORPORATE HEADQUARTERS, P.O. BOX 0, MINNEAPOLIS, MINN. 55440
SALES OFFICES AND SERVICE CENTERS IN MAJOR CITIES THROUGHOUT THE WORLD

LITHO IN U.S.A.



CONTROL DATA CORPORATION